



Southeast Aerospace, Inc
1399 General Aviation Dr
Melbourne, Florida 32935 USA
sales@seaerospace.com
Tel: 321-255-9877
Fax: 321-255-9608
www.seaerospace.com

Metro Capabilities List

Part Number	Model	Description	Capability
065-0053-00	KAS-297A	Altitude Alerter	SEA Repair
066-03062-0002	KEA-346	Encoding Altimeter	SEA Repair
066-1063-00	KN-75	Glideslope Receiver	SEA Repair
066-3012-01	KA-35A	Marker Light Assembly	SEA Repair
066-3034-12	KI-206	VOR/GS Indicator	SEA Repair
066-3062-02	KEA-346	Encoding Altimeter	SEA Repair
066-3114-00	IN-812A	Radar Indicator	SEA Repair
066-4009-00	KN-72	VOR/LOC Converter	SEA Repair
071-1192-22	KFS-576	Transponder Control	SEA Repair
071-1210-17	KFS-586	ADF Control	SEA Repair
071-1215-31	KFS-598	Comm Control	SEA Repair
071-1216-26	KFS-564	Nav Control	SEA Repair
071-1276-22	KFS-576A	Transponder Control	SEA Repair
071-1282-31	KFS-598A	Comm Control	SEA Repair
071-1283-26	KFS-564A	Nav Control	SEA Repair
071-1284-17	KFS-586A	ADF Control	SEA Repair
071-1378-00	RS-811A	Radar Transceiver	SEA Repair
071-4037-01	KA-33	Cooling Fan	SEA Repair
101735-11807		Altimeter	SEA Exchange
2594484	FX-220	FLUX VALVE	SEA Repair
270-2436-040	613L-3	Transponder Control	SEA Repair
30-0467-5		Strobe Light	SEA Exchange
3137LB23C		RMI	SEA Exchange
4000523-8501	3013H	Servo	SEA Exchange
4000790-4406	DA-144A	Radar Antenna	SEA Repair
4000946-5201	IN-152A	Radar Indicator	SEA Repair
4000946-5202	IN-152A	Radar Indicator	SEA Repair
4001018-6102	ART-161A	Radar Transceiver	SEA Repair
4001018-6104	ART-161A	Radar Transceiver	SEA Repair
4001018-6106	ART-161A	Radar Transceiver	SEA Repair
4001018-6108	ART-161A	Radar Transceiver	SEA Repair
4002963-901	RH-445	RMI	SEA Repair
501-1170-05	AI-904P/B	Attitude Indicator	SEA Exchange
5035P-P22		Altimeter	SEA Repair
504-0002-913	500ECFL	Horizon Gyro	SEA Exchange
504-0002-918	500ECFB	Horizon Gyro	SEA Exchange
504-0006-913	300-14L	Horizon Gyro	SEA Exchange
504-0006-914	300-14	Horizon Gyro	SEA Exchange
504-0010-909	500DCF28	Horizon Gyro	SEA Exchange
504-0017-901	510-1A	Horizon Gyro	SEA Repair

Part Number	Model	Description	Capability
504-0017-908	510-1B	Horizon Gyro	SEA Repair
504-0017-909	510-8A	Horizon Gyro	SEA Repair
504-0017-916	510-8B	Horizon Gyro	SEA Repair
504-0017-921	510-8D	Horizon Gyro	SEA Repair
504-0021-901	500ECF-2	Horizon Gyro	SEA Exchange
504-0021-903	500ECFL-2K	Horizon Gyro	SEA Exchange
504-0030-911	510-24L	Horizon Gyro	SEA Exchange
505-0010-902	200DCL(28)	Horizon Gyro	SEA Exchange
507-0020-909		Turn & Bank Indicator	SEA Exchange
509-0001-904		Turn & Bank Indicator	SEA Exchange
519-22702-031	22702-031	Encoding Altimeter	SEA Exchange
519-28702-502	28702-502	Encoding Altimeter	SEA Exchange
519-28702-552	28702-552	Encoding Altimeter	SEA Exchange
520-3137-303	3137LB61C	RMI	SEA Exchange
520-3137-304	3137LB63C	RMI	SEA Exchange
522-2638-001	331A-3G	HSI	SEA Repair
522-2638-006	331A-3G	HSI	SEA Repair
522-2638-007	331A-3G	HSI	SEA Repair
522-2638-009	331A-3G	HSI	SEA Repair
522-2644-001	328A-3G	Slaving Accessory	SEA Repair
522-2644-011	328A-3G	Slaving Accessory	SEA Repair
522-3241-000	332E- 4	Directional Gyro	SEA Repair
522-4945-001	323A-2G	Flux Valve	SEA Repair
540-22722-004	22722-004	Altitude Alerter	SEA Exchange
540-22722-034	22722-034	Altitude Alerter	SEA Exchange
5934PA-1		Altimeter	SEA Repair
622-0555-003	332C-10	RMI	SEA Repair
622-0555-005	332C-10	RMI	SEA Repair
622-0876-001	VIR-30A	Nav Receiver	SEA Repair
622-0876-201	VIR-30A	Nav Receiver	SEA Repair
622-0877-001	VIR-30M	Nav Receiver	SEA Repair
622-1204-004	339H-4	Rad Alt Indicator	SEA Repair
622-1233-001	DME-40	DME	SEA Repair
622-1234-012	339F-12	DME Indicator	SEA Repair
622-1234-013	339F-12	DME Indicator	SEA Repair
622-1234-016	339F-12	DME Indicator	SEA Repair
622-1270-001	TDR-90	Transponder	SEA Repair
622-1352-002	FD-112V	Flight Director	SEA Exchange
622-1879-001	VHF-20A	VHF Comm	SEA Repair
622-1879-002	VHF-20A	VHF Comm	SEA Repair
622-2012-012	339F-12A	DME Indicator	SEA Repair
622-2362-001	ADF-60A	ADF Receiver	SEA Repair
622-2363-001	ANT-60A	ADF Antenna	SEA Repair
622-3102-001	MKL-351	Marker Lights	SEA Repair
622-3594-005	ADI-84A	Flight Director	SEA Exchange
622-4483-001	IND-31C	Course Indicator	SEA Repair

Part Number	Model	Description	Capability
622-4483-002	IND-31C	Course Indicator	SEA Repair
622-4565-001	332D-11T	Vertical Gyro	SEA Repair
622-4938-001	RMI-30	RMI	SEA Repair
622-4938-002	RMI-30	RMI	SEA Repair
622-6136-002	DGS-65	Directional Gyro	SEA Exchange
622-6137-001	VIR-32	Nav Receiver	SEA Repair
622-6137-201	VIR-32	Nav Receiver	SEA Repair
622-6152-001	VHF-22A	VHF Comm	SEA Repair
622-6152-002	VHF-22A	VHF Comm	SEA Repair
622-6263-001	DME-42	DME	SEA Repair
622-6389-001	VHF-21A	VHF Comm	SEA Repair
622-6389-002	VHF-21A	VHF Comm	SEA Repair
622-6390-001	VHF-21B	VHF Comm	SEA Repair
622-6390-002	VHF-21B	VHF Comm	SEA Repair
622-6520-008	CTL-22	Comm Control	SEA Repair
622-6521-016	CTL-32	Nav Control	SEA Repair
622-6522-008	CTL-62	ADF Control	SEA Repair
622-6523-008	CTL-92	Transponder Control	SEA Repair
622-6524-003	IND-42A	DME Indicator	SEA Repair
777-1493-006	614L-11	ADF Control	SEA Repair
792-6275-003	614L-13	ADF Control	SEA Repair
8095536-8101	RS-811A	Radar Sensor	SEA Repair
8095537-8101	IN-812A	Radar Indicator	SEA Repair
822-1113-001	VHF-22C	VHF Comm	SEA Repair
822-1113-021	VHF-22C	VHF Comm	SEA Repair
93A100-80		CVR	SEA Repair
965-0476-088	MK II	GPWS	SEA Exchange
980-6019-001		CVR	SEA Exchange
GA100A		CVR	SEA Repair
LT-103	LT-103	DC Converter	SEA Exchange
LT-3100-1	LT3100-1	Power Supply	SEA Exchange
M811B		Clock	SEA Exchange
M877		Clock	SEA Exchange
PC15BC		Static Inverter	SEA Repair
PC15H(F)	PC-15HF	Static Inverter	SEA Repair
PC250		Static Inverter	SEA Repair
PC350		Static Inverter	SEA Repair