

GARMIN™ WAAS Upgrade Part Number Conversion

400 Series

GPS-400W

<u>GPS-400 P/N:</u>		<u>Upgrade GPS-400W P/N:</u>
011-00504-00	→	011-01057-40
011-00504-10	→	011-01057-50

GNC-420W

<u>GNC-420 P/N:</u>		<u>Upgrade GNC-420W P/N:</u>
011-00506-00	→	011-01058-45
011-00506-10	→	011-01058-40
011-00506-30	→	011-01058-50

GNC-420AW

<u>GNC-420A P/N:</u>		<u>Upgrade GNC-420AW P/N:</u>
011-00837-00	→	011-01059-40
011-00837-10	→	011-01059-50

GNS-430W

<u>GNS-430 P/N:</u>		<u>Upgrade GNS-430W P/N:</u>
011-00280-00	→	011-01060-45
011-00280-10	→	011-01060-40
011-00280-30	→	011-01060-50

GNS-430AW

<u>GNS-430A P/N:</u>		<u>Upgrade GNS-430AW P/N:</u>
011-00836-00	→	011-01061-40
011-00836-10	→	011-01061-50

500 Series

GPS-500W

<u>GPS-500 P/N:</u>		<u>Upgrade GPS-500W P/N:</u>
011-00562-00	→	011-01062-40
011-00562-10	→	011-01062-50

GPS-500W w/TAWS

<u>GPS-500 P/N:</u>		<u>Upgrade GPS-500W P/N:</u>
011-00863-00	→	011-01063-40
011-00863-01	→	011-01063-40
011-00863-10	→	011-01063-50
011-00863-11	→	011-01063-50

GNS-530W

<u>GNS-530 P/N:</u>		<u>Upgrade GNS-530W P/N:</u>
011-00550-00	→	011-01064-45
011-00550-10	→	011-01064-40
011-00550-30	→	011-01064-50

GNS-530W w/TAWS

<u>GNS-530 P/N:</u>		<u>Upgrade GNS-530W P/N:</u>
011-00940-00	→	011-01065-40
011-00940-01	→	011-01065-40
011-00940-10	→	011-01065-50
011-00940-11	→	011-01065-50
011-00940-31	→	011-01065-45

GNS-530AW

<u>GNS-530A P/N:</u>		<u>Upgrade GNS-530AW P/N:</u>
011-00835-00	→	011-01066-40
011-00835-10	→	011-01066-50

GNS-530AW w/TAWS

<u>GNS-530A P/N:</u>		<u>Upgrade GNS-530AW P/N:</u>
011-00864-00	→	011-01067-40
011-00864-01	→	011-01067-40
011-00864-10	→	011-01067-50
011-00864-11	→	011-01067-50