



Southeast Aerospace, Inc
 1399 General Aviation Dr
 Melbourne, Florida 32935 USA
sales@seaerospace.com
 Tel: 321-255-9877
 Fax: 321-255-9608
www.seaerospace.com

Capabilities List (ALL)

Part Number	Model	NSN	Description	Manufacturer	Capability
010-00200-00	GPSMAP 295		Color Handheld GPS (Americas Database)	Garmin	OEM Dealer Repair
010-00200-01	GPSMAP 295		Color Handheld GPS (Atlantic Database)	Garmin	OEM Dealer Repair
010-00200-02	GPSMAP 295		GPS (Pacific Database)	Garmin	OEM Dealer Repair
010-00247-00	GTX-320A	5826-01-549-3357	Transponder	Garmin	SEA Repair
010-00247-02	GTX-320A System		Transponder	Garmin	SEA Repair
010-00296-00	GMU-44		Magnetometer (Shipping P/N)	Garmin	OEM Dealer Repair
010-00301-00	GPSMAP 196		Handheld GPS (Americas)	Garmin	OEM Dealer Repair
010-00301-01	GPSMAP 196	5826-01-594-5301	Handheld GPS (Atlantic)	Garmin	OEM Dealer Repair
010-00301-51	GPSMAP 196		Handheld GPS (Atlantic)	Garmin	OEM Dealer Repair
010-00356-00	GPSMAP 296	5826-01-535-3329	Handheld GPS (Americas Database)	Garmin	OEM Dealer Repair
010-00356-01	GPSMAP 296		Handheld GPS (Atlantic Database)	Garmin	OEM Dealer Repair
010-00356-02	GPSMAP 296		Handheld GPS (Pacific Database)	Garmin	OEM Dealer Repair
010-00356-51	GPSMAP 296	5826-01-535-3329	Handheld GPS (Atlantic Database)	Garmin	OEM Dealer Repair
010-00425-00	GPSMAP 396		Handheld GPS/Portable MFD	Garmin	OEM Dealer Repair
010-00573-02	GPSMAP 495		Portable Aviation GPS (Pacific)	Garmin	OEM Dealer Repair
010-00578-00	GPSMAP 496	5825-01-554-9032	Handheld GPS/MFD (Americas)	Garmin	OEM Dealer Repair
010-00667-60	GPSMAP 695		Portable GPS/EFB (Atlantic)	Garmin	OEM Dealer Repair
010-00667-70	GPSMAP 695		Portable GPS/EFB (Pacific)	Garmin	OEM Dealer Repair
010-00836-00	aera 500		Portable GPS - Americas	Garmin	OEM Dealer Repair
010-00836-20	aera 550	5825-01-594-5303	Portable GPS - Americas	Garmin	OEM Dealer Repair
010-00836-22	aera 550		Portable GPS - Pacific	Garmin	OEM Dealer Repair
010-00967-00	aera 795		Portable Aviation GPS - Americas	Garmin	OEM Dealer Repair
0102-1		5133-00-224-4029	Mode Selector	S-Tec	OEM Dealer Repair
0103-1		5331-01-359-8771	Programmer/Annunciator	S-Tec	OEM Dealer Repair
0104-1	60-2	5133-00-236-4028	AutoPilot Control	S-Tec	OEM Dealer Repair
0105-13R2			Roll Servo	S-Tec	OEM Dealer Repair
0105-8-T6			Roll Servo	S-Tec	OEM Dealer Repair
0105-R9			Roll Servo	S-Tec	OEM Dealer Repair
0105-T6			Trim Servo	Cobham	OEM Dealer Repair
0106-11-T6	010611T6		Trim Servo Assy	S-Tec	OEM Dealer Repair
0106-14-T6			Autopilot Servo	S-Tec	OEM Dealer Repair
0106-15-R1			Autopilot Servo	S-Tec	OEM Dealer Repair
0106-16-T9			Trim Servo	S-Tec	OEM Dealer Repair
0106-6-R9		6615-01-529-4598	Roll Servo	S-Tec	OEM Dealer Repair
0106-R2			Roll Servo	S-Tec	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
0106-T12		6615-01-529-4599	Pitch Servo	S-Tec	OEM Dealer Repair
0106-T3			Servo	S-Tec	OEM Dealer Repair
0106-T8			Trim Servo	S-Tec	OEM Dealer Repair
0106-T9			Servo	S-Tec	OEM Dealer Repair
0107-1-P2			Pitch Servo	S-Tec	OEM Dealer Repair
0107-P4			Pitch Servo	S-Tec	OEM Dealer Repair
0107-P5			Pitch Servo	S-Tec	OEM Dealer Repair
0108-1-P4			Servo	S-Tec	OEM Dealer Repair
0108-5-P9		6615-01-529-4597	Pitch Servo	S-Tec	OEM Dealer Repair
0108-P5			Pitch Servo		OEM Dealer Repair
0109		5120-00-024-9531	Roll Computer	S-Tec	OEM Dealer Repair
0109-1		5133-01-101-9780	RFGC	S-Tec	OEM Dealer Repair
0109-11		5310-12-164-7838	RFGC	S-Tec	OEM Dealer Repair
0109-3		5133-00-189-9289	Pitch Computer	S-Tec	OEM Dealer Repair
0109-4		5133-01-101-9779	RFGC	Cobham	OEM Dealer Repair
0109-5		8115-01-363-9574	Flight Guidance Computer	S-Tec	OEM Dealer Repair
010-N0152-11	GMA-340	5133-00-224-4029	Audio Panel (Garmin OHC)	Garmin	OEM Dealer Repair
010-N0161-00	GNC-300XL		Reconditioned GPS/Comm System	Garmin	SEA Repair
011-00054-00	GPS-150	5826-01-411-4612	VFR GPS w/o Moving Map	Garmin	SEA Repair
011-00082-00	GNC-250		GPS	Garmin	SEA Repair
011-00104-00	GPS-155	5826-01-601-3146	GPS Receiver	Garmin	SEA Repair
011-00106-00	GPS-165	5826-01-411-9927	DZUS Mount IFR GPS Receiver	Garmin	SEA Repair
011-00106-01	GPS-165		DZUS Mount IFR GPS Receiver	Garmin	SEA Repair
011-00128-00	GNC-300		IFR GPS/Comm	Garmin	SEA Repair
011-00134-00	GA-56	5985-01-379-7821	GPS Antenna w/o Hardware Kit	Garmin	SEA Repair
011-00259-00	GTX-320		Transponder	Garmin	SEA Repair
011-00259-10	GTX-320		Transponder	Garmin	SEA Repair
011-00280-00	GNS-430		GPS Nav/Comm (28V)	Garmin	SEA Repair
011-00280-10	GNS-430		GPS/Nav/Comm (14/28V)	Garmin	SEA Repair
011-00280-30	GNS-430		GPS/Nav/Comm (Gray 14/28V)	Garmin	SEA Repair
011-00295-00	GNC-250XL		VFR GPS/Comm	Garmin	SEA Repair
011-00345-00	GPS-150XL		GPS unit only	Garmin	SEA Repair
011-00401-00	GMA-340		Audio Panel	Garmin	OEM Dealer Repair
011-00401-01	GMA-340H		Audio Panel	Garmin	OEM Dealer Repair
011-00401-10	GMA-340		Audio Panel (unit only)	Garmin	OEM Dealer Repair
011-00401-20	GMA-340		Audio Panel w/ Dual ADF Input	Garmin	OEM Dealer Repair
011-00412-00	GPS-155XL		IFR GPS Receiver	Garmin	SEA Repair
011-00412-45	GNS-430		GPS NAV/COMM	Garmin	SEA Repair
011-00417-00	GAD-42	5895-01-534-0706	Interface Adapter (Unit Only)	Garmin	OEM Dealer Repair
011-00433-00	GNC-300XL		IFR GPS/Comm	Garmin	SEA Repair
011-00455-00	GTX-330	5895-01-532-1217	Mode S Datalink Transponder	Garmin	SEA Repair
011-00455-10	GTX-330D	5841-01-571-2660	Mode S Datalink Transponder	Garmin	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
011-00455-20	GTX-330		Mode S Datalink Transponder	Garmin	SEA Repair
011-00455-30	GTX-330D		Mode S Datalink Transponder	Garmin	SEA Repair
011-00455-60	GTX-330		Mode S Transponder w/ ES	Garmin	OEM Dealer Repair
011-00490-00	GTX-327		Digital Transponder	Garmin	SEA Repair
011-00504-00	GPS-400		Color GPS Receiver	Garmin	SEA Repair
011-00504-10	GPS-400		Color GPS Receiver	Garmin	SEA Repair
011-00506-00	GNC-420		Color GPS/Comm (28V)	Garmin	SEA Repair
011-00506-10	GNC-420		Color GPS/Comm	Garmin	SEA Repair
011-00506-30	GNC-420		Color GPS/Comm	Garmin	SEA Repair
011-00550-00	GNS-530		GPS/Nav/Comm (28V)	Garmin	SEA Repair
011-00550-10	GNS-530	5825-01-533-9943	GPS/Nav/Comm (14/28V)	Garmin	SEA Repair
011-00550-30	GNS-530		GPS/Nav/Comm	Garmin	SEA Repair
011-00562-00	GPS-500		Color IFR GPS Receiver	Garmin	SEA Repair
011-00728-00	GTX-320A		Transponder (unit only)	Garmin	SEA Repair
011-00729-00	GDL-49		Datalink Receiver	Garmin	OEM Dealer Repair
011-00779-10	GTX-33	5841-01-592-5940	Remote Mount Mode S Transponder	Garmin	SEA Repair
011-00781-01	GIA-63		Integrated Avionics Unit	Garmin	OEM Dealer Repair
011-00807-00	GMA-347		Audio Panel (Black Bezel)	Garmin	OEM Dealer Repair
011-00809-00	GMA-1347	1680-01-597-6873	Digital Audio Panel	Garmin	OEM Dealer Repair
011-00831-00	GEA-71	2995-01-597-6877	Engine/Airframe Unit	Garmin	OEM Dealer Repair
011-00831-05	GEA-71H		Engine/Airframe Unit	Garmin	OEM Dealer Repair
011-00835-00	GNS-530A		GPS/Nav/Comm	Garmin	SEA Repair
011-00835-10	GNS-530A		GPS/Nav/Comm	Garmin	SEA Repair
011-00836-00	GNS-430A		GPS/Nav/Comm	Garmin	SEA Repair
011-00836-10	GNS-430A		GPS Nav/Comm	Garmin	SEA Repair
011-00837-00	GNC-420A		Color GPS/Comm	Garmin	SEA Repair
011-00837-10	GNS-430A		Color GPS/Comm	Garmin	SEA Repair
011-00863-01	GPS-500 TAWS		GPS Receiver w/ TAWS	Garmin	OEM Dealer Repair
011-00864-00	GNS-530A		GPS/Nav/Comm (Black - 28V - 16W Comm)	Garmin	SEA Repair
011-00864-01	GNS-530A		GPS/Nav/Comm/TAWS (High Power)	Garmin	SEA Repair
011-00864-10	GNS-530A		GPS/Nav/Comm	Garmin	SEA Repair
011-00864-11	GNS-530A		GPS/Nav/Comm/TAWS (High Power)	Garmin	SEA Repair
011-00868-00	GRS-77	1680-01-597-6879	AHARS System (Unit P/N)	Garmin	OEM Dealer Repair
011-00868-10	GRS-77	6615-01-592-6194	AHARS System (Unit P/N)	Garmin	OEM Dealer Repair
011-00870-00	GMU-44	5340-00-102-1103	Magnetometer	Garmin	OEM Dealer Repair
011-00877-00	GSA-80	1680-01-597-6865	Yaw Servo	Garmin	OEM Dealer Repair
011-00878-00	GSA-81	6615-01-592-5986	Pitch/Trim Servo	Garmin	OEM Dealer Repair
011-00882-00	GDC-74A	1680-01-597-6880	HIRF Air Data Computer	Garmin	SEA Repair
011-00882-01	GDC-74A		Air Data Computer	Garmin	SEA Repair
011-00882-10	GDC-74A	6605-01-597-7633	HIRF Air Data System (Unit P/N)	Garmin	SEA Repair
011-00882-11	GDC-74H		HIRF Air Data Computer	Garmin	SEA Repair
011-00883-20	GWX-68		Weather Radar (12")	Garmin	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
011-00940-00	GNS-530		GPS/Nav/Comm/TAWS (14/28V)	Garmin	SEA Repair
011-00940-01	GNS-530 TAWS		GPS/Nav/Comm/TAWS	Garmin	SEA Repair
011-00940-10	GNS-530		GPS/Nav/Comm	Garmin	SEA Repair
011-00940-11	GNS-530		GPS/Nav/Comm/TAWS	Garmin	SEA Repair
011-00940-31	GNS-530	6610-01-571-2661	GPS/Nav/Comm/TAWS	Garmin	SEA Repair
011-00972-00	GDU-1040	6610-01-597-7175	Multi-Function Display	Garmin	OEM Dealer Repair
011-00972-03	GDU-1040		Multi-Function Display	Garmin	OEM Dealer Repair
011-00972-20	GDU-1040H		Multi-Function Display NVIS Upgrade	Garmin	OEM Dealer Repair
011-00986-00	GDL-69		Satellite Data Link Receiver	Garmin	OEM Dealer Repair
011-00987-00	GDL-69A	6099-01-597-7433	XM Weather/Audio Data Receiver	Garmin	OEM Dealer Repair
011-01057-00	GPS-400W	5820-01-645-5152	Color WAAS GPS Receiver	Garmin	SEA Repair
011-01057-10	GPS-400W		Color IFR WAAS GPS	Garmin	SEA Repair
011-01057-40	GPS-400W		Color WAAS GPS Receiver	Garmin	SEA Repair
011-01057-50	GPS-400W		Color IFR WAAS GPS	Garmin	SEA Repair
011-01058-00	GNC-420W		Color WAAS GPS w/Comm	Garmin	SEA Repair
011-01058-10	GNS-420W		Color WAAS GPS w/Comm	Garmin	SEA Repair
011-01058-40	GNC-420W		Color WAAS GPS w/Comm	Garmin	SEA Repair
011-01058-50	GNC-420W		Color WAAS GPS w/Comm	Garmin	SEA Repair
011-01059-00	GNC-420AW		WAAS GPS/Comm	Garmin	SEA Repair
011-01059-10	GNC-420AW		WAAS GPS/Comm	Garmin	SEA Repair
011-01059-40	GNC-420AW		WAAS GPS/Comm	Garmin	SEA Repair
011-01059-50	GNC-420AW		WAAS GPS/Comm	Garmin	SEA Repair
011-01060-00	GNS-430W	5826-01-563-3017	WAAS GPS/Nav/Comm (unit only)	Garmin	SEA Repair
011-01060-10	GNS-430W		WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01060-40	GNS-430W	5826-01-648-1292	WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01060-45	GNS-430W	5826-01-563-3017	Nav/Comm/WAAS GPS (28V)	Garmin	SEA Repair
011-01060-50	GNS-430W		WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01061-00	GNS-430AW		WAAS/GPS/VOR/ILS/COM	Garmin	SEA Repair
011-01061-10	GNS-430AW		WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01061-40	GNS-430AW		WAAS/GPS/VOR/ILS/COM	Garmin	SEA Repair
011-01061-50	GNS-430AW		WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01062-00	GPS-500W	5826-01-562-7986	WAAS GPS Receiver	Garmin	SEA Repair
011-01062-10	GPS-500W		WAAS GPS	Garmin	SEA Repair
011-01062-40	GPS-500W	5826-01-562-7986	WAAS GPS	Garmin	SEA Repair
011-01062-50	GPS-500W		WAAS GPS	Garmin	SEA Repair
011-01063-00	GPS-500W		WAAS GPS w/TAWS	Garmin	SEA Repair
011-01063-10	GPS-500W w/TAWS	5826-01-594-5306	WAAS GPS-w/TAWS	Garmin	SEA Repair
011-01063-40	GPS-500W-w/TAWS		WAAS GPS w/TAWS	Garmin	SEA Repair
011-01063-50	GPS-500W-w/TAWS		WAAS GPS w/TAWS	Garmin	SEA Repair
011-01064-00	GNS-530W		WAAS GPS/NAV/COMM	Garmin	SEA Repair
011-01064-40	GNS-530W		GPS/Nav/Comm w/ WAAS (14/28V)	Garmin	SEA Repair
011-01064-45	GNS-530W		WAAS GPS/Nav/Comm	Garmin	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
011-01064-50	GNS-530W		WAAS GPS/Nav/Comm	Garmin	OEM Dealer Repair
011-01065-00	GNS-530W-w/TAWS		GPS/Nav/Comm w/ TAWS	Garmin	SEA Repair
011-01065-10	GNS-530W-w/TAWS		WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01065-40	GNS-530W-w/TAWS		WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01065-45	GNS-530W-w/TAWS	6610-01-571-2661	WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01065-50	GNS-530W-w/TAWS		WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01066-00	GNS-530AW		WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01066-10	GNS-530AW		WAAS GPS/Nav/Comm	Garmin	SEA Repair
011-01066-40	GNS-530AW		WAAS GPS/Nav//Comm	Garmin	SEA Repair
011-01066-50	GNS-530AW		WAAS GPS//Nav/Comm	Garmin	SEA Repair
011-01067-00	GNS-530AW-w/TAWS		WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01067-10	GNS-530AW-w/TAWS		WAAS GPS//Nav/Comm w/TAWS	Garmin	SEA Repair
011-01067-40	GNS-530AW-w/TAWS		WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01067-50	GNS-530AW-w/TAWS		WAAS GPS/Nav/Comm w/TAWS	Garmin	SEA Repair
011-01105-00	GIA-63W	6615-01-597-7227	Intergrated Avionics Unit	Garmin	OEM Dealer Repair
011-01105-01	GIA-63W		Intregrated Avionics Unit	Garmin	OEM Dealer Repair
011-01105-20	GIA-63W	6610-01-597-1657	Intergrated Avionics Unit	Garmin	OEM Dealer Repair
011-01105-30	GIA-63H		Integrated Avionics Equipment	Garmin	OEM Dealer Repair
011-01110-01	GDC-74B	6610-01-593-2428	HIRF Air Data Computer	Garmin	OEM Dealer Repair
011-01264-60	GDU-620 (RH)		Display Unit	Garmin	OEM Dealer Repair
011-01271-00	GMX-200		Multi-Function Display (Black)	Garmin	OEM Dealer Repair
011-01274-00	GDU-1044B	7025-01-597-7543	Multi-Function Display	Garmin	OEM Dealer Repair
011-01465-00	GMX-200		MFD (Black) w/Traffic Interface	Garmin	OEM Dealer Repair
011-01466-00	GMX-200		MFD (Black) w/ Radar/TAWS	Garmin AT	OEM Dealer Repair
011-01467-00	GMX-200		MFD (Black) w/Traffic/Radar	Garmin	OEM Dealer Repair
011-01467-10	GMX-200		MFD (Gray) w/Radar/Traffic	Garmin	OEM Dealer Repair
0110-14TF4			Pitch Flight Guidance Computer	S-Tec	OEM Dealer Repair
011-01553-00	GTS-850		Traffic Sensor (TCAS I)	Garmin	OEM Dealer Repair
011-01684-00	GTX-328		Mode S Transponder	Garmin	OEM Dealer Repair
011-01817-00	GSU 73		ADAHRS Interface Unit	Garmin	OEM Dealer Repair
0110-18T			Pitch Flight Guidance Computer	S-Tec	OEM Dealer Repair
011-02256-00	GTN-650		WAAS GPS/Nav/Comm	Garmin	OEM Dealer Repair
0110-3T			Pitch Computer	S-Tec	OEM Dealer Repair
0110-3TF			PFGC	S-Tec	OEM Dealer Repair
0110-41			Autopilot Computer	S-Tec	OEM Dealer Repair
0110-4TF			PFGC	S-Tec	OEM Dealer Repair
0111		5310-00-010-2634	Absolute Pressure Transducer	S-Tec	OEM Dealer Repair
0141		6340-01-531-6979	SYS 65 Annun.	S-Tec	OEM Dealer Repair
01188-1P			Annuciator	S-Tec	OEM Dealer Repair
01192-0-11TF			Programmer/Computer	S-Tec	OEM Dealer Repair
01192-0-17T			Computer	S-Tec	OEM Dealer Repair
01192-0-25T			Programmer/Computer	S-Tec	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
01192-0-2TF			A/P Control Computer	S-Tec	OEM Dealer Repair
01192-0-38T	System 55		Auto Pilot Computer 28v	S-Tec	OEM Dealer Repair
01192-0-4T			Autopilot	S-Tec	OEM Dealer Repair
01192-0-51T			Programmer/Computer	S-Tec	OEM Dealer Repair
01192-0-5T			Programmer/Computer	S-Tec	OEM Dealer Repair
01192-11-14TF4	System 55X		R.F.G.C.	S-Tec	OEM Dealer Repair
01192-12-11	System 55X		Autopilot Computer	S-Tec	OEM Dealer Repair
01192-12-8			Indicator		OEM Dealer Repair
01192-13-26T2			Programmer/Computer Assembly-System	S-Tec	OEM Dealer Repair
01192-1-46T			Autopilot Computer	S-Tec	OEM Dealer Repair
01192-1-48TP			Autopilot Computer	S-Tec	OEM Dealer Repair
01192-27-72T			Programmer/Computer	S-Tec	OEM Dealer Repair
01192-28-50T			Programmer/Computer	S-Tec	OEM Dealer Repair
01192-28-50TP			Indicator		OEM Dealer Repair
01192-32-60TFPM	System 55X		Programmer/Computer	S-Tec	OEM Dealer Repair
01192-34-61T-30			Autopilot Indicator	Meggitt Avionics	OEM Dealer Repair
01192-4-4TF			Programmer/Computer		OEM Dealer Repair
01192-4-53-30P			Autopilot Computer	S-Tec	OEM Dealer Repair
01192-5-18			Programmer/Computer	S-Tec	OEM Dealer Repair
01192-5-20TF	System 55X		Autopilot Programmer/Computer	S-Tec	OEM Dealer Repair
01192-5-5TF			Autopilot Computer	S-Tec	OEM Dealer Repair
01192-6-45TF			Autopilot Computer	S-Tec	OEM Dealer Repair
01192-9-9T	Fifty Five X		Autopilot	S-Tec	OEM Dealer Repair
0121-2		5133-00-227-9659	Yaw Damper Amplifier	S-Tec	OEM Dealer Repair
0121-7		5133-00-262-2157	Yaw Damper	S-Tec	OEM Dealer Repair
01260-3-0-14	System 20		Turn Coordinator/Roll Comp	S-Tec	OEM Dealer Repair
01279-PX	ST-360	6615-01-529-3382	Altitude Preselector	S-Tec	OEM Dealer Repair
013-00048-01	GI-102A		VLOC/GPS Indicator	Garmin	SEA Repair
013-00049-01	GI-106A		VOR/LOC/GS/GPS Indicator	Garmin	SEA Repair
013-00049-11	GI-106A		CDI with Course Datum	Garmin	SEA Repair
013-00106-00	SL40		VHF Comm	Garmin AT	OEM Dealer Repair
013-00235-00	GA-35	5985-01-562-7124	WAAS GPS Antenna	Garmin	OEM Dealer Repair
01304-02-01-009			Auto Pilot Computer	S-Tec	OEM Dealer Repair
0131-0-3	System 50	5910-01-106-0604	Programmer/Computer	S-Tec	OEM Dealer Repair
01311-02-04			Flight Control Computer (w/Beep Trim)	Cobham	OEM Dealer Repair
013-1616-010	938K-1	5985-01-121-6315	UHF/VHF Antenna	Collins	OEM Dealer Repair
0132-25-36			System 50 Programmer Computer	S-Tec	OEM Dealer Repair
0132-25-6			System 50 Programmer Computer	S-Tec	OEM Dealer Repair
0141		6340-01-531-6979	SYS 65 Annun.	S-Tec	OEM Dealer Repair
0132-4-0		5930-01-557-5432	System 50 Programmer	Cobham	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
0142-2		5310-00-209-2354	System 65 Programmer	S-Tec	OEM Dealer Repair
0142-3		5306-00-637-5986	System 65 Programmer	S-Tec	OEM Dealer Repair
017500-111	SX-16	6220-01-045-2162	Searchlight Assembly	Boeing	OEM Dealer Repair
019059-110	SX-16		Gimbal Assy.	Spectrolab	OEM Dealer Repair
04077 Mod 1	04077 Mod 1		Air Data Computer	Computer Inst Corp	SEA Exchange
051240-3-7145NV-	TDFM-7145NV		Tactical Radio	Technisonic	OEM Dealer Repair
051240-3-	TDFM-7000		Tactical Radio	Technisonic	OEM Dealer Repair
0572.926-915	BXP6403-2-01		Mode S Transponder	Becker	OEM Dealer Repair
0586.870-954	CK5101-C		CK 5101-C Kit for REU 5100/6100	Becker	OEM Dealer Repair
0586.889-954	CK5102-C		CK 5102-C Kit for ACU 5100/6100	Becker	OEM Dealer Repair
0588.921-921	ACU6100-2-(130)		Audio Control Unit	Becker	OEM Dealer Repair
060-00040-0100	KRG-333		Multi-Axis Rate Gyro	BendixKing	OEM Dealer Repair
060-0013-01	KSG-105		Directional Gyro	BendixKing	SEA Repair
060-0015-00	KG-102A		Directional Gyro	BendixKing	SEA Repair
060-0016-00	Gyro Can		Dir Gyro Can	BendixKing	SEA Repair
060-0017-00	KI-256		Flight Command Indicator	BendixKing	SEA Repair
060-0017-01	KI-256		Flight Director Indicator	BendixKing	SEA Repair
060-0020-01	KG-258		Horizon Gyro (0 deg. tilt)	BendixKing	SEA Repair
060-0020-02	KG-258		Horizon Gyro (8 deg. tilt)	BendixKing	SEA Repair
060-0020-03	KG-258		Horizon Gyro	BendixKing	SEA Repair
060-0020-04	KG-258		Attitude Gyro	BendixKing	SEA Repair
060-0020-07	KG-258		Attitude Gyro (KAP150 - 0 deg)	BendixKing	SEA Repair
060-0020-08	KG-258		Horizon Gyro (KAP-150 - 8 deg)	BendixKing	SEA Repair
060-0020-09	KG-258		Horizon Gyro (KAP-100 - 0 deg)	BendixKing	SEA Repair
060-0024-00	KRG-331	6615-01-386-6321	Rate Gyro	BendixKing	OEM Dealer Repair
060-0026-00	KVG-350	6615-01-312-3040	Vertical Gyro	BendixKing	OEM Dealer Repair
060-0033-00	KRG-332	6615-01-312-3043	Rate Gyro	BendixKing	OEM Dealer Repair
0608.254-921	REU6100-2-110		Remote Electronic Unit for ACU6100-X	Becker	OEM Dealer Repair
0608.262-921	REU6100-3-(110)		Remote Electronic Unit	Becker	OEM Dealer Repair
0608.602-919			CSW6100-2 Configuration Set	Becker	OEM Dealer Repair
0631.604-915	BXP6403-2-12		Mode S Transponder	Becker	OEM Dealer Repair
063-1007-00	KTR-993		HF Transceiver	BendixKing	SEA Repair
064-01065-0100	KTR-909		UHF Transceiver	BendixKing	SEA Repair
064-01072-0101	KPA-1052	5996-01-555-4224	HF Power Amplifier	BendixKing	SEA Exchange
064-01073-0102	KRX-1053	5820-01-555-4227	HF Receiver/Exciter	BendixKing	SEA Exchange
064-01074-0101	KAC-1052	5985-01-555-4226	HF Antenna Coupler	BendixKing	SEA Exchange
064-01076-0101	KTR-909B		UHF Transceiver w/Guard	BendixKing	SEA Repair
064-01084-0101	KY-196B		8.33 VHF Comm	BendixKing	SEA Repair
064-01084-0201	KY-196B		8.33 VHF Comm (CNI5000)	BendixKing	SEA Repair
064-1009-00	KTR-905		VHF Comm	BendixKing	SEA Repair
064-1009-01	KTR-905E		VHF Comm R/T	BendixKing	SEA Repair
064-1009-02	KTR-905		VHF Comm	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
064-1009-03	KTR-905E		VHF Comm R/T	BendixKing	SEA Repair
064-1015-00	KTR-953		HF Receiver/Exciter	BendixKing	SEA Repair
064-1015-01	KTR-953		HF Receiver/Exciter	BendixKing	SEA Repair
064-1015-10	KTR-953		HF Receiver/Exciter	BendixKing	SEA Repair
064-1015-11	KTR-953		HF Receiver/Exciter	BendixKing	SEA Repair
064-1015-40	KTR-953		HF Receiver/Exciter	BendixKing	SEA Repair
064-1015-41	KTR-953		HF Receiver/ Exciter	BendixKing	SEA Repair
064-1015-51	KTR-953		Receiver/Exciter	BendixKing	SEA Repair
064-1015-53	KTR-953		HF Receiver/Excitier	BendixKing	SEA Repair
064-1016-00	KCU-951		HF Control	BendixKing	SEA Repair
064-1016-01	KCU-951		HF Control	BendixKing	SEA Repair
064-1016-02	KCU-951		HF Control	BendixKing	SEA Repair
064-1016-03	KCU-951		HF Control	BendixKing	SEA Repair
064-1016-04	KCU-951		HF Control	BendixKing	SEA Repair
064-1016-05	KCU-951		HF Control - NVG	BendixKing	OEM Dealer Repair
064-1017-00	KAC-952		HF Antenna Coupler	BendixKing	SEA Repair
064-1017-01	KAC-952		HF Antenna Coupler	BendixKing	SEA Repair
064-1017-02	KAC-952		HF Antenna Coupler	BendixKing	SEA Repair
064-1019-00	KY-196		Panel Mount VHF Comm Transceiver	BendixKing	SEA Repair
064-1019-01	KY-196E		VHF Comm	BendixKing	SEA Repair
064-1019-02	KY-196		VHF Comm	BendixKing	SEA Repair
064-1019-05	KY-196		VHF Comm (9 Mem Chan / 118-135 MHz)	BendixKing	SEA Repair
064-1019-06	KY-196E		VHF Comm	BendixKing	SEA Repair
064-1019-07	KY-196		VHF Comm	BendixKing	SEA Repair
064-1019-10	KY-196		VHF Comm	BendixKing	SEA Repair
064-1019-11	KY-196E		VHF Comm	BendixKing	SEA Repair
064-1019-12	KY-196		VHF Comm	BendixKing	SEA Repair
064-1019-20	KY-196		VHF Comm (9 Mem Chan / 118-136 MHz)	BendixKing	SEA Repair
064-1021-00	KY-197		VHF Comm (14V)	BendixKing	SEA Repair
064-1021-01	KY-197E		VHF Comm	BendixKing	SEA Repair
064-1021-05	KY-197		VHF Comm	BendixKing	SEA Repair
064-1021-10	KY-197		VHF Comm	BendixKing	SEA Repair
064-1021-11	KY-197E		VHF Comm	BendixKing	SEA Repair
064-1021-20	KY-197		VHF Comm	BendixKing	SEA Repair
064-1023-00	KTR-908		VHF Comm Transceiver	BendixKing	SEA Repair
064-1023-01	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-02	KTR-908		VHF Comm Transceiver (Ext. Range)	BendixKing	SEA Repair
064-1023-03	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-04	KTR-908		VHF Comm (136 - SELCAL/DF)	BendixKing	SEA Repair
064-1023-05	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-06	KTR-908		VHF Comm (151 - SELCAL/DF)	BendixKing	SEA Repair
064-1023-07	KTR-908		VHF Comm	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
064-1023-08	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-09	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-10	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-11	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-12	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-13	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-14	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1023-15	KTR-908		VHF Comm	BendixKing	SEA Repair
064-1029-00	KAC-992		HF Probe Antenna Coupler	BendixKing	SEA Repair
064-1029-01	KAC-992		Antenna Coupler	BendixKing	SEA Repair
064-1029-10	KAC-992		HF Antenna Coupler	BendixKing	SEA Repair
064-1051-60	KY-97A		VHF Comm	BendixKing	SEA Repair
064-1051-70	KY-97A		VHF Comm Transceiver	BendixKing	SEA Repair
064-1052-60	KY-96A		VHF Comm	BendixKing	SEA Repair
064-1052-70	KY-96A		VHF Comm Transceiver	BendixKing	SEA Repair
064-1053-30	KY-197A		VHF Comm	BendixKing	SEA Repair
064-1053-31	KY-197A		VHF Comm	BendixKing	SEA Repair
064-1053-32	KY-197A		VHF COMM	BendixKing	SEA Repair
064-1053-60	KY-197A		VHF Comm (SC+)	BendixKing	SEA Repair
064-1054-30	KY-196A		VHF Comm	BendixKing	SEA Repair
064-1054-31	KY-196A		VHF Comm	BendixKing	SEA Repair
064-1054-32	KY-196A		VHF Comm	BendixKing	SEA Repair
064-1054-50	KY-196A		VHF Comm (CNI5000)	BendixKing	SEA Repair
064-1054-60	KY-196A		VHF Comm Transceiver (SC+)	BendixKing	SEA Repair
065-0014-10	KSA-275		Servo Actuator	BendixKing	SEA Exchange
065-0014-14	KSA-370		Servo Actuator	BendixKing	OEM Dealer Repair
065-0014-15	KSA-370		Servo Actuator	BendixKing	OEM Dealer Repair
065-0015-23	KSM-375		Servo Mount	BendixKing	OEM Dealer Repair
065-00158-0102	KCP-520		Flight Computer	BendixKing	OEM Dealer Repair
065-00158-0211	KCP-520		Autopilot Computer	BendixKing	OEM Dealer Repair
065-00158-0502	KCP-520		Autopilot Computer	BendixKing	SEA Exchange
065-0016-01	KDC-380		Air Data Computer	BendixKing	OEM Dealer Repair
065-00167-0100	KSM-575		Actuator Assembly	BendixKing	OEM Dealer Repair
065-00167-0500	KSM-575		Yaw Linear Actuator	BendixKing	OEM Dealer Repair
065-0017-01	KMC-340		Autopilot Mode Controller	BendixKing	SEA Exchange
065-00176-2603	KC-140		Flight Control Computer	BendixKing	OEM Dealer Repair
065-00176-5402	KC-140		Flight Computer	BendixKing	OEM Dealer Repair
065-00176-5403	KC-140		Flight Computer	BendixKing	OEM Dealer Repair
065-00176-7702	KC-140		Flight Control Computer	BendixKing	OEM Dealer Repair
065-00176-7703	KC-140		Autopilot Computer	BendixKing	OEM Dealer Repair
065-00176-7904	KC-140	6615-01-597-7228	Flight Control Computer	BendixKing	SEA Exchange
065-00178-0100	KS-270C		Servo	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-00178-2100	KS-270C		Pitch Servo	BendixKing	SEA Repair
065-00178-2200	KS-270C		Pitch Servo	BendixKing	OEM Dealer Repair
065-00178-2200	KS-270C		Pitch Servo	BendixKing	SEA Repair
065-00178-2500	KS-270C		Pitch Servo	BendixKing	SEA Repair
065-00179-0100	KS-271C		Primary Servo	BendixKing	SEA Repair
065-00179-0200	KS-271C		Primary Servo	BendixKing	SEA Repair
065-00179-0300	KS-271C		Roll Servo	BendixKing	SEA Repair
065-00179-0500	KS-271C		Pitch Servo	BendixKing	SEA Repair
065-00179-0600	KS-271C		Roll/Yaw Servo	BendixKing	SEA Repair
065-00180-0400	KS-272C		Trim Servo	BendixKing	SEA Repair
065-00180-0600	KS-272C		Trim Servo	BendixKing	SEA Repair
065-00180-0800	KS-272C		Trim Servo	BendixKing	SEA Repair
065-00180-1400	KS-272C		Trim Servo	BendixKing	SEA Repair
065-00180-2700	KS-272C		Trim Servo	BendixKing	SEA Repair
065-0018-03	KCP-320		Flight Computer	BendixKing	OEM Dealer Repair
065-0018-04	KCP-320		Flight Computer	BendixKing	OEM Dealer Repair
065-00183-0301	KC-225		Autopilot Computer	BendixKing	OEM Dealer Repair
065-00183-0501	KC-225		Flight Computer	BendixKing	SEA Exchange
065-00183-2901	KC-225		Autopilot Computer	BendixKing	SEA Exchange
065-00184-0100	KA-285A		Autopilot Annunciator (KFC-225)	BendixKing	OEM Dealer Repair
065-0019-00	KAC-325		Autopilot Computer	BendixKing	SEA Exchange
065-0019-03	KAC-325		Autopilot Computer	BendixKing	OEM Dealer Repair
065-0019-04	KAC-325		Autopilot Computer	BendixKing	OEM Dealer Repair
065-0024-09	KSA-371		Servo	BendixKing	OEM Dealer Repair
065-0027-01	KS-270		Primary Servo	BendixKing	SEA Repair
065-0027-02	KS-270		Servo	BendixKing	SEA Repair
065-0027-03	KS-270		Primary Servo	BendixKing	SEA Repair
065-0027-04	KS-270		Servo	BendixKing	SEA Repair
065-0027-05	KS-270		Servo	BendixKing	SEA Repair
065-0027-06	KS-270		Servo	BendixKing	SEA Repair
065-0028-00	KS-271		Roll/Yaw Servo	BendixKing	SEA Repair
065-0028-01	KS-271		Roll Servo	BendixKing	SEA Repair
065-0028-02	KS-271		Servo	BendixKing	SEA Repair
065-0028-03	KS-271		Servo	BendixKing	SEA Repair
065-0028-04	KS-271		Servo	BendixKing	SEA Repair
065-0028-05	KS-271		Servo	BendixKing	SEA Repair
065-0029-00	KS-272		Trim Servo	BendixKing	SEA Repair
065-0029-01	KS-272		Servo	BendixKing	SEA Repair
065-0029-02	KS-272		Servo	BendixKing	SEA Repair
065-0029-03	KS-272		Servo	BendixKing	SEA Repair
065-0029-04	KS-272		Servo	BendixKing	SEA Repair
065-0029-05	KS-272		Trim Servo	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-0029-06	KS-272		Servo	BendixKing	SEA Repair
065-0029-07	KS-272		Servo	BendixKing	SEA Repair
065-0029-08	KS-272		Servo	BendixKing	SEA Repair
065-0029-09	KS-272		Servo	BendixKing	SEA Repair
065-0029-10	KS-272		Servo	BendixKing	SEA Repair
065-0029-11	KS-272		Servo	BendixKing	SEA Repair
065-0029-12	KS-272		Servo	BendixKing	SEA Repair
065-0029-13	KS-272		Servo	BendixKing	SEA Repair
065-0029-14	KS-272		Servo	BendixKing	SEA Repair
065-0029-15	KS-272		Servo	BendixKing	SEA Repair
065-0029-16	KS-272		Servo	BendixKing	SEA Repair
065-0029-17	KS-272		Servo	BendixKing	SEA Repair
065-0029-18	KS-272		Servo	BendixKing	SEA Repair
065-0029-19	KS-272		Servo	BendixKing	SEA Repair
065-0029-21	KS-272		Servo	BendixKing	SEA Repair
065-0029-22	KS-272		Trim Servo	BendixKing	SEA Repair
065-0029-24	KS-272		Servo	BendixKing	SEA Repair
065-0029-25	KS-272		Servo	BendixKing	SEA Repair
065-0029-26	KS-272		Servo	BendixKing	SEA Repair
065-0029-27	KS-272		Servo	BendixKing	SEA Repair
065-0029-28	KS-272		Servo	BendixKing	SEA Repair
065-0029-29	KS-272		Servo	BendixKing	SEA Repair
065-0029-30	KS-272		Servo	BendixKing	SEA Repair
065-0029-31	KS-272		Servo	BendixKing	SEA Repair
065-0029-32	KS-272		Servo	BendixKing	SEA Repair
065-0029-33	KS-272		Servo	BendixKing	SEA Repair
065-0029-34	KS-272		Servo	BendixKing	SEA Repair
065-0029-35	KS-272		Servo	BendixKing	SEA Repair
065-0029-36	KS-272		Servo	BendixKing	SEA Repair
065-0029-37	KS-272		Servo	BendixKing	SEA Repair
065-0029-38	KS-272		Servo	BendixKing	SEA Repair
065-0029-39	KS-272		Servo	BendixKing	SEA Repair
065-0029-40	KS-272		Servo	BendixKing	SEA Repair
065-0030-00	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-02	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-20	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-27	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-35	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-36	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-43	KM-275		Servo Mount	BendixKing	SEA Repair
065-0030-60	KM-275H		Servo Mount	BendixKing	SEA Repair
065-0031-21	KM-276		Servo Mount	BendixKing	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-0032-00	KA-285		Autopilot Annunciator	BendixKing	SEA Repair
065-0032-01	KA-285		Annuciator Panel	BendixKing	SEA Repair
065-0033-00	KC-290		Autopilot Mode Controller	BendixKing	SEA Repair
065-0033-01	KC-290		Mode Controller	BendixKing	SEA Repair
065-0034-00	KC-295		Autopilot Computer	BendixKing	SEA Repair
065-0034-01	KC-295		Flight Guidance Computer	BendixKing	SEA Repair
065-0034-02	KC-295		Flight Computer	BendixKing	OEM Dealer Repair
065-0034-03	KC-295		Flight Computer	BendixKing	SEA Repair
065-0034-05	KC-295		Autopilot computer	BendixKing	SEA Repair
065-0034-06	KC-295		Computer	BendixKing	SEA Repair
065-0034-09	KC-295		Flight Computer	BendixKing	SEA Repair
065-0034-10	KC-295		Autopilot Computer	BendixKing	SEA Repair
065-0034-13	KC-295		Autopilot Computer	BendixKing	SEA Repair
065-0034-14	KC-295		Flight Guidance Computer	BendixKing	SEA Repair
065-0034-15	KC-295		Flight Computer	BendixKing	SEA Repair
065-0034-16	KC-295		Flight Computer	BendixKing	SEA Repair
065-0035-01	KC-291		Yaw Controller	BendixKing	SEA Repair
065-0036-00	KC-296		Yaw Computer	BendixKing	SEA Repair
065-0036-01	KC-296		Yaw Computer	BendixKing	SEA Repair
065-0036-30	KC-296		Yaw Computer	BendixKing	SEA Repair
065-0036-31	KC-296		Yaw Computer	BendixKing	SEA Repair
065-0037-00	KC-292		Mode Controller	BendixKing	OEM Dealer Repair
065-0039-03	KSA-373		Trim Servo	BendixKing	OEM Dealer Repair
065-0039-04	KSA-373		Trim Servo	BendixKing	OEM Dealer Repair
065-0042-00	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-01	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-02	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-03	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-04	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-05	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-06	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-07	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-09	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-12	KC-192		Autopilot Computer	BendixKing	SEA Repair
065-0042-15	KC-192		Autopilot Computer	BendixKing	SEA Exchange
065-0044-02	KDC-298		Air Data Computer	BendixKing	OEM Dealer Repair
065-0045-01	KCP-299		Flight Computer	BendixKing	OEM Dealer Repair
065-0045-06	KCP-299		Flight Computer	BendixKing	OEM Dealer Repair
065-0046-00	KAS-297		Altitude Selector	BendixKing	SEA Repair
065-0046-02	KAS-297		Altitude Preselector	BendixKing	SEA Repair
065-0050-01	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-02	KS-177		Pitch Servo	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-0050-04	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-06	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-07	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-09	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-11	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-12	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0050-60	KS-177		Pitch Servo	BendixKing	SEA Repair
065-0051-01	KS-178		Roll Servo	BendixKing	SEA Repair
065-0051-02	KS-178		Roll Servo	BendixKing	SEA Repair
065-0051-04	KS-178		Roll Servo	BendixKing	SEA Repair
065-0051-06	KS-178		Roll Servo	BendixKing	SEA Repair
065-0051-07	KS-178		Roll Servo	BendixKing	SEA Repair
065-0051-08	KS-178		Roll Servo	BendixKing	SEA Repair
065-0052-04	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-06	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-07	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-10	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-13	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-14	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-15	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-16	KS-179		Trim Servo	BendixKing	SEA Repair
065-0052-17	KS-179		Trim Servo	BendixKing	SEA Repair
065-0053-00	KAS-297A		Altitude Preselector (KFC-300)	BendixKing	SEA Repair
065-0053-01	KAS-297A		Altitude Preselector	BendixKing	SEA Repair
065-0053-02	KAS-297A		Altitude Preselector (KFC-300)	BendixKing	SEA Repair
065-0053-03	KAS-297A		Altitude Selector	BendixKing	SEA Repair
065-0053-04	KAS-297A		Altitude Selector	BendixKing	SEA Repair
065-0053-08	KAS-297A		Altitude Preselector	BendixKing	SEA Repair
065-0054-00	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-01	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-02	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-03	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-04	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-05	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-06	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-07	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-09	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-12	KC-191		Autopilot Computer	BendixKing	SEA Repair
065-0054-15	KC-191		Autopilot Computer	BendixKing	OEM Dealer Repair
065-0055-00	KC-190		Autopilot Computer	BendixKing	SEA Repair
065-0055-02	KC-190		Autopilot Computer	BendixKing	SEA Repair
065-0056-01	KSA-372		Servo Actuator C90	BendixKing	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-0056-50	KSA-372		Servo Actuator	BendixKing	SEA Exchange
065-0056-57	KSA-372		Servo Actuator	BendixKing	OEM Dealer Repair
065-0056-71	KSA-372X		Servo Actuator (High Torque)	BendixKing	OEM Dealer Repair
065-0057-00	KSA-374		Servo	BendixKing	OEM Dealer Repair
065-0057-10	KSA-374		Servo	BendixKing	OEM Dealer Repair
065-0058-01	KA-185		Annunciator	BendixKing	SEA Repair
065-0058-03	KA-185		Annunciator	BendixKing	SEA Repair
065-0059-01	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-02	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-03	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-04	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-05	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-06	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-08	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0059-23	KS-270A		Pitch Servo	BendixKing	SEA Repair
065-0060-00	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-01	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-02	KS-271A		Servo	BendixKing	SEA Repair
065-0060-03	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-04	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-05	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-09	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-30	KS-271A		Servo	BendixKing	SEA Repair
065-0060-61	KS-271A		Roll/Yaw Servo	BendixKing	SEA Repair
065-0060-62	KS-271A		Pitch Servo	BendixKing	SEA Repair
065-0060-63	KS-271A		Pitch Servo	BendixKing	SEA Repair
065-0061-00	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-01	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-02	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-03	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-04	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-05	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-06	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-07	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-08	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-09	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-10	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-11	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-12	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-13	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-14	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-15	KS-272A		Trim Servo	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-0061-16	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-17	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-18	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-19	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-21	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-22	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-24	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-25	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-26	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-27	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-28	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-29	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-30	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-31	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-32	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-33	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-34	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-35	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-36	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-37	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-38	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-39	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-40	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-41	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-42	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-44	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0061-50	KS-272A		Trim Servo	BendixKing	SEA Repair
065-0062-00	KMC-221		Mode Controller	BendixKing	OEM Dealer Repair
065-0063-00	KAP-315A		Annunciator (Black Bezel)	BendixKing	OEM Dealer Repair
065-0064-01	KCP-220		Autopilot Computer	BendixKing	SEA Exchange
065-0064-07	KCP-220		Autopilot Computer	BendixKing	OEM Dealer Repair
065-0064-08	KCP-220		Flight Computer	BendixKing	OEM Dealer Repair
065-0064-09	KCP-220		Autopilot Computer	BendixKing	OEM Dealer Repair
065-0064-15	KCP-220		Flight Computer	BendixKing	SEA Exchange
065-0065-00	KAS-297B		Altitude/VSI Selector (KAP/KFC-150)	BendixKing	OEM Dealer Repair
065-0065-01	KAS-297B		Altitude/VSI Selector (KAP/KFC-150)	BendixKing	SEA Repair
065-0069-03	KCP-420		Flight Computer (Merlin IVC)	BendixKing	OEM Dealer Repair
065-0069-07	KCP-420		Flight Computer (King Air 200)	BendixKing	SEA Exchange
065-0069-13	KCP-420		Flight Computer (King Air 350)	BendixKing	OEM Dealer Repair
065-0069-17	KCP-420		Flight Computer (Lear 31A)	BendixKing	SEA Exchange
065-0070-38	KMC-440		Mode Controller	BendixKing	OEM Dealer Repair
065-0073-22	KMS-446		Mode Selector	BendixKing	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
065-0073-24	KMS-446		Mode Selector	BendixKing	OEM Dealer Repair
065-0076-11	KSA-470		Servo Actuator	BendixKing	OEM Dealer Repair
065-0079-12	KSM-475		Servo Mount	BendixKing	SEA Exchange
065-0079-13	KSM-475		Servo Mount	BendixKing	SEA Exchange
065-0082-01	KDC-481		Air Data Computer	BendixKing	SEA Exchange
065-0082-04	KDC-481		Air Data Computer	BendixKing	OEM Dealer Repair
065-0082-10	KDC-481		Air Data Computer	BendixKing	OEM Dealer Repair
065-0085-10	KDC-222		Air Data Computer	BendixKing	SEA Exchange
065-0086-00	KMC-321		Mode Controller	BendixKing	OEM Dealer Repair
065-0086-08	KMC-321		Mode Controller	BendixKing	SEA Exchange
065-0086-12	KMC-321		Mode Controller	BendixKing	OEM Dealer Repair
065-0089-04	KAS-297C		Altitude Preselector	BendixKing	SEA Repair
065-0089-05	KAS-297C		Altitude Preselector	BendixKing	OEM Dealer Repair
065-0089-12	KAS-297C		Altitude Preselector	BendixKing	OEM Dealer Repair
065-0089-16	KAS-297C		Altitude Preselector	BendixKing	OEM Dealer Repair
065-0089-16	KAS-297C		Altitude Preselector	BendixKing	SEA Repair
065-0091-01	KAM-432		Autopilot Monitor	BendixKing	SEA Exchange
065-0091-03	KAM-432		Autopilot Monitor	BendixKing	OEM Dealer Repair
065-0091-04	KAM-432		Autopilot Monitor	BendixKing	OEM Dealer Repair
065-0144-01	KC-193		Autopilot Computer	BendixKing	OEM Dealer Repair
065-0155-56	KSA-372T		Servo Actuator	BendixKing	OEM Dealer Repair
065-5009-22	KC-295		Circuit Card	BendixKing	SEA Repair
065-5013-00	KA-136		Trim Monitor	BendixKing	SEA Exchange
065-5013-02	KA-136		Trim Monitor	BendixKing	OEM Dealer Repair
065-5018-01	KA-141		Autopilot Monitor	BendixKing	OEM Dealer Repair
065-5025-27	KC-19X		Adapter Module	BendixKing	OEM Dealer Repair
065-5026-14			Adapter Module	BendixKing	OEM Dealer Repair
065-5030-01	KDA-430		Gyro/429 Adapter	BendixKing	OEM Dealer Repair
065-5040-01	KA-152		Accelerometer	BendixKing	OEM Dealer Repair
066-01127-1301	TRA-67A		Transponder	Honeywell	OEM Dealer Repair
066-01127-1402	TRA-67A		Enhanced Mode S Transponder - Airbus	Honeywell	OEM Dealer Repair
066-01130-0501	KN-40		Nav Converter	BendixKing	SEA Exchange
066-01130-0701	KN-40		Dual VOR Composite Converter	BendixKing	SEA Exchange
066-01130-0801	KN-40		Dual VOR Composite Converter	BendixKing	SEA Exchange
066-01141-0101	KT-70		Mode S Transponder	BendixKing	SEA Repair
066-01141-0201	KT-70		Mode S Transponder (SC Plus)	BendixKing	SEA Repair
066-01141-1101	KT-70		Mode S Transponder (CNI5000)	BendixKing	SEA Repair
066-01141-5101	KT-71		Digital Transponder	BendixKing	SEA Repair
066-01141-5201	KT-71		Digital Transponder	BendixKing	SEA Repair
066-01141-6101	KT-71		Digital Transponder (CNI5000)	BendixKing	SEA Repair
066-01143-0201	MST-67A		Mode S Transponder (Non-Diversity)	BendixKing	SEA Repair
066-01143-0301	MST-67A		Mode S Transponder	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-01143-0601	MST-67A		Mode S Transponder	BendixKing	SEA Repair
066-01143-1301	MST-67A		Mode S Transponder	BendixKing	SEA Repair
066-01143-1602	MST-67A		Mode S Transponder	BendixKing	SEA Repair
066-01143-2001	MST-67A		Mode S Transponder	BendixKing	SEA Repair
066-01143-2101	MST-67A		Enhanced Mode S Transponder	BendixKing	SEA Repair
066-01145-0101	TPU-66A		TCAS I Processor	BendixKing	OEM Dealer Repair
066-01146-0201	TPU-67A		TCAS II Processor	BendixKing	OEM Dealer Repair
066-01146-1111	TPU-67A		TCAS II Processor	BendixKing	SEA Exchange
066-01146-1211	TPU-67A		TCAS II Processor	BendixKing	OEM Dealer Repair
066-01146-2221	TPU-67B		TCAS Processor (Change 7.1)	BendixKing	OEM Dealer Repair
066-01148-0101	KLN-89B		IFR GPS Receiver	BendixKing	SEA Repair
066-01148-0102	KLN-89B		IFR GPS Receiver	BendixKing	SEA Repair
066-01151-0101	KLN-35A		VFR GPS Receiver	BendixKing	SEA Repair
066-01151-0102	KLN-35A		VFR GPS Receiver	BendixKing	SEA Repair
066-01151-0103	KLN-35A		VFR GPS Receiver	BendixKing	SEA Repair
066-01152-0101	KTA-810		Traffic Awareness Unit	BendixKing	SEA Exchange
066-01153-0101	KRA-405B		Radio Altimeter R/T	BendixKing	SEA Repair
066-01153-0202	KRA-405B		Radar Altimeter R/T w/ DH output	BendixKing	SEA Repair
066-01153-2001	KRA-405B		Radio Altimeter R/T w/ Enh. Accuracy	BendixKing	SEA Repair
066-01156-0101	KT-76C		Digital Transponder	BendixKing	SEA Repair
066-01156-0201	KT-76C		Digital Transponder	BendixKing	SEA Exchange
066-01164-0101	KT-73		Mode S Transponder	BendixKing	SEA Repair
066-01171-0901	IVA-81D		TCAS Indicator	BendixKing	OEM Dealer Repair
066-01171-0903	IVA-81D		TCAS Indicator (VS meters/sec)	BendixKing	OEM Dealer Repair
066-01171-0904	IVA-81D		TCAS Indicator	BendixKing	OEM Dealer Repair
066-01171-1001	IVA-81D		TCAS Indicator	BendixKing	SEA Exchange
066-01171-1704	IVA-81D		TCAS Indicator	BendixKing	SEA Exchange
066-01171-1804	IVA-81D		TCAS Indicator	BendixKing	OEM Dealer Repair
066-01171-2304	IVA-81D		TCAS Indicator (Black 28V/28V)	BendixKing	OEM Dealer Repair
066-01171-2704	IVA-81D	6610-01-606-8788	TCAS Indicator (28V/5V- Black)	BendixKing	SEA Exchange
066-01171-2804	IVA-81D	5840-01-582-0819	TCAS Indicator (28V/5V- Gray)	BendixKing	SEA Exchange
066-01171-3104	IVA-81D		TCAS Indicator (28V/28V)	BendixKing	SEA Exchange
066-01171-3404	IVA-81D		TCAS Indicator	BendixKing	SEA Exchange
066-01171-3706	IVA-81D		TCAS Indicator (Military NVG Capable)	BendixKing	OEM Dealer Repair
066-01174-0101	KMD-150		MFD w/ VFR GPS	BendixKing	OEM Dealer Repair
066-01175-2101	KMH-820		Multi-Hazard Awareness Unit	BendixKing	SEA Exchange
066-01175-2102	KMH-820		Multi-Hazard Awareness Unit	BendixKing	SEA Exchange
066-01176-0101	KMA-28		Audio Panel	BendixKing	OEM Dealer Repair
066-01177-0101	KTA-910	6615-01-593-1670	Traffic Awareness Unit	BendixKing	SEA Exchange
066-01178-2101	KMH-920		Multi Hazard Awareness Unit	BendixKing	OEM Dealer Repair
066-01178-2102	KMH-920		Multi-Hazard Sensor Unit	BendixKing	SEA Exchange
066-01179-0101	KI-825		Electronic HSI w/ Black Bezel	BendixKing	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-01179-0103	KI-825	5826-01-504-9312	Electronic HSI	BendixKing	SEA Exchange
066-01179-0104	KI-825		Electronic HSI (Black - WAAS)	BendixKing	SEA Exchange
066-01179-0201	KI-825		Electronic HSI w/ Gray Bezel	BendixKing	OEM Dealer Repair
066-01179-0303	KI-825		Electronic HSI NVIS	BendixKing	OEM Dealer Repair
066-01196-0101	KGP-560		EGPWS	BendixKing	OEM Dealer Repair
066-01196-0203	KGP-560		EGPWS	BendixKing	OEM Dealer Repair
066-01196-0205	KGP-560		965-1198-005 EGPWS Computer	BendixKing	SEA Exchange
066-01197-0205	KGP-860		965-1199-005 EGPWS Computer	BendixKing	SEA Exchange
066-01202-0101	KDU-1080		Display Unit (Primus Apex)	BendixKing	SEA Exchange
066-01227-0101	MKXXI		EGPWS w/ Internal GPS Class B	BendixKing	OEM Dealer Repair
066-01227-0205	MKXXI		965-1227-005 EGPWS (Class B)	BendixKing	OEM Dealer Repair
066-03062-0000	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0001	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0002	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0003	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0008	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0009	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0010	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03062-0011	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-03064-0005	KEA-130A		Encoding Altimeter	BendixKing	SEA Repair
066-03123-0600	ED-461		Electronic Display	BendixKing	OEM Dealer Repair
066-03123-1600	ED-461		EFIS Display	BendixKing	SEA Exchange
066-03125-0600	ED-462		Electronic Display	BendixKing	OEM Dealer Repair
066-03125-1600	ED-462		Electronic Display	BendixKing	OEM Dealer Repair
066-03125-2500	ED-462		EFIS Display	BendixKing	SEA Exchange
066-03125-2600	ED-462		EFIS Display	BendixKing	SEA Exchange
066-03137-3100	ED-551A		EFIS Display	BendixKing	SEA Exchange
066-03137-3200	ED-551A		EFIS Display	BendixKing	SEA Exchange
066-03137-3300	ED-551A		EFIS Display	BendixKing	SEA Exchange
066-04021-0403	SG-465		Symbol Generator	BendixKing	OEM Dealer Repair
066-04021-1107	SG-465		Symbol Generator	BendixKing	OEM Dealer Repair
066-04021-1111	SG-465	6625-01-505-4311	EFIS Symbol Generator	BendixKing	SEA Exchange
066-04021-1112	SG-465		Symbol Generator	BendixKing	OEM Dealer Repair
066-04021-1113	SG-465		EFIS Symbol Generator	BendixKing	SEA Exchange
066-04021-1114	SG-465		EFIS Symbol Generator	BendixKing	OEM Dealer Repair
066-04021-1115	SG-465		EFIS Symbol Generator (WAAS)	BendixKing	SEA Exchange
066-04021-1116	SG-465		EFIS Symbol Generator	BendixKing	SEA Exchange
066-04021-1411	SG-465		Symbol Generator	BendixKing	OEM Dealer Repair
066-04021-1413	SG-465		Symbol Generator	BendixKing	OEM Dealer Repair
066-04031-0101	KLN-90		GPS	BendixKing	SEA Repair
066-04031-0111	KLN-90A		GPS	BendixKing	SEA Repair
066-04031-0201	KLN-90		GPS	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-04031-0311	KLN-90A		GPS Receiver	BendixKing	SEA Repair
066-04031-0411	KLN-90A		GPS Receiver	BendixKing	SEA Repair
066-04031-1121	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-1122	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-1221	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-1321	KLN-90B		GPS Receiver	BendixKing	SEA Repair
066-04031-1322	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-1421	KLN-90B		GPS Receiver	BendixKing	SEA Repair
066-04031-1422	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-1521	KLN-90B		IFR GPS Receiver (NVG)	BendixKing	OEM Dealer Repair
066-04031-1622	KLN-90B		IFR GPS Receiver (NVG)	BendixKing	SEA Repair
066-04031-2121	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-2122	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-2221	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04031-2222	KLN-90B		GPS Receiver	BendixKing	SEA Repair
066-04031-2321	KLN-90B		GPS Receiver	BendixKing	SEA Repair
066-04031-2322	KLN-90B		GPS Receiver	BendixKing	SEA Repair
066-04031-2421	KLN-90B		GPS Receiver	BendixKing	SEA Repair
066-04031-2422	KLN-90B		IFR GPS Receiver	BendixKing	SEA Repair
066-04034-0101	KLN-900		DZUS Mount GPS	BendixKing	SEA Repair
066-04034-0102	KLN-900		DZUS Mount GPS	BendixKing	SEA Repair
066-04034-0104	KLN-900		DZUS Mount GPS	BendixKing	SEA Repair
066-04034-0201	KLN-900		DZUS Mount GPS	BendixKing	SEA Repair
066-04034-0202	KLN-900		DZUS Mount GPS	BendixKing	SEA Repair
066-04034-0204	KLN-900		DZUS Mount GPS	BendixKing	SEA Repair
066-04035-0101	KMD-540		Multifunction Display (Black)	BendixKing	SEA Repair
066-04035-0201	KMD-540		Multifunction Display (Gray)	BendixKing	SEA Repair
066-04035-0301	KMD-540		MFD (Silver Crown Bezel)	BendixKing	SEA Repair
066-04035-1101	KMD-540		Multifunction Display (unit only)	BendixKing	SEA Repair
066-04035-1201	KMD-540		Multifunction Display (unit only)	BendixKing	SEA Repair
066-04035-1301	KMD-540		Multifunction Display (unit only)	BendixKing	SEA Repair
066-1021-00	KR-21		Marker Beacon Receiver	BendixKing	SEA Repair
066-1021-01	KR-21		Marker Receiver	BendixKing	SEA Repair
066-1021-02	KR-21		Marker Beacon Receiver	BendixKing	SEA Repair
066-1033-00	KN-73		Glideslope Receiver	BendixKing	SEA Repair
066-1035-00	KGM-691		Glideslope/Marker Receiver	BendixKing	SEA Repair
066-1035-01	KGM-691		Glideslope/Marker Receiver	BendixKing	SEA Repair
066-1035-02	KGM-691		Glideslope/Marker Receiver	BendixKing	SEA Repair
066-1041-00	KXP-755		Transponder	BendixKing	SEA Repair
066-1044-00	KMR-675		Marker Receiver	BendixKing	SEA Repair
066-1044-01	KMR-675		Marker Beacon Receiver	BendixKing	SEA Repair
066-1047-00	KDF-805		ADF Receiver	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-1047-01	KDF-805		ADF Receiver	BendixKing	SEA Repair
066-1048-00	KRA-405		Radio Altimeter R/T	BendixKing	SEA Repair
066-1048-02	KRA-405		Radio Altimeter R/T	BendixKing	SEA Repair
066-1053-00	KT-79		Digital Transponder	BendixKing	SEA Repair
066-1055-00	KMA-24		Audio/Marker Panel	BendixKing	SEA Repair
066-1055-01	KMA-24		Audio/Marker Panel	BendixKing	SEA Repair
066-1055-02	KMA-24		Audio/Marker Panel	BendixKing	SEA Repair
066-1055-03	KMA-24		Audio/Marker Panel	BendixKing	SEA Repair
066-1055-50	KMA-24H		Audio Panel	BendixKing	SEA Repair
066-1055-51	KMA-24H		Audio Panel	BendixKing	SEA Repair
066-1055-52	KMA-24H		Audio Panel w/ Intercom	BendixKing	SEA Repair
066-1055-53	KMA-24H		Audio Panel	BendixKing	SEA Repair
066-1055-70	KMA-24H		Audio Panel w/ Intercom	BendixKing	SEA Repair
066-1055-71	KMA-24H		Audio Panel w/ Intercom	BendixKing	SEA Repair
066-1061-00	KRA-10		Radar Altimeter Receiver	BendixKing	SEA Repair
066-1061-03	KRA-10A		Radio Altimeter R/T	BendixKing	SEA Repair
066-1062-00	KT-76A		Transponder	BendixKing	SEA Repair
066-1062-01	KT-78A		Transponder	BendixKing	SEA Repair
066-1062-02	KT-76A		Transponder	BendixKing	SEA Repair
066-1062-10	KT-76A		Transponder (Crown Series)	BendixKing	SEA Repair
066-1063-00	KN-75		Glideslope Receiver	BendixKing	SEA Repair
066-1064-00	KN-62		Panel Mount DME	BendixKing	SEA Repair
066-1065-00	KR-22		Marker Receiver	BendixKing	SEA Repair
066-1066-00	KDM-706		DME Transceiver	BendixKing	SEA Repair
066-1066-01	KDM-706		DME	BendixKing	SEA Repair
066-1066-02	KDM-706		DME Transceiver	BendixKing	SEA Repair
066-1066-11	KDM-706A		DME R/T	BendixKing	SEA Repair
066-1066-20	KDM-706A		DME R/T	BendixKing	SEA Repair
066-1066-21	KDM-706A		DME R/T	BendixKing	SEA Repair
066-1066-22	KDM-706A		DME Transceiver	BendixKing	SEA Repair
066-1066-23	KDM-706A		DME R/T	BendixKing	SEA Repair
066-1066-24	KDM-706A		DME Transceiver	BendixKing	SEA Repair
066-1066-25	KDM-706A		DME Transceiver	BendixKing	SEA Repair
066-1066-41	KDM-706		DME R/T	BendixKing	SEA Repair
066-1067-00	KN-53		Nav Receiver w/ GS	BendixKing	SEA Repair
066-1067-01	KN-53		Nav Receiver w/o GS	BendixKing	SEA Repair
066-1067-02	KN-53		Nav Receiver	BendixKing	SEA Repair
066-1067-03	KN-53		Nav Receiver	BendixKing	SEA Repair
066-1067-04	KN-53		Nav Receiver w/ GS (CNI5000)	BendixKing	SEA Repair
066-1067-05	KN-53		Nav Receiver	BendixKing	SEA Repair
066-1067-10	KN-53		Nav Receiver (SC+)	BendixKing	SEA Repair
066-1068-00	KN-62A		Panel Mount DME	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-1068-01	KN-62A		Panel Mount DME	BendixKing	SEA Repair
066-1068-04	KN-62A		Panel Mount DME	BendixKing	SEA Repair
066-1069-00	KDI-572		DME Indicator	BendixKing	SEA Repair
066-1069-01	KDI-572		DME Indicator	BendixKing	SEA Repair
066-1069-02	KDI-573		Slave DME Indicator	BendixKing	SEA Repair
066-1069-03	KDI-573		DME Indicator	BendixKing	SEA Repair
066-1069-04	KDI-574		DME Indicator	BendixKing	SEA Repair
066-1069-05	KDI-574		DME Indicator	BendixKing	SEA Repair
066-1070-00	KN-63		DME Transceiver	BendixKing	SEA Repair
066-1070-01	KN-63		DME Transceiver	BendixKing	SEA Repair
066-1071-00	KXP-756		ATC Transponder	BendixKing	SEA Repair
066-1072-00	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1072-01	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1072-02	KR-87		ADF Receiver (Dual Ind. Capability)	BendixKing	SEA Repair
066-1072-03	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1072-04	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1072-05	KR-87		ADF Receiver (28V - Dual Ind)	BendixKing	SEA Repair
066-1072-06	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1072-07	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1072-14	KR-87		ADF Receiver	BendixKing	SEA Repair
066-1074-00	KTU-709		TACAN Receiver	BendixKing	SEA Repair
066-1074-01	KTU-709		TACAN Receiver	BendixKing	SEA Repair
066-1074-02	KTU-709		TACAN Receiver	BendixKing	SEA Repair
066-1077-00	KDF-806		ADF Receiver	BendixKing	SEA Repair
066-1077-01	KDF-806		ADF Receiver	BendixKing	SEA Repair
066-1078-00	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-01	KNR-634		NAV Receiver	BendixKing	SEA Repair
066-1078-02	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-03	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-04	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-05	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-06	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-07	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-08	KNR-634		Nav Receiver	BendixKing	SEA Repair
066-1078-10	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-11	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-12	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-13	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-14	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-15	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-16	KNR-634A		Nav Receiver	BendixKing	SEA Repair
066-1078-17	KNR-634A		Nav Receiver	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-1088-00	KN-64		Panel Mount DME	BendixKing	SEA Repair
066-1088-01	KN-64		Panel Mount DME (SC+)	BendixKing	SEA Repair
066-1089-00	KA-120		DME/GS Adapter	BendixKing	SEA Repair
066-3011-01	KNI-520		Navigation Indicator	BendixKing	SEA Repair
066-3011-04	KNI-520		Nav Indicator	BendixKing	SEA Repair
066-3012-00	KA-35		Marker Beacon Lights	BendixKing	SEA Repair
066-3012-01	KA-35A		Marker Beacon Lights	BendixKing	SEA Repair
066-3024-40	KPI-552		Pictorial Nav Indicator	BendixKing	SEA Exchange
066-3024-47	KPI-552	6610-01-391-9355	HSI	BendixKing	SEA Exchange
066-3031-00	KNI-415		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3031-01	KNI-415		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3031-02	KNI-415		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3031-03	KNI-415		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3034-00	KI-203		VOR/LOC Indicator	BendixKing	SEA Repair
066-3034-01	KI-203		VOR/ILS Indicator	BendixKing	SEA Repair
066-3034-02	KI-204		VOR/LOC/GS Indicator	BendixKing	SEA Repair
066-3034-03	KI-204		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-04	KI-206		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-05	KI-206		VOR/LOC/GS Indicator w/ Course Datum	BendixKing	SEA Repair
066-3034-06	KI-207		VOR/LOC/GS Ind. (no OBS)	BendixKing	SEA Repair
066-3034-07	KI-202		VOR/LOC Indicator	BendixKing	SEA Repair
066-3034-08	KI-202		VOR Indicator	BendixKing	SEA Repair
066-3034-09	KI-202		VOR Indicator	BendixKing	SEA Repair
066-3034-10	KI-206		VOR/GS Indicator w/ Synchro	BendixKing	SEA Repair
066-3034-11	KI-202		Nav Indicator	BendixKing	SEA Repair
066-3034-12	KI-206		VOR/GS Indicator (400Hz resolver)	BendixKing	SEA Repair
066-3034-13	KI-206		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-14	KI-206		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-15	KI-206		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-16	KI-206		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-17	KI-207		VOR Indicator	BendixKing	SEA Repair
066-3034-18	KI-204		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-22	KI-204		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-24	KI-206		VOR/GS Indicator	BendixKing	SEA Repair
066-3034-25	KI-207		VOR/GS Repeater Indicator	BendixKing	SEA Repair
066-3038-00	KI-229		RMI	BendixKing	SEA Repair
066-3038-01	KI-229		RMI	BendixKing	SEA Repair
066-3042-00	KNI-581		RMI	BendixKing	SEA Repair
066-3042-01	KNI-581		RMI	BendixKing	SEA Repair
066-3042-02	KNI-581		RMI	BendixKing	SEA Repair
066-3042-03	KNI-581		RMI	BendixKing	SEA Repair
066-3042-04	KNI-581		RMI	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-3044-00	KNI-416		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3044-01	KNI-416		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3044-02	KNI-416		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3044-03	KNI-416		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3046-00	KI-525A		HSI	BendixKing	SEA Repair
066-3046-01	KI-525A		HSI	BendixKing	SEA Repair
066-3046-02	KI-525A		HSI	BendixKing	SEA Repair
066-3046-03	KI-525A		HSI	BendixKing	SEA Repair
066-3046-04	KI-525A		HSI	BendixKing	SEA Repair
066-3046-05	KI-525A		HSI	BendixKing	SEA Repair
066-3046-06	KI-525A		HSI	BendixKing	SEA Repair
066-3046-07	KI-525A		HSI	BendixKing	SEA Repair
066-3046-08	KI-525A		HSI	BendixKing	SEA Repair
066-3046-09	KI-525A		HSI	BendixKing	SEA Repair
066-3046-10	KI-525A		HSI	BendixKing	SEA Repair
066-3046-11	KI-525A		HSI	BendixKing	SEA Repair
066-3046-12	KI-525A		HSI	BendixKing	SEA Repair
066-3046-13	KI-525A		HSI NVG	BendixKing	SEA Repair
066-3054-00	KI-250		Radar Altimeter Indicator	BendixKing	SEA Repair
066-3054-01	KI-250		Radio Altimeter Indicator	BendixKing	SEA Repair
066-3054-02	KI-250		Radar Altimeter Indicator	BendixKing	SEA Repair
066-3054-03	KI-250		Radar Altimeter Indicator	BendixKing	SEA Repair
066-3054-04	KI-250		Radar Altimeter Indicator	BendixKing	SEA Repair
066-3054-05	KI-250		Radar Altimeter Indicator	BendixKing	SEA Repair
066-3056-00	KI-208		VOR/LOC Indicator	BendixKing	SEA Repair
066-3056-01	KI-209		VOR/ILS/GS Indicator	BendixKing	SEA Repair
066-3056-02	KI-208		VOR/LOC Indicator (Anti-Refl)	BendixKing	SEA Repair
066-3056-03	KI-209		VOR/LOC/GS Indicator (Anti-Refl)	BendixKing	SEA Repair
066-3056-10	KI-208A		VOR/LOC/GPS Indicator	BendixKing	SEA Repair
066-3056-11	KI-209A		VOR/LOC/GS/GPS Indicator	BendixKing	SEA Repair
066-3059-00	KI-228		Dual ADF Indicator	BendixKing	SEA Repair
066-3059-01	KI-228		Dual ADF Indicator	BendixKing	SEA Repair
066-3060-00	KNI-582		Nav Indicator	BendixKing	SEA Repair
066-3060-01	KNI-582		Nav Indicator	BendixKing	SEA Repair
066-3060-02	KNI-582		Nav Indicator	BendixKing	SEA Repair
066-3060-03	KNI-582		Nav Indicator	BendixKing	SEA Repair
066-3060-04	KNI-582		Nav Indicator (TACAN version)	BendixKing	SEA Repair
066-3060-05	KNI-582		Nav Indicator	BendixKing	SEA Repair
066-3060-06	KNI-582		Nav Indicator NVG	BendixKing	SEA Repair
066-3062-00	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3062-01	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3062-02	KEA-346		Encoding Altimeter	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-3062-03	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3062-08	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3062-09	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3062-10	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3062-11	KEA-346		Encoding Altimeter	BendixKing	SEA Repair
066-3063-00	KI-227		ADF Indicator	BendixKing	SEA Repair
066-3063-01	KI-227		ADF Indicator	BendixKing	SEA Repair
066-3064-00	KEA-129		Encoding Altimeter	BendixKing	SEA Exchange
066-3064-01	KEA-129	5826-01-357-8219	Encoding Altimeter	BendixKing	SEA Exchange
066-3064-02	KEA-130		Encoding Altimeter	BendixKing	SEA Repair
066-3064-03	KEA-130		Encoding Altimeter	BendixKing	SEA Repair
066-3064-05	KEA-130A		Encoding Altimeter	BendixKing	SEA Repair
066-3077-20	KAV-485		Altimeter/VSI	BendixKing	OEM Dealer Repair
066-3077-60	KAV-485		Altimeter/VSI	BendixKing	OEM Dealer Repair
066-3079-00	KAI-487		Mach Airspeed Indicator	BendixKing	OEM Dealer Repair
066-3079-10	KAI-487		March Airspeed Indicator	BendixKing	OEM Dealer Repair
066-3080-04	KAS-488		SAT/TAS Indicator	BendixKing	OEM Dealer Repair
066-3084-00	IN-182A		Color Radar Indicator	BendixKing	SEA Repair
066-3084-01	IN-182A		Radar Indicator	BendixKing	SEA Repair
066-3084-02	IN-182A		Color Radar Indicator	BendixKing	SEA Repair
066-3084-03	IN-182A		Radar Indicator	BendixKing	SEA Repair
066-3084-30	IN-182A		Radar Indicator	BendixKing	SEA Repair
066-3084-32	IN-182A		Radar Indicator	BendixKing	SEA Repair
066-3084-33	IN-182A		Radar Indicator	BendixKing	SEA Repair
066-3085-00	IN-842A		Radar Indicator	BendixKing	SEA Repair
066-3085-10	IN-842A		Radar Indicator	BendixKing	SEA Repair
066-3085-11	IN-842A		Radar Indicator	BendixKing	SEA Repair
066-3085-30	IN-842A		Color Radar Indicator (RDS-84VP)	BendixKing	SEA Repair
066-3085-31	IN-842A		Color Radar Indicator	BendixKing	SEA Repair
066-3086-00	IN-862A		Radar Indicator	BendixKing	SEA Repair
066-3086-01	IN-862A		Radar Indicator (RDS-86)	BendixKing	SEA Repair
066-3086-10	IN-862A		Radar Indicator	BendixKing	SEA Repair
066-3086-11	IN-862A		Radar Indicator	BendixKing	SEA Repair
066-3086-30	IN-862A		Color Radar Indicator	BendixKing	SEA Repair
066-3086-31	IN-862A		Radar Indicator	BendixKing	SEA Repair
066-3114-00	IN-812A		Radar Indicator	BendixKing	SEA Repair
066-3114-01	IN-812A		Color Radar Indicator	BendixKing	SEA Repair
066-4004-00	KN-77		VOR/LOC Converter	BendixKing	SEA Repair
066-4007-00	KNR-630		Nav Receiver	BendixKing	SEA Repair
066-4007-01	KNR-631		Nav Receiver	BendixKing	SEA Repair
066-4007-02	KNR-632		Nav Receiver	BendixKing	SEA Repair
066-4007-03	KNR-633		VOR Converter	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
066-4008-00	KNS-80		Nav System	BendixKing	SEA Repair
066-4008-01	KNS-80		Nav System	BendixKing	SEA Repair
066-4009-00	KN-72		VOR/LOC Converter	BendixKing	SEA Repair
066-4010-00	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-01	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-03	KNS-81		Nav System	BendixKing	SEA Repair
066-4010-04	KNS-81		Nav System	BendixKing	SEA Repair
066-4010-10	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-11	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-12	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-13	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-18	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-19	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-30	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-32	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-40	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-4010-62	KNS-81		Panel Mount Nav System	BendixKing	SEA Repair
066-50008-0102	RTA-4B		Radar Transceiver	BendixKing	OEM Dealer Repair
066-50008-0408	RTA-4B		Radar Receiver Transmitter	BendixKing	OEM Dealer Repair
069-01028-0101	KX-125		LCD Nav/Comm	BendixKing	SEA Repair
069-01028-1101	KX-125		LCD Nav/Comm	BendixKing	SEA Repair
069-01029-0701	KLX-135A		VFR GPS/Comm Atlantic	BendixKing	SEA Repair
069-01029-0702	KLX-135A		VFR GPS/Comm Pacific	BendixKing	SEA Repair
069-01029-0703	KLX-135A		VFR GPS/Comm	BendixKing	SEA Repair
069-01032-0101	KX-155A		Nav/Comm w/ Glideslope (28V)	BendixKing	SEA Repair
069-01032-0201	KX-155A		Nav/Comm w/o GS (28V)	BendixKing	SEA Repair
069-01033-0101	KX-165A		Nav/Comm	BendixKing	SEA Repair
069-01033-0201	KX-165A		Nav/Comm (8.33)	BendixKing	SEA Repair
069-01034-0101	KLN-94		Color IFR GPS Receiver	BendixKing	SEA Repair
069-01034-0102	KLN-94		Color IFR GPS Receiver	BendixKing	SEA Repair
069-1024-00	KX-155		Nav/Comm w/o GS	BendixKing	SEA Repair
069-1024-01	KX-155		Nav/Comm w/GS	BendixKing	SEA Repair
069-1024-02	KX-155		Nav/Comm	BendixKing	SEA Repair
069-1024-03	KX-155		Nav/Comm	BendixKing	SEA Repair
069-1024-04	KX-155		Nav/Comm w/o GS/28V	BendixKing	SEA Repair
069-1024-05	KX-155		Nav/Comm w/ GS (28V)	BendixKing	SEA Repair
069-1024-06	KX-155		Nav/Comm	BendixKing	SEA Repair
069-1024-07	KX-155		Nav/Comm	BendixKing	SEA Repair
069-1024-08	KX-155		Nav/Comm w/o GS (14V)	BendixKing	SEA Repair
069-1024-09	KX-155		Nav/Comm	BendixKing	SEA Repair
069-1024-10	KX-155		Nav/Comm	BendixKing	SEA Repair
069-1024-11	KX-155		Nav / Comm w/o GS / 28v	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
069-1024-12	KX-155		Nav / Comm w/GS / 14v	BendixKing	SEA Repair
069-1024-13	KX-155		Nav / Comm w/GS / 28v	BendixKing	SEA Repair
069-1024-30	KX-155		Nav/Comm w/o GS/14V	BendixKing	SEA Repair
069-1024-31	KX-155		Nav/Comm w/ GS / 14v	BendixKing	SEA Repair
069-1024-32	KX-155		Nav / Comm w/o GS / 14v	BendixKing	SEA Repair
069-1024-33	KX-155		Nav / Comm w/GS / 14v	BendixKing	SEA Repair
069-1024-34	KX-155		Nav/Comm w/o GS (28V)	BendixKing	SEA Repair
069-1024-35	KX-155		Nav/Comm w/ GS (28V)	BendixKing	SEA Repair
069-1024-36	KX-155		Nav / Comm w/o GS / 28v	BendixKing	SEA Repair
069-1024-37	KX-155		Nav / Comm w/GS / 28v	BendixKing	SEA Repair
069-1024-38	KX-155		Nav/Comm w/o GS (14V)	BendixKing	SEA Repair
069-1024-39	KX-155		Nav/Comm w/o GS (28V)	BendixKing	SEA Repair
069-1024-40	KX-155		Nav/Comm / No GS / 14v	BendixKing	SEA Repair
069-1024-41	KX-155		Nav/Comm / No GS / 28v	BendixKing	SEA Repair
069-1024-42	KX-155		Nav/Comm w/ GS (14V)	BendixKing	SEA Repair
069-1024-43	KX-155		Nav/Comm w/ GS (28V)	BendixKing	SEA Repair
069-1025-00	KX-165		Nav/Comm w/o GS	BendixKing	SEA Repair
069-1025-01	KX-165		Nav/Comm w/ GS (14V)	BendixKing	SEA Repair
069-1025-02	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-03	KX-165		Nav/Comm w/ GS (14V)	BendixKing	SEA Repair
069-1025-04	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-05	KX-165		Nav/Comm w/ GS	BendixKing	SEA Repair
069-1025-06	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-07	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-20	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-21	KX-165		Nav/Comm w/ GS (14V)	BendixKing	SEA Repair
069-1025-22	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-23	KX-165		Nav/Comm	BendixKing	SEA Repair
069-1025-24	KX-165		Nav/Comm w/o GS	BendixKing	SEA Repair
069-1025-25	KX-165		Nav/Comm w/ GS (28V)	BendixKing	SEA Repair
069-1025-26	KX-165		Nav/Comm w/ GS	BendixKing	SEA Repair
069-1025-27	KX-165		Nav/Comm	BendixKing	SEA Repair
070-01029-0010	KLX-135A		KLX0135A GPS/Com 14 V	BendixKing	SEA Repair
070-01029-0012	KLX-135A		VFR GPS/ Comm	BendixKing	SEA Repair
071-0003-00	KA-40		Marker Lights	BendixKing	SEA Repair
071-00097-0100	CM-2000		Configuration Module	BendixKing	SEA Repair
071-00158-0211	KAC-502		EGPWS Module	BendixKing	SEA Repair
071-00159-0111	KAC-501		Weather Radar Module	BendixKing	SEA Repair
071-00166-0411	KAC-504		Traffic Module	BendixKing	SEA Repair
071-00168-0311	KAC-503		FIS Module	BendixKing	SEA Repair
071-0017-00	KA-57		Autopilot Adapter	BendixKing	SEA Repair
071-0019-00	KA-158		Bridging Amplifier	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-01438-0101	CP-466A		EFIS Control	BendixKing	SEA Repair
071-01438-0102	CP-466A		EFIS Control Panel (Black)	BendixKing	SEA Repair
071-01438-0201	CP-466A		EFIS Control	BendixKing	SEA Repair
071-01438-0202	CP-466A		EFIS Control Panel (Gray)	BendixKing	SEA Repair
071-01438-0301	CP-466A		EFIS Control	BendixKing	SEA Repair
071-01438-0302	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-0401	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-0402	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-0502	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-0602	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-0702	CP-466A		EFIS/Radar Control Panel	BendixKing	SEA Repair
071-01438-0802	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-0902	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-1002	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-1102	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01438-1202	CP-466A		EFIS Control Panel	BendixKing	SEA Repair
071-01439-3100	CP-467	1680-01-415-5770	EFIS Control	BendixKing	SEA Exchange
071-01493-0101	CP-466B		EFIS Control	BendixKing	SEA Repair
071-01493-0102	CP-466B		EFIS Control Panel (Black)	BendixKing	SEA Repair
071-01493-0202	CP-466B		EFIS Control Panel (Gray)	BendixKing	SEA Repair
071-01493-0302	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-0401	CP-466B		EFIS Control	BendixKing	SEA Repair
071-01493-0402	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-0502	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-0602	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-0702	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-0802	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-0902	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-1002	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-1102	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01493-1202	CP-466B		EFIS Control Panel	BendixKing	SEA Repair
071-01501-0000	KA-54A		Rad. Alt. Antenna	BendixKing	SEA Repair
071-01501-0100	KA-54A		Rad Alt Antenna (Black)	BendixKing	SEA Repair
071-01507-0901	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1001	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1101	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1201	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1301	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1401	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1501	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1601	KFS-578A		Transponder Control	BendixKing	SEA Repair
071-01507-1701	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-01507-1801	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-1901	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-2001	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-2201	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-2301	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-2501	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-2901	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-3201	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-3303	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-3403	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-3502	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-3503	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-3603	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4102	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4202	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4302	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4304	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4402	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4404	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4902	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-4903	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5002	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5003	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5102	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5103	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5202	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5203	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-5503	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-6503	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-6603	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-6703	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-6803	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-7504	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-7604	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-8103	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-8203	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-8303	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01507-8403	KFS-578A		TCAS/Transponder Control	BendixKing	SEA Repair
071-01508-0201	KA-90		Multifunction Adapter	BendixKing	SEA Exchange
071-01508-0202	KA-90		Multi-interface Adapter	BendixKing	SEA Exchange
071-01519-0101	ART-2000		Radar Transceiver	BendixKing	SEA Repair
071-01528-0100	AA-2010H		Antenna Array (Horizontal Polarization)	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-01528-0200	AA-2012H		Radar Antenna Array	BendixKing	SEA Repair
071-01539-0101	KFS-599A		UHF Comm Control - NVG	BendixKing	SEA Repair
071-01546-0101	KFS-599A		UHF Comm Control	BendixKing	SEA Repair
071-01546-0202	KFS-599A		UHF Comm Control	BendixKing	SEA Repair
071-01546-0401	KFS-599A		UHF Comm Control	BendixKing	SEA Repair
071-01549-0100	AA-2010V		10\ Antenna Array"	BendixKing	SEA Repair
071-01549-0200	AA-2012V		Radar Antenna Array (12\)"	BendixKing	SEA Repair
071-01550-0101	ART-2100		Radar Sensor	BendixKing	SEA Repair
071-01553-0200	KA-92		GPS Antenna	BendixKing	SEA Repair
071-01597-0401	KMC-9200		AFCS Controller	BendixKing	SEA Exchange
071-01605-0201	PS-440		HF Control (Black)	BendixKing	SEA Exchange
071-01605-1201	PS-440		HF Control	BendixKing	OEM Dealer Repair
071-01618-0004	PS-578		TCAS Transponder Control	BendixKing	OEM Dealer Repair
071-01618-0025	PS-578		TCAS/Transponder Control	BendixKing	OEM Dealer Repair
071-01618-0027	PS-578		TCAS/Transponder Control	BendixKing	OEM Dealer Repair
071-01618-0104	PS-578		TCAS/ Transponder Control	BendixKing	SEA Exchange
071-01618-0114	PS-578		TCAS/Transponder Control	BendixKing	OEM Dealer Repair
071-01618-0122	PS-578A		TCAS/Transponder Control	BendixKing	OEM Dealer Repair
071-01618-0125	PS-578		TCAS/Transponder Control	BendixKing	SEA Exchange
071-01619-0121	PS-550		TCAS II Control	BendixKing	OEM Dealer Repair
071-1012-09	KFS-590A		Comm Control	BendixKing	SEA Repair
071-1012-10	KFS-590A		Communications Control	BendixKing	SEA Repair
071-1012-11	KFS-590A		Communications Control	BendixKing	SEA Repair
071-1012-12	KFS-590B		VHF Comm Control	BendixKing	SEA Repair
071-1012-13	KFS-590B		Communications Control	BendixKing	SEA Repair
071-1012-14	KFS-590B		Communications Control	BendixKing	SEA Repair
071-1012-15	KFS-590B		Communications Control	BendixKing	SEA Repair
071-1012-17	KFS-590B		Comm Control	BendixKing	SEA Repair
071-1041-00	KA-39		Voltage Converter	BendixKing	SEA Repair
071-1041-01	KA-39		Voltage Converter	BendixKing	SEA Repair
071-1043-02	KFS-570B		ATC Transponder Control	BendixKing	SEA Repair
071-1052-00	KMT-112		Flux Detector	BendixKing	SEA Repair
071-1054-02	KFS-560B		Nav Control	BendixKing	SEA Repair
071-1054-04	KFS-560B		Nav Control	BendixKing	SEA Repair
071-1054-05	KFS-560B		VHF NAV Control Head	BendixKing	SEA Repair
071-1055-00	KA-52		Autopilot Adapter	BendixKing	SEA Repair
071-1059-00	KA-54		Radio Altimeter Antenna	BendixKing	SEA Repair
071-1066-00	KFS-580B		ADF Control	BendixKing	SEA Repair
071-1076-00	KDA-697		RMI Adapter	BendixKing	SEA Repair
071-1095-00	KA-118		Heading Error Adapter	BendixKing	SEA Repair
071-1095-01	KA-118		Heading Error Adapter	BendixKing	SEA Repair
071-1114-00	KA-131		Radio Altimeter Antenna	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-1114-01	KA-131		Radio Altimeter Antenna	BendixKing	SEA Repair
071-1133-00	KA-42B		ADF Antenna	BendixKing	SEA Repair
071-1192-00	KFS-576		Transponder Control	BendixKing	SEA Repair
071-1192-01	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-02	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-03	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-04	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-05	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-06	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-07	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-08	KFS-576		Transponder Control	BendixKing	SEA Repair
071-1192-09	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-10	KFS-576		Transponder Control	BendixKing	SEA Repair
071-1192-11	KFS-576		Transponder Control	BendixKing	SEA Repair
071-1192-13	KFS-576		Transponder Control (Dual)	BendixKing	SEA Repair
071-1192-14	KFS-576		Transponder Control (Dual)	BendixKing	SEA Repair
071-1192-15	KFS-576		Transponder Control (Dual)	BendixKing	SEA Repair
071-1192-16	KFS-576		Transponder Control (Dual)	BendixKing	SEA Repair
071-1192-18	KFS-576		Transponder Control	BendixKing	SEA Repair
071-1192-22	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1192-26	KFS-576		ATC Transponder Control	BendixKing	SEA Repair
071-1196-00	KA-44		ADF Antenna	BendixKing	SEA Repair
071-1210-04	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-05	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-06	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-07	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-08	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-09	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-10	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-11	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-12	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-13	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-14	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-15	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-16	KFS-586		ADF Control	BendixKing	SEA Repair
071-1210-17	KFS-586		ADF Control	BendixKing	SEA Repair
071-1215-24	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-25	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-26	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-27	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-29	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-30	KFS-598		Comm Control	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-1215-31	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-32	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-34	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-35	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-36	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-37	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-38	KFS-598		Communications Control	BendixKing	SEA Repair
071-1215-39	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-40	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-41	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-42	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-43	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-44	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-54	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-55	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-56	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-57	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-59	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-60	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-61	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-62	KFS-598		Comm Control	BendixKing	SEA Repair
071-1215-64	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-65	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-66	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-67	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-70	KFS-598		VHF Comm Control	BendixKing	SEA Repair
071-1215-71	KFS-598		Comm Control	BendixKing	SEA Repair
071-1216-12	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-13	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-15	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-16	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-17	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-18	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-20	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-21	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-22	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-23	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-25	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-26	KFS-564		Nav Control	BendixKing	SEA Repair
071-1216-27	KFS-564		Nav Control	BendixKing	SEA Repair
071-1217-00	KDA-692		ADF Adapter	BendixKing	SEA Repair
071-1217-01	KDA-692		ADF Adapter	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-1232-00	KDA-688		Dual Superflag Adapter	BendixKing	SEA Repair
071-1234-00	KA-44B		ADF Antenna	BendixKing	SEA Repair
071-1234-01	KA-44B		ADF Antenna	BendixKing	SEA Repair
071-1234-02	KA-44B		ADF Antenna	BendixKing	SEA Repair
071-1242-00	KA-51B		Slaving Accessory (14V - Black - Vertical)	BendixKing	SEA Repair
071-1242-01	KA-51B		Slaving Accessory (28V - Black - Vertical)	BendixKing	SEA Repair
071-1242-02	KA-51B		Slaving Accessory(28V - Gray - Vertical)	BendixKing	SEA Repair
071-1242-03	KA-51B		Slaving Accessory(5V - Black - Vertical)	BendixKing	SEA Repair
071-1242-04	KA-51B		Slaving Accessory(28V - Black - Vertical)	BendixKing	SEA Repair
071-1242-05	KA-51B		Slaving Accessory(14V - Black Horizontal)	BendixKing	SEA Repair
071-1242-06	KA-51B		Slaving Control	BendixKing	SEA Repair
071-1242-07	KA-51B		Slaving Accessory(5V - Gray - Horizontal)	BendixKing	SEA Repair
071-1242-08	KA-51B		Slaving Accesspru(5V - Gray - Vertical)	BendixKing	SEA Repair
071-1242-09	KA-51B		Slaving Accessory(28V - Gray - Horizontal)	BendixKing	SEA Repair
071-1242-11	KA-51B		Slaving Accessory(5V - Black - Horizontal)	BendixKing	SEA Repair
071-1242-12	KA-51B		Slaving Accessory	BendixKing	SEA Repair
071-1251-00	KA-138		Relay	BendixKing	SEA Repair
071-1268-00	KA-594		HF Control Adapter	BendixKing	SEA Repair
071-1268-01	KA-594		HF Control Adapter	BendixKing	SEA Repair
071-1269-00	KA-160		Dual HF antenna adapter	BendixKing	SEA Repair
071-1269-01	KA-160		Dual HF Antenna Adapter	BendixKing	SEA Repair
071-1269-02	KA-160		Dual HF Antenna Adapter	BendixKing	SEA Repair
071-1270-01	KA-162		Dual HF External Capacitor	BendixKing	SEA Repair
071-1270-02	KA-162		Dual HF External Capacitor	BendixKing	SEA Repair
071-1274-00	KFS-594		HF Control	BendixKing	SEA Repair
071-1274-01	KFS-594		HF Control	BendixKing	SEA Repair
071-1274-02	KFS-594		HF Control	BendixKing	SEA Repair
071-1274-03	KFS-594		HF Control	BendixKing	SEA Repair
071-1274-04	KFS-594		HF Control	BendixKing	SEA Repair
071-1276-08	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-09	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-10	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-11	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-13	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-14	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-15	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-16	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-18	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-19	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-20	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-21	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-22	KFS-576A		Transponder Control	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-1276-23	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-24	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-25	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-26	KFS-576A		Transponder Control	BendixKing	SEA Repair
071-1276-27	KFS-576A		Transponder Control (NVG)	BendixKing	SEA Repair
071-1281-15	KFS-579A		TACAN Control	BendixKing	SEA Repair
071-1282-24	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-25	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-26	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-27	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-30	KFS-598A		Communications Control	BendixKing	SEA Repair
071-1282-31	KFS-598A		VHF Comm Control	BendixKing	SEA Repair
071-1282-34	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-35	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-36	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-37	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-38	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-39	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-40	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-41	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-43	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-44	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-46	KFS-598A		Comm Control (115VAC NVG)	BendixKing	SEA Repair
071-1282-47	KFS-598A		Comm Control NVG	BendixKing	SEA Repair
071-1282-64	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-65	KFS-598A		Comm Control (28V Black)	BendixKing	SEA Repair
071-1282-66	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-67	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-70	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-71	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-74	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-75	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-76	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-77	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-80	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-81	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1282-86	KFS-598A		Comm Control NVG	BendixKing	SEA Repair
071-1282-86	KFS-598A		Comm Control - 115V NVG	BendixKing	SEA Repair
071-1283-12	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-13	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-15	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-16	KFS-564A		NAV Control (Gray)	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-1283-17	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-18	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-20	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-21	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-22	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-23	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-25	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-26	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-27	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-28	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1283-30	KFS-598A		Communications Control	BendixKing	SEA Repair
071-1283-31	KFS-598A		VHF Comm Control	BendixKing	SEA Repair
071-1283-38	KFS-564A		Nav Control- 115VAC NVG	BendixKing	SEA Repair
071-1283-39	KFS-598A		Comm Control	BendixKing	SEA Repair
071-1284-04	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-05	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-06	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-07	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-08	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-09	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-10	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-11	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-12	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-13	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-14	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-15	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-16	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-17	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-18	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-19	KFS-586A		ADF Control (115 NVG 2 Layer)	BendixKing	SEA Repair
071-1284-20	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-21	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-22	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-23	KFS-564A		Nav Control	BendixKing	SEA Repair
071-1284-24	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1284-29	KFS-586A		ADF Control	BendixKing	SEA Repair
071-1315-00	RS-181A		Radar Sensor	BendixKing	SEA Repair
071-1315-10	RS-181A		Radar Transceiver	BendixKing	SEA Repair
071-1315-30	RS-181A		Radar Transceiver	BendixKing	SEA Repair
071-1316-00	AA-5510B		10 inch Antenna Array	BendixKing	SEA Repair
071-1317-00	AA-5512B		Antenna Array	BendixKing	SEA Repair
071-1318-00	RS-841A		Radar Sensor	BendixKing	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
071-1318-10	RS-841A		Radar Sensor	BendixKing	SEA Repair
071-1318-30	RS-841A		Radar Sensor	BendixKing	SEA Repair
071-1319-00	RS-861A		Radar Sensor	BendixKing	SEA Repair
071-1319-30	RS-861A		Radar Sensor w/ VP	BendixKing	SEA Repair
071-1378-00	RS-811A		Radar Sensor	BendixKing	SEA Repair
071-2008-00	KA-25A		ISO Amp	BendixKing	SEA Repair
0900-1840-22T	EPU28-24RM		Emergency Power Unit	Castleberry	OEM Dealer Repair
0900-3000-00	TRA-3000		Radio Altimeter R/T-Antenna	Free Flight	OEM Dealer Repair
0900-3030-00	TRI-30		Radar Altimeter Indicator (3")	Free Flight	OEM Dealer Repair
0900-3040-00	TRI-40		Radio Altimeter Indicator	Free Flight	OEM Dealer Repair
100-380006-167	76-174-1	6625-01-310-9154	Fuel Quantity Probe	Beechcraft	SEA Exchange
100-5657-02	2606013-1		Tachometer - Percent R.P.M.	Aero-Mach Labs	SEA Exchange
100-5658-01	2606014-1		Propeller Tachometer	Aero-Mach Labs	SEA Exchange
101-00901	TT1000A	2305-01-175-6530	Digital Turbine Temp Tester	Barfield	OEM Dealer Repair
101-00930	TT1200A	4920-01-527-1690	Digital Turbine Temp. Test Set	Barfield	OEM Dealer Repair
101-331-45-100	101 331 45 100		Comm Control	Gables	SEA Exchange
1013-41-011	UNS-1M		FMS CDU	Universal Avionics	OEM Dealer Repair
1013-42-011	UNS-1M	1680-01-644-9322	Flight Management Computer	Universal Avionics	OEM Dealer Repair
101-384106-9	563-124	6625-01-493-4880	Volt Load Meter	Beechcraft	SEA Exchange
101-384233-1	MD69-1	6625-01-363-3830	Volt and Amp Indicator	Beechcraft	SEA Exchange
1016-1-11			Control Display Unit	Universal Avionics	OEM Dealer Repair
10172-32-011	UNS-1C+		FMS	Universal Avionics	OEM Dealer Repair
10172-32-111			FMS	Universal Avionics	OEM Dealer Repair
10172-41-121	UNS-1C+		FMS	Universal Avionics	OEM Dealer Repair
1017-32-011	UNS 1		FMS	Universal Avionics	OEM Dealer Repair
1017-42-101	UNS-1		Flight Mgmt. System-CDU	Universal Avionics	OEM Dealer Repair
1017-42-201	UNS-1		Flight Mgmt. System- CDU	Universal Avionics	OEM Dealer Repair
102-0059-01	RCA26BK-7		Horizon Indicator		SEA Exchange
10312N01T00	76450-01076-111	6620-01-493-6988	Turbine Inlet Temperature Indicator	Ametek	SEA Exchange
10313N01R00	76450-01076-112	6620-01-417-4057	Triple Torque Indicator	Ametek	SEA Exchange
10-381550-4C	10-381550-4C	2925-01-462-8218	Ignition Exciter	Unison Industries	SEA Exchange
10-622-4531-113	CTL-31		Nav Control	Collins	SEA Repair
111302-5	111302-5	2920-00-580-1168	HSI	Astronautics	SEA Exchange
11162-40-1116	UNS-1K+		FMS Computer	Universal Avionics	OEM Dealer Repair
1116-30-1116	UNS-1K		FMS/ECU	Universal Avionics	OEM Dealer Repair
1116-40-1116	UNS-1K		NCU	Universal Avionics	OEM Dealer Repair
1117-11	UNS-1K		FMS CDU (Gray/Aft Mount)	Universal Avionics	OEM Dealer Repair
1117-1-106	UNS-1L		FMS Flat Panel CDU	Universal Avionics	OEM Dealer Repair
1117-1-206	UNS-1		Flat Panel Control Display Unit	Universal Avionics	SEA Exchange
114-380013-1	114-380013-1		Attitude Gyro	Beechcraft	SEA Exchange
114-380015-1	6900027-1	6110-01-311-6849	Prop Sync Indicator	Beechcraft	SEA Exchange
114-389039-21	EM450-4		Ice Vane Actuator	Beechcraft	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
118-380000-1	81-208-1		Fuel Quantity Indicator	Beechcraft	SEA Exchange
118-389004-49	75-134-13		Tank Unit	Beechcraft	SEA Exchange
1190-01-2111			NCU	Universal Avionics	OEM Dealer Repair
1190-02-2111	UNS-1B		Nav Computer Unit	Universal Avionics	OEM Dealer Repair
1192-00-111102	1D NCU		Flight Management System	Universal Avionics	OEM Dealer Repair
1192-00-111106			Flight Management System	Universal Avionics	OEM Dealer Repair
1192-30-111101	UNS-1D		Navigation Computer Unit	Universal Avionics	OEM Dealer Repair
121-040129-01	AT-160	5985-01-552-3279	Flexcomm Antenna (29.7-960 MHz) WHITE	Cobham	OEM Dealer Repair
121672-01-17	7000B	6615-00-900-5959	Vertical Gyro	Lear Siegler	SEA Exchange
125810-11	125810-11		HSI Indicator	Astronautics	SEA Exchange
130346-6	130346-6		Cabin Pressure Controller	Airesearch	SEA Exchange
130374-29	130374-29		Cabin Pressure Controller	Honeywell	SEA Exchange
130-380042-3	43-202-1		Torque Indicator	Beechcraft	SEA Exchange
1378-1B	1378-1B	1660-00-939-0460	Anti-Ice Controller	Sundstrand	SEA Exchange
1405-01-2	DTU		Data Transfer Unit	Universal Avionics	OEM Dealer Repair
1406-01-1	DTU-100	7025-01-530-8158	Data Transfer Unit (Gray)	Universal Avionics	OEM Dealer Repair
1406-01-2	DTU-100	7025-01-552-7543	Data Transfer Unit (Black)	Universal Avionics	OEM Dealer Repair
1407-01-1	DTU-100	7025-01-553-2846	Portable Data Transfer Unit	Universal Avionics	OEM Dealer Repair
142640-01-01	4005AC	6610-00-929-8968	Attitude Indicator	Lear Siegler	SEA Exchange
153-017311-01	AFIS		Sat Comm Transceiver	Honeywell	SEA Exchange
15527-1C	15527-1C		Altitude Control	Honeywell	SEA Exchange
1603-02-03	CVR-30B		SSCVR	Universal Avionics	OEM Dealer Repair
1603-02-12	CVR-120	5835-01-456-2572	SSCVR	Universal Avionics	OEM Dealer Repair
1614-01	1614-01	2815-01-102-7810	CVR Control	Universal Avionics	SEA Exchange
1614-02	1614-02	6515-01-023-4651	CVR Control Unit	Universal Avionics	SEA Exchange
163B220	163B220		Oil Temperature Indicator	Lewis Eng. Co.	SEA Exchange
16650-1151	166501151		Standby Altimeter (2 Inch)	Aerosonic	SEA Exchange
1775390-6	1775390-6	5985-01-005-1623	Trim Coupler	Honeywell	SEA Exchange
17960-0102-0003	GNS-XLS		Flight Management System	Honeywell	SEA Exchange
17960-0103-0001	GNS-XLS		Flight Management System	Honeywell	SEA Exchange
1901-3000-00	TRA-3000		Radar Altimeter R/T-Antenna	Free Flight	OEM Dealer Repair
1901-3040-00	TRI-40		Radar Altimeter Indicator	Free Flight	OEM Dealer Repair
1901-3040-10	TRI-40		Radar Altimeter Indicator (NVG)	Free Flight	OEM Dealer Repair
1901-3500-00	TRA-3500		Radar Altimeter Transceiver	Free Flight	OEM Dealer Repair
1A250-1A	1A2501AM	6130-01-068-7624	Static Inverter	Avionic Instruments	SEA Exchange
2017-41-211	UNS-1E		Flight Management System	Universal Avionics	OEM Dealer Repair
2019-41-201	UNS-1Espw		WAAS FMS (Gray - 5V)	Universal Avionics	OEM Dealer Repair
203-021-003	76450-01078-103	8415-01-607-2095	26055-203-021-003 Dual Fuel Qty Ind	Gull Airborne	SEA Exchange
203-022-005	76450-01078-101		Temp & Pressure Indicator	Gull Airborne	SEA Exchange
203-022-009	76450-01078-126	8415-01-607-2371	Engine Oil Press/Temp Ind	Parker Hannifin	SEA Exchange
203-022-013	76450-00906-102		Oil Pressure/Temperature Indicator	Gull Airborne	SEA Exchange
203-022-017	203-022-17		Oil Temperature/Pressure Indicator	Gull Airborne	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
209-070-262-101	124.115-3	6620-01-540-4298	Temp & Pressure Indicator	Bell Helicopter	SEA Exchange
2100-1010-00	FA2100	5835-01-476-8210	Solid State CVR	L3 Communications	SEA Repair
2100-1020-00	FA2100	6610-01-501-0114	Solid State CVR	L3 Communications	SEA Repair
2100-1020-02	FA2100 CVR	5999-01-266-3927	SSCVR - 2-Hour - AC/DC - FSK GMT	L3 Communications	SEA Exchange
2100-2042-00	FA2100 FDR		Solid State Flight Data Recorder	L3 Communications	SEA Exchange
212-075-037-101	3571262-5108	6685-01-462-4491	RPM Tachometer	Bell Helicopter	SEA Exchange
2179A-CF	2179ACF		Attitude Gyro	Honeywell	SEA Exchange
21B17-10B	6110-01-HR1-1403	6110-01-044-4331	Generator Control Unit	Bendix	SEA Exchange
245-604067-001	GPM		GPS Module (Non-WAAS) - EPIC	Honeywell	SEA Exchange
2587193-3	C-14	6615-00-433-0340	Directional Gyro	Honeywell	SEA Repair
2587193-23	C-14	6615-01-029-0025	Directional Gyro	Honeywell	SEA Repair
2587193-33	C-14	6615-01-020-7535	Directional Gyro	Honeywell	SEA Repair
2587193-42	C-14A		Directional Gyro	Honeywell	SEA Repair
2587193-43	C-14A	6615-01-020-7531	Directional Gyro	Honeywell	SEA Repair
2591411-444	HZ-444	6610-01-041-1879	Flight Director Indicator	Honeywell	SEA Exchange
2592920-044	RD-44	6610-01-141-6343	Radio Deviation Indicator	Honeywell	SEA Exchange
2592920-444	RD-444		HSI	Honeywell	SEA Exchange
2593379-001	CS-412 / DRC1	5895-01-419-0038	Dual Remote Compensator	Honeywell	SEA Exchange
2593379-1	CS-412	6605-01-284-3611	Dual Remote Compensator	Honeywell	SEA Exchange
2593996-333	TARSYN 333	6615-01-439-7594	3-Axis Reference Gyro	Honeywell	SEA Exchange
2593996-555	TARSYN 555		3 Axis Gyro	Honeywell	SEA Exchange
2594484	FX-220		Flux Valve	Honeywell	SEA Repair
270-2436-010	613L-3		Transponder Control	Collins	SEA Repair
270-2436-020	613L-3	5895-01-360-4183	Transponder Control	Collins	SEA Repair
270-2436-030	613L-3		Transponder Control	Collins	SEA Repair
270-2436-040	613L-3	5895-01-213-0806	Transponder Control	Collins	SEA Repair
270-2436-050	613L-3	5895-01-641-7782	Dual Transponder Control	Collins	SEA Repair
270-2436-060	613L-3	5895-01-530-1803	Transponder Control	Collins	SEA Repair
270-2436-070	613L-3		Transponder Control	Collins	SEA Repair
270-2436-080	613L-3		Transponder Control	Collins	SEA Repair
270-2436-090	613L-3		Transponder Control	Collins	SEA Repair
2800-0012-102	Jet Call 2	5895-01-322-7685	Selcal Decoder (2 Channel)	Free Flight	SEA Exchange
3017-41-211	UNS-1EW		WAAS FMS (Gray - Single ARINC - Analog)	Universal Avionics	OEM Dealer Repair
31300-0101-1200	C-5000		Flexcomm Control	Cobham	OEM Dealer Repair
31300-0201-1200	C-5000	5821-01-474-2548	Flexcomm II Control	Cobham	OEM Dealer Repair
31300-0401-1200	C-5000	5821-01-548-3925	Flexcomm Control	Cobham	OEM Dealer Repair
31300-1102-1200	C-5000		Flexcomm II Control Head	Cobham	OEM Dealer Repair
31300-1202-1200	C-5000		Flexcomm II Control Head (NVG)	Cobham	OEM Dealer Repair
31300-1202-1220	C-5000	5821-01-629-6380	Flexcomm Control	Cobham	OEM Dealer Repair
3137LB61C	3137LB61C	5826-01-309-9785	RMI	Aeronetics	SEA Exchange
3137L-B-6-3-C	3137LB63C		RMI	Aeronetics	SEA Exchange
3137LB64C	3137LB64C		RMI	Aeronetics	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
341C-1	341C-1		RMI Servo Amp	Collins	SEA Repair
352-001	352-001	5920-00-280-5073	Audio Selector Panel	DB Systems	SEA Exchange
3614001-4001	VC-401B		VHF Transceiver	Cobham	SEA Exchange
3614077-8101	RS-181A		Radar Transceiver	Honeywell	SEA Repair
3614078-8201	IN-182A		Radar Indicator	Honeywell	SEA Repair
3614078-8202	IN-182A		Radar Indicator	Honeywell	SEA Repair
3614165-5510	AA-5510B		10 inch Flat Plate	Honeywell	SEA Repair
3614165-5512	AA-5512B		12 inch Flat Plate	Honeywell	SEA Repair
3614475-8601	RS-861A		Radar Sensor	Honeywell	SEA Repair
3614475-8631	RS-861A		Radar Sensor	Honeywell	SEA Repair
3614477-8601	IN-862A		Radar Indicator	Honeywell	SEA Repair
3614477-8602	IN-862A		Radar Indicator	Honeywell	SEA Repair
3614477-8611	IN-862A		Radar Indicator	Honeywell	SEA Repair
3614477-8612	IN-862A		Radar Indicator	Honeywell	SEA Repair
400-015525-0101	RT-5000	5821-01-548-3924	Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-015525-0301	RT-5000		Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-015525-0501	RT-5000	5821-01-474-2550	Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-015525-2611	RT-5000		Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-015525-5011	RT-5000	5821-01-629-6382	Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-015525-5111	RT-5000		Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-015525-5711	RT-5000		Flexcomm II Transceiver	Cobham	OEM Dealer Repair
400-045500-0211	DMU		AFIS Plus DMU w/ Aero-C	Honeywell	OEM Dealer Repair
400-047153-8000	CD-5000		Control Display (NVG)	Cobham	OEM Dealer Repair
400-047252-0104	CVN-252		Nav Control Display	Cobham	OEM Dealer Repair
4000502-0101	RT-1201A	5841-01-007-2213	Radar Transceiver	Honeywell	SEA Repair
4000503-0201	IN-1202A	5895-01-01-3518	Radar Indicator	Honeywell	SEA Repair
4000503-0203	IN-1202A	5841-01-381-4565	Radar Indicator	Honeywell	SEA Repair
4000503-0204	IN-1202A		Radar Indicator	Honeywell	SEA Repair
4000503-0205	IN-1202A		Radar Indicator	Honeywell	SEA Repair
4000503-0241	IN-1202A		Radar Indicator	Honeywell	SEA Repair
4000503-0251	IN-1202A		Radar Indicator	Honeywell	SEA Repair
4000503-0253	IN-1202A		Radar Indicator	Honeywell	SEA Repair
4000504-0301	DA-1203A	5985-01-009-2872	Radar Antenna	Honeywell	SEA Repair
4000504-0302	DA-1203A		Radar Antenna	Honeywell	SEA Repair
4000504-0303	DA-1203A	5985-01-369-4387	Antenna Drive	Honeywell	SEA Repair
4000504-0306	DA-1203A		Radar Antenna	Honeywell	SEA Repair
4000525-1210	AA-1210A		10 inch Antenna Array	Honeywell	SEA Repair
4000525-1212	AA-1212A		Antenna Array	Honeywell	SEA Repair
4000525-1218	AA-1218A		Antenna Array	Honeywell	SEA Repair
4000525-4510	AA-4510		Antenna Array	Honeywell	SEA Repair
4000525-4512	AA-4512A		Antenna Array	Honeywell	SEA Repair
4000525-4518	AA-4518		Radar Antenna	Honeywell	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
4000525-5510	AA-5510		Radar Antenna Array	Honeywell	SEA Repair
4000525-5512	AA-5512A		Antenna Array	Honeywell	SEA Repair
4000763-3101	RT-131A	5841-01-544-8431	Radar Receiver/Transmitter	Honeywell	SEA Repair
4000764-3201	IN-132A		Radar Indicator	Honeywell	SEA Repair
4000790-4401	DA-144A		Radar Antenna	Honeywell	SEA Repair
4000790-4402	DA-144A		Radar Antenna	Honeywell	SEA Repair
4000790-4405	DA-144A		Radar Antenna	Honeywell	SEA Repair
4000790-4406	DA-144A		Radar Antenna	Honeywell	SEA Repair
4000831-0101	RT-1401A		Radar Receiver/Transmitter	Honeywell	SEA Repair
4000831-0102	RT-1401B		Radar Transceiver	Honeywell	SEA Repair
4000831-0103	RT-1401B	5821-01-268-3821	Radar Transceiver	Honeywell	SEA Repair
4000831-0105	RT-1401B		Radar Transceiver	Honeywell	SEA Repair
4000831-0106	RT-1401B	5841-01-363-2767	Radar Transceiver	Telephonics	SEA Repair
4000833-0201	IN-1402A		Radar Indicator	Honeywell	SEA Repair
4000833-0207	IN-1402B		Radar Indicator	Honeywell	SEA Repair
4000833-0208	IN-1402B		Radar Indicator	Honeywell	SEA Repair
4000833-0209	IN-1402B		Radar Indicator	Honeywell	SEA Repair
4000833-0210	IN-1402B		Radar Indicator	Honeywell	SEA Repair
4000833-0211	IN-1402B		Radar Indicator	Collins	SEA Repair
4000833-0212	IN-1402B		Radar Indicator	Collins	SEA Repair
4000946-5201	IN-152A	5826-01-141-9962	Monochrome Radar Indicator	Honeywell	SEA Repair
4000946-5202	IN-152A		Monochrome Radar Indicator	Honeywell	SEA Repair
4000964-0201	IN-1102A		Monochrome Radar Indicator	Honeywell	SEA Repair
4000965-0201	IN-1302A		Monochrome Radar Ind.	Honeywell	SEA Repair
4000965-0202	IN-1302A		Radar Indicator	Honeywell	SEA Repair
4000965-0203	IN-1302A		Radar Indicator	Honeywell	SEA Repair
4000965-0207	IN-1302A		Radar Indicator	Honeywell	SEA Repair
4000966-0101	RT-1301A		Radar Transceiver	Honeywell	SEA Repair
4000966-0103	RT-1301B		Radar Receiver/Transmitter	Honeywell	SEA Repair
4000966-0109	RT-1301B		Radar Transceiver	Honeywell	SEA Repair
4001018-6101	ART-161A		Radar Transceiver	Honeywell	SEA Repair
4001018-6102	ART-161A		Radar Transceiver (10\)"	Honeywell	SEA Repair
4001018-6103	ART-161A		Radar Transceiver	Honeywell	SEA Repair
4001018-6104	ART-161A		Radar Antenna/RT	Honeywell	SEA Repair
4001018-6105	ART-161A		Radar Transceiver	Honeywell	SEA Repair
4001018-6106	ART-161A		Radar Transceiver	Honeywell	SEA Repair
4001018-6107	ART-161A		Radar Transceiver	Honeywell	SEA Repair
4001018-6108	ART-161A		Radar Transceiver	Honeywell	SEA Repair
4001098-0201	IN-1202B		Monochrome Radar Indicator	Honeywell	SEA Repair
4001098-0203	IN-1202B		Monochrome Radar Indicator	Honeywell	SEA Repair
4001098-0204	IN-1202B		Monochrome Radar Indicator	Honeywell	SEA Repair
4001098-0205	IN-1202B		Radar Indicator	Honeywell	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
4001291-2101	IN-2021A		Color Radar Indicator	Honeywell	SEA Repair
4001291-2102	IN-2021A		Color Radar Indicator	Honeywell	SEA Repair
4001291-2103	IN-2021A		Color Radar Indicator	Honeywell	SEA Repair
4001291-2104	IN-2021A		Color Radar Indicator	Honeywell	SEA Repair
4001294-2601	IN-2026A		Color Radar Indicator	Honeywell	SEA Repair
4001294-2602	IN-2026A		Color Radar Indicator	Telephonics	SEA Repair
4001294-2604	IN-2026A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2701	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2702	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2703	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2704	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2705	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2706	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2707	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001295-2708	IN-2027A		Color Radar Indicator	Honeywell	SEA Repair
4001373-2201	IN-2022A		Color Radar Indicator	Honeywell	SEA Repair
4001373-2203	IN-2022A		Color Radar Indicator	Honeywell	SEA Repair
4001373-2204	IN-2022A		Color Radar Indicator	Honeywell	SEA Repair
4001373-2205	IN-2022A		Color Radar Indicator	Honeywell	SEA Repair
4001670-2501	IN-2025A	6625-01-411-1222	Color Radar Indicator	Honeywell	SEA Repair
4001670-2502	IN-2025A		Color Radar Indicator	Telephonics	SEA Repair
4001670-2503	IN-2025A		Color Radar Indicator	Honeywell	SEA Repair
4001670-2504	IN-2025A		Color Radar Indicator	Honeywell	SEA Repair
4001670-2511	IN-2025B	5841-01-267-5932	Color Radar Indicator	Honeywell	SEA Repair
4001670-2512	IN-2025B		Color Radar Indicator	Honeywell	SEA Repair
4001670-2513	IN-2025B	5841-01-544-8436	Color Radar Indicator	Honeywell	SEA Repair
4001670-2514	IN-2025B		Color Radar Indicator	Honeywell	SEA Repair
4001846-3201	IN-232A	5895-01-428-6776	Color Radar Indicator	Honeywell	SEA Repair
4001846-3203	IN-232A		Radar Indicator	Honeywell	SEA Repair
4001846-3205	IN-232A		Radar Indicator	Honeywell	SEA Repair
4001921-5101	RT-1151A		Radar Transceiver	Honeywell	SEA Repair
4004437-901	RT-220	5841-01-003-1964	Radio Altimeter R/T	Honeywell	SEA Repair
4004437-902	RT-221		Radio Altimeter	Honeywell	SEA Repair
4004437-903	RT-220H		Rad. Alt. R/T	Honeywell	SEA Repair
4004444-901	RA-210		Radio Altimeter Indicator	Honeywell	SEA Repair
4006719-904	SM-200A		Servo	Honeywell	SEA Exchange
4006719-906	SM-200A	6615-01-141-6344	Servo Drive	Honeywell	SEA Exchange
4006719-910	SM-200A	6615-01-141-6345	Servo Motor	Honeywell	SEA Exchange
4006719-912	SM-200	6615-01-005-1867	Servo Drive	Honeywell	SEA Exchange
4006719-914	SM-200		Servo Drive	Honeywell	SEA Exchange
4006719-926	SM-200	6615-01-424-3655	Servo Drive	Honeywell	SEA Exchange
4006719-933	SM-200		Servo Drive	Honeywell	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
4006719-942	SM-200A		Servo Drive	Honeywell	SEA Exchange
4006719-944	SB-200A		Servo Drive	Honeywell	SEA Exchange
4006719-956	SB-200A		Servo Drive	Honeywell	SEA Exchange
4011026-902	SPZ-200	6615-01-141-6348	Engage Controller	Honeywell	OEM Dealer Repair
4011049-901	MC-201	6615-01-141-6349	Manual Controller	Honeywell	OEM Dealer Repair
4012373-901			Linear Actuator	Honeywell	OEM Dealer Repair
4012373-905	SM-710	1680-01-255-7920	Actuator	Honeywell	OEM Dealer Repair
4012373-906	SM-710		Actuator	Honeywell	OEM Dealer Repair
4012373-907	SM-710		Actuator	Honeywell	OEM Dealer Repair
4013241-931	AZ-241		Air Data Computer	Honeywell	SEA Exchange
4014267-901	RA-215		Radio Altimeter Indicator	Honeywell	SEA Repair
4018285-903	AL-245		Altitude Alerter	Honeywell	OEM Dealer Repair
4018285-904	AL-285		ALT Alert Controller	Honeywell	OEM Dealer Repair
4018368-902	MS-500		Mode Selector	Honeywell	OEM Dealer Repair
4018368-906	MS-500		Mode Selector	Honeywell	OEM Dealer Repair
4018368-924	MS-500		Mode Selector	Honeywell	OEM Dealer Repair
4018369-902	FZ-500		Flight Director Computer	Honeywell	OEM Dealer Repair
4018369-903	FZ-500		Flight Director Computer	Honeywell	OEM Dealer Repair
4018369-905	FZ-500	6610-01-121-4917	Flight Director Computer	Honeywell	SEA Exchange
4018639-901	PC-500		Autopilot Controller	Honeywell	SEA Exchange
4018639-902	PC-500		Autopilot Control	Honeywell	OEM Dealer Repair
4018639-903	PC-500		Autopilot Control	Honeywell	SEA Exchange
4018639-904	PC-500	6615-01-292-7101	Autopilot Controller	Honeywell	SEA Exchange
4018639-906	PC-500		Autopilot Controller	Honeywell	SEA Exchange
4018639-907	PC-500		Autopilot Controller	Honeywell	SEA Exchange
4018639-909	PC-500		Autopilot Controller	Honeywell	OEM Dealer Repair
4018639-912	PC-500		Autopilot Control	Honeywell	SEA Exchange
4018639-924	PC-500	6615-01-424-3656	Autopilot Controller	Honeywell	SEA Exchange
4018639-930	PC-500		Autopilot Controller	Honeywell	SEA Exchange
4018639-933	PC-500		Autopilot Controller	Honeywell	SEA Exchange
4019286-901	VG-14H	6615-01-329-9596	Vertical Gyro	Honeywell	SEA Exchange
4019286-903	VG-14H		Vertical Gyro	Honeywell	SEA Exchange
4020501-590	GH-14		Gyro Horizon Indicator	Honeywell	SEA Exchange
4020531-574	GH-14		Gyro Horizon Indicator	Honeywell	SEA Exchange
4020577-3	C-14D	6610-01-320-4343	Directional Gyro	Honeywell	SEA Exchange
4020936-901	TARSYNH		3 Axis Reference	Honeywell	SEA Exchange
4020936-904	TARSYN H		3 Axis Reference Gyro	Honeywell	SEA Exchange
4021541-671	GH-14		Horizon Gyro	Honeywell	SEA Exchange
4023400-0503	RT-859A/APX-72	5841-00-068-1555	IFF Transponder	Honeywell	SEA Exchange
4025008-901	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-902	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-908	SP-711	6610-01-394-1071	Helipilot Computer	Honeywell	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
4025008-910	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-911	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-912	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-915	SP-711		Helipilot Computer	Honeywell	OEM Dealer Repair
4025008-916	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-918	SP-711		Helipilot Computer	Honeywell	OEM Dealer Repair
4025008-920	SP-711		Helipilot Computer	Honeywell	OEM Dealer Repair
4025008-922	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-923	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4025008-924	SP-711		Helipilot Computer	Honeywell	SEA Exchange
4029377-918	SP-600		Autopilot Computer	Honeywell	OEM Dealer Repair
4029516-520	ZC-220		Flight Director Computer	Honeywell	OEM Dealer Repair
4030182-901	AC-702	6610-01-597-8219	Altitude Sensor	Honeywell	OEM Dealer Repair
4030182-903	AC-702		Altitude Sensor	Honeywell	SEA Exchange
4033089-901	FZ-702	6610-01-485-8970	Flight Director Computer	Honeywell	OEM Dealer Repair
418-00475-600	418-00475-600		Module	SFIM	SEA Exchange
418-00487-400	418-00487-400		Computer	SFIM	SEA Exchange
430-0270-500	MX-20		Multifunction Display	Garmin	OEM Dealer Repair
430-0270-502	MX-20		Multifunction Display	Garmin	OEM Dealer Repair
430-0270-601	MX-20		Multi-Function Display w/ Traffic	Garmin	OEM Dealer Repair
430-0270-700	MX-20		Multi-Function Display w/ Radar Card	Garmin	OEM Dealer Repair
430-0270-701	MX-20		Traffic/Radar Multifunction Display	Garmin	OEM Dealer Repair
430-6040-203	SL-40		VHF Comm	Garmin	OEM Dealer Repair
430-6040-300	SL-30		Nav/Comm	Garmin	OEM Dealer Repair
430-6040-302	SL-30		Nav/Comm	Garmin	OEM Dealer Repair
430-6040-303	SL-30		Nav/Comm Slim Line	Garmin	OEM Dealer Repair
430-6040-600	SL-60		GPS/Comm	Garmin	OEM Dealer Repair
430-6040-800	SL-40		GPS/Comm (Unit Only)	Garmin	OEM Dealer Repair
430-6050-201	GX-55		GPS Receiver	Garmin	OEM Dealer Repair
430-6050-202	GX-55		GPS Receiver	Garmin	OEM Dealer Repair
430-6050-400	GX-50		IFR GPS Receiver	Garmin	OEM Dealer Repair
430-6050-401	GX-50		IFR GPS Receiver	Garmin	OEM Dealer Repair
430-6050-403	GX-50		IFR GPS	Garmin	OEM Dealer Repair
430-6050-600	GX-60		IFR GPS/Comm	Garmin	OEM Dealer Repair
430-6050-601	GX-60		GPS/Comm Receiver	Garmin	OEM Dealer Repair
430-6050-603	GX-60		IFR GPS/Comm	Garmin	OEM Dealer Repair
430-6067-100	SL-70R		Remote Transponder	Garmin	OEM Dealer Repair
430-6100-800-001	CNX-80		GPS/WAAS/NAV/COM	Garmin	OEM Dealer Repair
430-6100-800-002	GNS-480		GPS/WAAS/NAV/COM	Garmin	SEA Repair
453-5000	C406-2	5821-01-458-4894	ELT (Transmitter Only)	Artex	SEA Repair
453-5001	C406-2HM	5826-01-561-2911	ELT (Transmitter Only)	Artex	SEA Repair
453-5002	C406-1	6610-01-568-5241	ELT	Artex	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
453-5003	C406-1HM		ELT (Transmitter Only)	Artex	SEA Repair
453-5004	B406-4	5821-01-579-2726	ELT (Transmitter Only)	Artex	SEA Repair
453-5004-999	B406-4		ELT (Transmitter Only) - User Program	Artex	SEA Repair
453-5012	G406-4		ELT	Artex	OEM Dealer Repair
453-5060	C406-N	5821-01-561-9503	ELT	Artex	OEM Dealer Repair
453-5061	C406-NHM	6610-01-553-8726	ELT	Artex	OEM Dealer Repair
453-5100	G406-1		ELT Transmitter	Artex	SEA Repair
453-6500	453-6500	5821-01-561-2912	ELT to Nav Interface	Artex	SEA Repair
453-6603	ME406		Emergency Locator Transmitter	Artex	SEA Repair
453-6604	ME-406HM		ELT Main Assembly	Artex	SEA Repair
453-6611	ME406P	5820-01-631-4791	ELT Main Assembly	Artex	SEA Repair
453-9703		5930-01-552-6982	NVP Remote Switch (Black)	Artex	OEM Dealer Repair
455-5003	C406-1HM		C406-1HM Base Pack List	Artex	OEM Dealer Repair
455-5016	C406-1HM		ELT (406 MHz) w/ 110-338 Antenna	Artex	OEM Dealer Repair
455-5044	G406-4		ELT w/ 110-324 and 110-329 Whip Antenna	Artex	OEM Dealer Repair
455-6605	ME406		ELT System w/ 110-773 Whip Antenna	Artex	OEM Dealer Repair
455-9100		6625-21-912-5966	ELT Test Set	Artex	OEM Dealer Repair
501-1075-02	PS-823B		Emergency Power Supply	L3 Communications	SEA Exchange
501-1105-03	AI-804J/B	6615-01-114-9281	Attitude Gyro	L3 Communications	SEA Exchange
501-1105-04	AI-804J/G		Standby Att. Indicator	L3 Communications	SEA Exchange
501-1148-01	SI-2500B	6130-01-036-4447	Static Inverter	L3 Communications	SEA Exchange
501-1197-05	AI-804R	6610-01-284-0009	Attitude Indicator	L3 Communications	SEA Exchange
501-1197-08	AI-804U	6610-01-152-2821	Attitude Gyro	L3 Communications	SEA Exchange
501-1204-01	VG-206D		Vertical Gyro	L3 Communications	SEA Exchange
501-1210-01	VG-208C	6615-01-516-1072	Vertical Gyro	L3 Communications	SEA Exchange
501-1224-02	VG-204Z		76600-02113-102 - Vertical Gyro	L3 Communications	SEA Exchange
501-1228-03	PS-835C	6130-01-554-3168	Emergency Power Supply	L3 Communications	SEA Repair
501-1228-04	PS-835D	6130-01-219-8285	Emergency Power Supply	L3 Communications	SEA Repair
501-1228-06	PS-835F	6130-01-594-9809	Emergency Power Supply	L3 Communications	SEA Exchange
501-1240-01	SI-100A		Static Inverter for PS-835 - 3 Phase	L3 Communications	SEA Exchange
501-1296-04	AI-804AF		Attitude Indicator	L3 Communications	SEA Exchange
501-1296-06	AI-804BA		Attitude Indicator	L3 Communications	SEA Exchange
501-1318-01	SC-841A	1560-01-371-0029	DC-DC Converter for PS-835	L3 Communications	SEA Exchange
501-1453-01	VG-204AB	6615-01-492-5112	Vertical Gyro	L3 Communications	SEA Exchange
501-1568-10	AI-330K		Attitude Indicator	L3 Communications	SEA Exchange
501-1682-01	PS-834A		Power Supply - 0.5 AMP - 5 VDC Output	L3 Communications	SEA Exchange
501-1712-01	PS-855A		Emergency Power Supply - 2.5 Amp - 5 Vdc Output	L3 Communications	SEA Repair
501-1712-02	PS-855B	6130-01-482-8530	Emergency Power Supply - 5.0 Amp - 5 Vdc Output	L3 Communications	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
501-1712-03	PS-855C	6130-01-506-2360	Emergency Power Supply - 2.5 Amp - Short Circuit Protection	L3 Communications	SEA Repair
501-1712-04	PS-855D		Emergency Power Supply - 5.0 Amp - Short Circuit Protection	L3 Communications	SEA Repair
501-1719-01	PS-850A		Emergency Power Supply - 2.5 Amp	L3 Communications	SEA Repair
501-1719-02	PS-850B		Emergency Power Supply - 5.0 Amp	L3 Communications	SEA Repair
504-0017-901	510-1A		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0017-909	510-8A		Attitude Gyro	Symetrics	SEA Exchange
504-0017-913	510-17A		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0017-916	510-8B		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0017-917	510-8C		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0017-926	510-1G		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0021-904	500E		Horizon Gyro	Symetrics	SEA Exchange
504-0030-913	510-24N		Attitude Gyro (4-inch)	Symetrics	SEA Exchange
504-0032-902	505-2B		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0032-912	505-2BS	6615-01-433-5987	Attitude Gyro (3-inch) - 28VDC	Symetrics	SEA Exchange
504-0033-930	305-2BL		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0033-933	305-2BC		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0035-902	520-1AG		Attitude Indicator	Symetrics	SEA Exchange
504-0035-903	520-1B	6605-01-382-4868	Attitude Indicator	Symetrics	SEA Exchange
504-0035-904	520-1BG		Attitude Indicator	Symetrics	SEA Exchange
504-0035-907	520-2B		Attitude Indicator	Symetrics	SEA Exchange
504-0035-921	520-9B		Attitude Indicator	Symetrics	SEA Exchange
504-0035-922	520-10B		Attitude Indicator	Symetrics	SEA Exchange
504-0038-906	510-30C		Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0041-902	510-31B		Attitude Gyro (4-inch)	Symetrics	SEA Exchange
504-0045-901	510-35A	6610-01-595-1027	Attitude Gyro (3-inch)	Symetrics	SEA Exchange
504-0111-906	1100-28(0)CES		Attitude Indicator	Symetrics	SEA Exchange
504-0111-914	1100-28L(8F)		Attitude Indicator	Symetrics	SEA Exchange
504-0111-928	1100-28LS(7F)		Attitude Indicator	Symetrics	SEA Exchange
504-0111-930	1100-28LS(15F)		Attitude Indicator	Symetrics	SEA Exchange
504-0121-901	1200-1R(0D)		Attitude Indicator	Symetrics	SEA Exchange
504-0122-906	1200-2FS(15D)		Attitude Indicator	Symetrics	SEA Exchange
504-5612-003	37P-2		Glideslope Antenna	Collins	SEA Repair
505-0001-920	200-10				SEA Repair
505-0002-916	200-10DC(14)				SEA Repair
505-0008-907	200-10BL				SEA Repair
505-0010-901	200DC(BELL)		DIRECTIONAL GYRO	AIM	SEA Repair
505-0010-902	200DCL(28)		DIRECTIONAL GYRO	AIM	SEA Repair
505-0010-904	200DCFM		DIRECTIONAL GYRO	AIM	SEA Repair
505-0031-904	205-1BL		Directional Gyro	Symetrics	SEA Exchange
505-0032-901	210-17A	6615-01-352-4996	Directional Gyro	Symetrics	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
506-0003-902	P-20A		Inverter (28VDC to 26/115VAC)	L3 Communications	SEA Repair
506-0004-901	P-21		Inverter (14VDC to 26/115VAC)	L3 Communications	SEA Repair
520-3137-304	3137LB63C		RMI	Aeronetics	SEA Exchange
520-3137-307	3137LB21C		RMI	Aeronetics	SEA Exchange
520-5160-006	CDI-5160L-EO/B	6610-01-416-2738	Course Selector Indicator	Aeronetics	SEA Exchange
522-0027-003	37P-3		Glideslope Antenna	Collins	SEA Repair
522-0027-113	37P-3		Glideslope Antenna	Collins	SEA Repair
522-0688-003	37P-4	5826-00-539-7458	Glideslope Antenna	Collins	SEA Repair
522-0688-013	37P-4	5985-00-495-4876	Glideslope Antenna	Collins	SEA Repair
522-0688-063	37P-4	5985-00-688-8586	Glideslope Antenna	Collins	SEA Repair
522-0688-103	37P-4		Glideslope Antenna	Collins	SEA Repair
522-0688-123	37P-4		Glideslope Antenna	Collins	SEA Repair
522-0688-133	37P-4		Glideslope Antenna	Collins	SEA Repair
522-0688-163	37P-4		Glideslope Antenna	Collins	SEA Repair
522-0688-183	37P-4		Glideslope Antenna	Collins	SEA Repair
522-0688-186	37P-4		Glideslope Antenna	Collins	SEA Repair
522-0700-003	37P-5	5826-00-861-8984	Glideslope Antenna	Collins	SEA Repair
522-0700-023	37P-5	5826-00-861-8984	Glideslope Antenna	Collins	SEA Repair
522-0700-043	37P-5		Glideslope Antenna	Collins	SEA Repair
522-0854-003	37X-2	5985-00-523-1044	Marker Beacon Antenna	Collins	SEA Repair
522-0854-013	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-023	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-043	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-053	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-063	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-064	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-065	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-066	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-067	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-0854-068	37X-2		Marker Beacon Antenna	Collins	SEA Repair
522-1135-011	37R-2		VHF Comm Antenna	Collins	SEA Repair
522-1135-012	37R-2	5985-01-080-8452	VHF Comm Antenna	Collins	SEA Repair
522-1136-011	137X-1	5985-00-801-4671	Nav/Comm Antenna	Collins	SEA Repair
522-1400-00	341C-1	6110-00-482-0552	RMI Servo Amp	Collins	SEA Repair
522-1400-000	341C-1		RMI Servo Amp	Collins	SEA Repair
522-2447-205	313N-2		Nav/Comm Control	Collins	SEA Repair
522-2447-215	313N-2	5826-01-077-7047	Nav Control	Collins	SEA Repair
522-2447-235	313N-2D		Control	Collins	SEA Repair
522-2447-250	313N-2D	5825-01-044-1407	Nav/Comm Control	Collins	SEA Repair
522-2447-251	313N-2D	5821-01-090-2847	Nav Control	Collins	SEA Repair
522-2447-252	313N-2	5895-01-099-8589	Nav Control	Collins	SEA Repair
522-2447-256	313N-2D	5895-01-416-2525	Nav/Comm Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
522-2447-260	313N-2D		Nav/Comm Control	Collins	SEA Repair
522-2447-262	313N-2	5821-01-503-5826	Control	Collins	SEA Repair
522-2447-264	313N-2D	5895-01-416-2524	Radio Set Control	Collins	SEA Repair
522-2447-563	313N-2D	5895-01-220-0603	Nav/Com Control	Collins	SEA Repair
522-2447-564	313N-2D	5825-01-416-0163	Radio Set Control	Collins	SEA Repair
522-2448-015	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-025	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-035	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-045	313N-3	6615-00-413-1354	Nav/Comm Control	Collins	SEA Repair
522-2448-055	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-056	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-057	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-059	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-060	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-061	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-063	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-065	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-066	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-067	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-069	313N-3	5826-00-404-0244	Nav/Comm Control	Collins	SEA Repair
522-2448-072	313N-3	5826-00-134-5967	Nav/Comm Control	Collins	SEA Repair
522-2448-073	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-074	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-075	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-205	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-215	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-235	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-245	313N-3	5826-01-548-2213	Nav/Comm Control	Collins	SEA Repair
522-2448-255	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-256	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-258	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-259	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-260	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-261	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-263	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-265	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-266	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-267	313N-3D	4920-01-302-0988	Nav/Comm Control	Collins	SEA Repair
522-2448-269	313N-3		Nav/Comm Control	Collins	SEA Repair
522-2448-272	313N-3	5826-01-351-2143	Nav/Comm Control	Collins	SEA Repair
522-2448-274	313N-3D		Nav/Comm Control	Collins	SEA Repair
522-2448-276	313N-3D	5826-01-126-5643	Nav/Comm Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
522-2572-002	37R-2U	5985-00-892-0895	UHF/VHF Antenna	Collins	SEA Repair
522-2599-000	313N-5		VHF Comm Control	Collins	SEA Repair
522-2599-001	313N-5	5820-00-480-3247	VHF Comm Control	Collins	SEA Repair
522-2599-002	313N-5	5826-01-136-7854	VHF Comm Control	Collins	SEA Repair
522-2599-003	313N-5		VHF Comm Control	Collins	SEA Repair
522-2599-004	313N-5		VHF Comm Control	Collins	SEA Repair
522-2599-500	313N-5	5826-01-548-2167	VHF Comm Control	Collins	SEA Repair
522-2599-501	313N-5	5820-01-293-4170	VHF Comm Control	Collins	SEA Repair
522-2599-502	313N-5	5826-01-170-8326	VHF Comm Control	Collins	SEA Repair
522-2599-503	313N-5		VHF Comm Control	Collins	SEA Repair
522-2599-504	313N-5		VHF Comm Control	Collins	SEA Repair
522-2638-000	331A-3G		Flight Control System	Collins	SEA Repair
522-2638-001	331A-3G	6610-01-100-8063	HSI	Collins	SEA Repair
522-2638-002	331A-3G		Flight Control System	Collins	SEA Repair
522-2638-003	331A-3G		HSI	Collins	SEA Repair
522-2638-005	331A-3G		Flight Control System	Collins	SEA Repair
522-2638-006	331A-3G	5826-01-013-0734	HSI	Collins	SEA Repair
522-2638-007	331A-3G		HSI	Collins	SEA Repair
522-2638-008	331A-3G		HSI	Collins	SEA Repair
522-2638-009	331A-3G		HSI	Collins	SEA Repair
522-2638-010	331A-3G		HSI	Collins	SEA Repair
522-2644-001	328A-3G		Slaving Accessory	Collins	SEA Repair
522-2644-011	328A-3G	6605-01-360-2983	Slaving Amp	Collins	SEA Repair
522-2644-013	328A-3G		Slaving Accessory/Amp	Collins	SEA Repair
522-2646-000	37R-2A		VHF Comm Antenna	Collins	SEA Repair
522-2646-014	37R-2A		VHF Comm Antenna	Collins	SEA Repair
522-2866-00	356C-4	5895-00-811-6818	Isolation Amplifier	Collins	SEA Repair
522-2866-000	356C-4	5996-00-876-3164	Isolation Amplifier	Collins	SEA Repair
522-2867-00	356F-3		Amplifier	Collins	SEA Repair
522-2867-000	356F-3	5820-00-936-6928	Amplifier	Collins	SEA Repair
522-2899-00	387C-4		Audio Control	Collins	SEA Repair
522-2899-000	387C-4		Audio Control	Collins	SEA Repair
522-2899-012	387C-4		Audio Control	Collins	SEA Repair
522-2899-013	387C-4		Audio Control	Collins	SEA Repair
522-3082-00	331A-3F		HSI	Collins	SEA Repair
522-3082-000	331A-3F		Course Indicator	Collins	SEA Repair
522-3082-001	331A-3F	5826-01-369-5455	HSI	Collins	SEA Repair
522-3082-002	331A-3F		HSI	Collins	SEA Repair
522-3241-00	3.32E-02		Directional Gyro	Collins	SEA Repair
522-3241-000	3.32E-02		Directional Gyro	Collins	SEA Repair
522-3306-00	331H-3G		Course Indicator	Collins	SEA Repair
522-3306-000	331H-3G	5826-01-131-6622	Course Indicator	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
522-3306-001	331H-3G		Course Indicator	Collins	SEA Repair
522-3306-011	331H-3G	5826-00-404-0245	Course Indicator	Collins	SEA Repair
522-3306-014	331H-3G	5826-01-082-8168	Course Indicator	Collins	SEA Repair
522-3614-000	313N-4B	5826-00-226-5163	VHF Control	Collins	SEA Repair
522-3614-001	313N-4B		VHF Control	Collins	SEA Repair
522-3614-003	313N-4B		VHF Control	Collins	SEA Repair
522-3614-004	313N-4B		VHF Control	Collins	SEA Repair
522-3614-200	313N-4B	5985-01-127-0095	VHF Control	Collins	SEA Repair
522-3614-203	313N-4B	5826-01-006-0983	VHF Control	Collins	SEA Repair
522-3614-205	313N-4B		VHF Control	Collins	SEA Repair
522-3614-206	313N-4B	5826-01-136-7853	VHF Control	Collins	SEA Repair
522-3614-300	313N-4B	5826-00-346-7286	VHF Control	Collins	SEA Repair
522-3614-500	313N-4B	5895-01-252-5810	Nav Control	Collins	SEA Repair
522-3614-503	313N-4B	5826-01-212-2145	Nav Control	Collins	SEA Repair
522-3614-506	313N-4B	5826-01-136-7853	Radio Control Set	Collins	SEA Repair
522-3615-001	313N-4C		VHF Control	Collins	SEA Repair
522-3615-002	313N-4C		VHF Control	Collins	SEA Repair
522-3615-003	313N-4C		VHF Control	Collins	SEA Repair
522-3615-005	313N-4C		VHF Control	Collins	SEA Repair
522-3615-201	313N-4C	5820-01-129-6009	VHF Control	Collins	SEA Repair
522-3615-202	313N-4C		VHF Control	Collins	SEA Repair
522-3615-205	313N-4C		VHF Control	Collins	SEA Repair
522-3616-000	313N-4D		VHF Control	Collins	SEA Repair
522-3616-200	313N-4D		VHF Control	Collins	SEA Repair
522-3616-201	313N-4D	5820-01-129-6009	VHF Control	Collins	SEA Repair
522-3616-202	313N-4D	5895-01-422-0954	VHF Control	Collins	SEA Repair
522-3616-204	313N-4D	5826-01-214-3403	VHF Control	Collins	SEA Repair
522-3616-501	313N-4D	5820-01-548-2162	Nav Control	Collins	SEA Repair
522-3616-502	313N-4D	5895-01-422-0954	Nav Control	Collins	SEA Repair
522-3616-503	313N-4D	5826-01-494-9467	Nav Control	Collins	SEA Repair
522-3616-504	313N-4D	5826-01-384-4305	Nav Control	Collins	SEA Repair
522-3617-00	313N-5A		VHF Comm Control	Collins	SEA Repair
522-3617-000	313N-5A		VHF Comm Control	Collins	SEA Repair
522-3617-001	313N-5A		VHF Comm Control	Collins	SEA Repair
522-3617-002	313N-5A		VHF Comm Control	Collins	SEA Repair
522-3617-003	313N-5A	5895-01-152-0416	VHF Comm Control	Collins	SEA Repair
522-3617-500	313N-5A	5826-01-146-5430	VHF Comm Control	Collins	SEA Repair
522-3763-001	346B-3	5895-01-013-0719	Audio Control	Collins	SEA Repair
522-3763-002	346B-3	5821-01-008-7445	Audio Control	Collins	SEA Repair
522-3763-003	346B-3		Audio Control	Collins	SEA Repair
522-4114-002	339H-1	1680-01-481-5724	Radio Altimeter Indicator	Collins	SEA Repair
522-4114-003	339H-1	5841-00-758-4547	Radio Altimeter Indicator	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
522-4114-004	339H-1		Radio Altimeter Indicator	Collins	SEA Repair
522-4114-006	339H-1		Radio Altimeter Indicator	Collins	SEA Repair
522-4114-008	339H-1		Radio Altimeter Indicator	Collins	SEA Repair
522-4114-010	339H-1	5841-00-134-5975	Radio Altimeter Indicator	Collins	SEA Repair
522-4114-012	339H-1	5841-01-012-2184	Radio Altimeter Indicator	Collins	SEA Repair
522-4140-001	437X-1	5985-00-758-4548	Rad. Alt. Ant.	Collins	SEA Repair
522-4140-002	437X-1		Antenna	Collins	SEA Repair
522-4140-003	437X-1		Radio Altimeter Antenna	Collins	SEA Repair
522-4140-004	437X-1		Radio Altimeter Antenna	Collins	SEA Repair
522-4140-005	437X-1		Radio Altimeter Antenna	Collins	SEA Repair
522-4140-006	437X-1	5985-00-758-4548	Radio Altimeter Antenna	Collins	SEA Repair
522-4140-007	437X-1		Rad Alt Antenna	Collins	SEA Repair
522-4255-001	437X-1A	5985-00-088-8562	Radio Altimeter Antenna	Collins	SEA Repair
522-4255-002	437X-1A		Radio Altimeter Antenna	Collins	SEA Repair
522-4255-003	437X-1A		Radio Altimeter Antenna	Collins	SEA Repair
522-4255-004	437X-1A		Radio Altimeter Antenna	Collins	SEA Repair
522-4255-005	437X-1A		Radio Altimeter Antenna	Collins	SEA Repair
522-4255-006	437X-1A		Radio Altimeter Antenna	Collins	SEA Repair
522-4255-007	437X-1A		Radio Altimeter Antenna	Collins	SEA Repair
522-4363-002	339H-1B		Radio Altimeter Indicator	Collins	SEA Repair
522-4363-004	339H-1B		Radio Altimeter Indicator	Collins	SEA Repair
522-4363-007	339H-1B		Radio Altimeter Indicator	Collins	SEA Repair
522-4625-001	339H-1D		Radio Altimeter Indicator	Collins	SEA Repair
522-4825-001	339H-2		Rad. Alt. Indicator	Collins	SEA Repair
522-4825-002	339H-2		Radio Altitude Indicator	Collins	SEA Repair
522-4825-004	339H-2	5826-01-197-9611	Altitude Indicator	Collins	SEA Repair
522-4825-005	339H-2		Radio Altitude Indicator	Collins	SEA Repair
522-4825-006	339H-2		Radio Altitude Indicator	Collins	SEA Repair
522-4825-007	339H-2		Radio Altitude Indicator	Collins	SEA Repair
522-4825-008	339H-2		Radio Altimeter Indicator	Collins	SEA Repair
522-4825-011	339H-2		Radio Altitude Indicator	Collins	SEA Repair
522-4945-001	323A-2G	5895-01-013-0720	Flux Detector	Collins	SEA Repair
622-0171-001	339H-3		Radio Altimeter Indicator	Collins	SEA Repair
622-0171-002	339H-3	5841-01-306-8407	Radio Altimeter Indicator	Collins	SEA Repair
622-0555-001	332C-10		RMI	Collins	SEA Repair
622-0555-002	332C-10		RMI	Collins	SEA Repair
622-0555-003	332C-10	5820-01-111-5097	RMI	Collins	SEA Repair
622-0555-004	332C-10		RMI	Collins	SEA Repair
622-0555-005	332C-10		RMI	Collins	SEA Repair
622-0555-006	332C-10		RMI	Collins	SEA Repair
622-0555-007	332C-10		RMI	Collins	SEA Repair
622-0555-008	332C-10		RMI	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-0555-010	332C-10		RMI	Collins	SEA Repair
622-0555-011	332C-10		RMI	Collins	SEA Repair
622-0876-001	VIR-30A	5895-01-014-1704	Nav Receiver	Collins	SEA Repair
622-0876-002	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-004	VIR-30A	5826-01-359-9930	Nav Receiver	Collins	SEA Repair
622-0876-011	VIR-30A	5826-01-309-9786	Nav Receiver	Collins	SEA Repair
622-0876-012	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-013	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-014	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-201	VIR-30A		Navigation Receiver	Collins	SEA Repair
622-0876-202	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-204	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-211	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-212	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0876-214	VIR-30A		Nav Receiver	Collins	SEA Repair
622-0877-001	VIR-30M		Navigation Receiver	Collins	SEA Repair
622-0877-002	VIR-30M		Navigation Receiver	Collins	SEA Repair
622-0877-004	VIR-30M		Navigation Receiver	Collins	SEA Repair
622-0877-201	VIR-30M		Nav Receiver	Collins	SEA Repair
622-0954-001	437X-1B	5985-01-013-0721	Radar Altimeter Antenna	Collins	SEA Repair
622-0954-002	437X-1B		Radar Altimeter Antenna	Collins	SEA Repair
622-0965-002	334D-6		Trim Servo	Collins	SEA Exchange
622-0965-004	334D-6		Trim Servo	Collins	SEA Exchange
622-1032-001	699Z-1	5826-01-081-8411	RMI Adapter	Collins	SEA Repair
622-1204-001	339H-4		Radio Altimeter Indicator	Collins	SEA Repair
622-1204-002	339H-4		Radio Altimeter Indicator	Collins	SEA Repair
622-1204-003	339H-4	5841-01-014-1674	Radio Altimeter Indicator	Collins	SEA Repair
622-1204-004	339H-4	5841-01-481-4513	Radio Altimeter Indicator	Collins	SEA Repair
622-1204-005	339H-4		Radar Altimeter Indicator	Collins	SEA Repair
622-1204-006	339H-4		Radar Altimeter Indicator	Collins	SEA Repair
622-1204-007	339H-4		Radio Altimeter Indicator	Collins	SEA Repair
622-1204-008	339H-4	5841-01-074-7165	Radar Altimeter Indicator	Collins	SEA Repair
622-1204-010	339H-4		Radio Altimeter Indicator	Collins	SEA Repair
622-1205-001	339H-4A		Radio Altimeter Indicator	Collins	SEA Repair
622-1205-002	339H-4A		Radio Altimeter Indicator	Collins	SEA Repair
622-1205-003	339H-4A	5841-01-611-4506	Radio Altimeter Indicator	Collins	SEA Repair
622-1205-004	339H-4A		Radio Altimeter Indicator	Collins	SEA Repair
622-1205-005	339H-4A		Radio Altimeter Indicator	Collins	SEA Repair
622-1205-006	339H-4A		Radio Altimeter Indicator	Collins	SEA Repair
622-1233-001	DME-40	5826-01-008-0927	DME Transceiver	Collins	SEA Repair
622-1234-001	339F-12		DME Indicator	Collins	SEA Repair
622-1234-002	339F-12	5841-01-013-0820	DME Indicator	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-1234-003	339F-12		DME Indicator	Collins	SEA Repair
622-1234-004	339F-12		DME Indicator	Collins	SEA Repair
622-1234-005	339F-12		DME Indicator	Collins	SEA Repair
622-1234-007	339F-12		DME Indicator	Collins	SEA Repair
622-1234-012	339F-12	5841-01-093-6982	DME Indicator	Collins	SEA Repair
622-1234-013	339F-12	5826-01-107-5511	DME Indicator	Collins	SEA Repair
622-1234-016	339F-12		DME Indicator	Collins	SEA Repair
622-1234-017	339F-12		DME Indicator	Collins	SEA Repair
622-1234-103	339F-12		DME Indicator	Collins	SEA Repair
622-1234-113	339F-12	5826-01-416-6656	DME Indicator	Collins	SEA Repair
622-1234-207	339F-12	5826-01-422-5461	DME Indicator	Collins	SEA Repair
622-1234-313	339F-12		DME Indicator	Collins	SEA Repair
622-1239-001	VIR-31A	5826-01-120-5991	Nav Receiver w/ RMI	Collins	SEA Repair
622-1239-002	VIR-31A		Nav Receiver	Collins	SEA Repair
622-1239-007	VIR-31A	5826-01-486-8271	Nav Receiver	Collins	SEA Repair
622-1239-011	VIR-31A	5826-01-202-7420	Nav Receiver	Collins	SEA Repair
622-1239-012	VIR-31A	5826-01-130-3162	Nav Receiver	Collins	SEA Repair
622-1239-014	VIR-31A		Nav Receiver	Collins	SEA Repair
622-1239-201	VIR-31A	5826-01-482-4504	Nav Receiver	Collins	SEA Repair
622-1239-202	VIR-31A		Nav Receiver	Collins	SEA Repair
622-1239-211	VIR-31A	5826-01-482-4505	Nav Receiver	Collins	SEA Repair
622-1270-001	TDR-90	5895-01-015-3810	ATC Transponder	Collins	SEA Repair
622-1334-001	VHF-20B	5821-01-056-7571	VHF Comm (118-151 MHz / 8K Bandpass)	Collins	SEA Repair
622-1334-002	VHF-20B		VHF Comm (118-151 MHz / 15K Bandpass)	Collins	SEA Repair
622-1879-001	VHF-20A	5895-00-614-2754	VHF Comm (118-135 MHz / 8K Bandpass)	Collins	SEA Repair
622-1879-002	VHF-20A	5895-00-614-2734	VHF Comm (118-135 MHz / 15K Bandpass)	Collins	SEA Repair
622-2012-011	339F-12A	5826-01-269-2206	DME Indicator	Collins	SEA Repair
622-2012-012	339F-12A	5826-01-284-3240	DME Indicator	Collins	SEA Repair
622-2012-013	339F-12A	5826-01-641-7781	DME Indicator	Collins	SEA Repair
622-2012-201	339F-12A		DME Indicator	Collins	SEA Repair
622-2084-001	GLS-350	5826-01-060-9490	Glideslope Receiver	Collins	SEA Repair
622-2093-001	PWC-150	5826-01-057-3513	Power Converter	Collins	SEA Repair
622-2175-001	339F-12B		DME Indicator	Collins	SEA Repair
622-2175-002	339F-12B		DME Indicator	Collins	SEA Repair
622-2175-003	339F-12B		DME Indicator	Collins	SEA Repair
622-2175-004	339F-12B		DME Indicator	Collins	SEA Repair
622-2175-201	339F-12B		DME Indicator	Collins	SEA Repair
622-2176-001	339F-12C		DME Indicator	Collins	SEA Repair
622-2176-002	339F-12C	5841-01-360-2958	DME Indicator	Collins	SEA Repair
622-2176-201	339F-12C		DME Indicator	Collins	SEA Repair
622-2177-001	339F-12D		DME Indicator	Collins	SEA Repair
622-2362-001	ADF-60A		ADF Receiver	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-2363-001	ANT-60A	5985-01-112-8057	ADF Antenna	Collins	SEA Repair
622-2363-002	ANT-60A		ADF Antenna	Collins	SEA Repair
622-2363-011	ANT-60A		ADF Antenna	Collins	SEA Repair
622-2494-001	ANT-212		Radar Antenna (Bottom Fed)	Collins	SEA Repair
622-2494-002	ANT-212		Radar Antenna (Top Fed)	Collins	SEA Repair
622-2495-001	ANT-210		Radar Antenna	Collins	SEA Repair
622-2495-002	ANT-210		Radar Antenna	Collins	SEA Repair
622-2501-001	ANT-312	5985-01-548-3004	Radar Antenna	Collins	SEA Repair
622-2502-001	ANT-310		Radar Antenna	Collins	SEA Repair
622-2504-001	ANT-318	5985-01-304-3741	Radar Antenna	Collins	SEA Repair
622-2506-001	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-002	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-003	RMI-36	5825-01-328-0196	Radio Magnetic Indicator	Collins	SEA Repair
622-2506-004	RMI-36	5826-01-317-9871	Radio Magnetic Indicator	Collins	SEA Repair
622-2506-005	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-006	RMI-36	5826-01-317-9872	Radio Magnetic Indicator	Collins	SEA Repair
622-2506-007	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-008	RMI-36	5826-01-304-3862	Radio Magnetic Indicator	Collins	SEA Repair
622-2506-009	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-010	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-011	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-012	RMI-36		RMI	Collins	SEA Repair
622-2506-013	RMI-36		RMI	Collins	SEA Repair
622-2506-014	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-101	RMI-36		Radio Magnetic Indicator	Collins	SEA Repair
622-2506-102	RMI-36		RMI	Collins	SEA Repair
622-2506-103	RMI-36		RMI	Collins	SEA Repair
622-2506-104	RMI-36		RMI	Collins	SEA Repair
622-2506-105	RMI-36		RMI	Collins	SEA Repair
622-2506-106	RMI-36		RMI	Collins	SEA Repair
622-2506-107	RMI-36		RMI	Collins	SEA Repair
622-2506-108	RMI-36		RMI	Collins	SEA Repair
622-2506-109	RMI-36		RMI	Collins	SEA Repair
622-2506-110	RMI-36		RMI	Collins	SEA Repair
622-2506-111	RMI-36		RMI	Collins	SEA Repair
622-2819-001	VIR-31H	5895-01-339-2471	Navigation Receiver	Collins	SEA Repair
622-2819-002	VIR-31H		Navigation Receiver	Collins	SEA Repair
622-2819-003	VIR-31H		Navigation Receiver	Collins	SEA Repair
622-2819-004	VIR-31H		Navigation Receiver	Collins	SEA Repair
622-2819-201	VIR-31H	5895-01-507-9558	Navigation Receiver	Collins	SEA Repair
622-2819-202	VIR-31H		Navigation Receiver	Collins	SEA Repair
622-2819-203	VIR-31H		Navigation Receiver	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-2819-204	VIR-31H		Navigation Receiver	Collins	SEA Repair
622-2855-001	ALT-55B	5841-01-272-2715	Radio Altimeter Transceiver	Collins	SEA Repair
622-2855-002	ALT-55B		Radio Altimeter Transceiver	Collins	SEA Repair
622-2855-011	ALT-55B	5841-01-429-4799	Radio Altimeter Transceiver	Collins	SEA Repair
622-2855-012	ALT-55B		Radio Altimeter Transceiver	Collins	SEA Repair
622-2873-001	ADF-60B	5825-01-335-5226	ADF Receiver	Collins	SEA Repair
622-2883-001	PWR-200		HF Power Amplifier	Collins	SEA Repair
622-2884-001	AAC-200	5985-01-304-3861	HF Antenna Coupler	Collins	SEA Repair
622-2884-003	AAC-200	5985-01-327-1621	Antenna Coupler	Collins	SEA Repair
622-2884-004	AAC-200		HF Antenna Coupler	Collins	SEA Repair
622-2884-005	AAC-200		Antenna Coupler (Helicopter)	Collins	SEA Repair
622-2885-001	CTL-200		HF Control	Collins	SEA Repair
622-2885-002	CTL-200		HF Control	Collins	SEA Repair
622-2885-003	CTL-200		HF Control	Collins	SEA Repair
622-2885-004	CTL-200		HF Control	Collins	SEA Repair
622-2885-005	CTL-200		Control	Collins	SEA Repair
622-2885-006	CTL-200		Control	Collins	SEA Repair
622-2885-011	CTL-200		Control	Collins	SEA Repair
622-2885-012	CTL-200		Control	Collins	SEA Repair
622-2885-013	CTL-200		Control	Collins	SEA Repair
622-2885-014	CTL-200		Control	Collins	SEA Repair
622-2885-015	CTL-200		Control	Collins	SEA Repair
622-2885-016	CTL-200		Control	Collins	SEA Repair
622-2937-001	ALI-55	5841-01-307-1526	Radio Altimeter Indicator	Collins	SEA Repair
622-2937-002	ALI-55	5841-01-125-5754	Radio Altimeter Indicator	Collins	SEA Repair
622-2937-003	ALI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-2937-004	ALI-55	5841-01-333-7901	Radio Altimeter Indicator	Collins	SEA Repair
622-2937-005	ALI-55	5841-01-439-5464	Radio Altimeter Indicator	Collins	SEA Repair
622-2937-008	ALI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-2937-009	ALI-55	5841-01-495-5422	Radio Altimeter Indicator	Collins	SEA Repair
622-2938-001	ALI-55A	5841-01-416-3841	Radio Altimeter Indicator	Collins	SEA Repair
622-2938-002	ALI-55A		Radio Altimeter Indicator	Collins	SEA Repair
622-2938-003	ALI-55A		Radio Altimeter Indicator	Collins	SEA Repair
622-2938-004	ALI-55A		Radio Altimeter Indicator	Collins	SEA Repair
622-3001-001	339F-12E	6625-01-166-8825	DME Indicator	Collins	SEA Repair
622-3201-001	ALT-50A	5826-01-284-3601	Radio Altimeter Transceiver	Collins	SEA Repair
622-3201-002	ALT-50A	5841-01-074-7161	Radio Altimeter R/T (non adj trips)	Collins	SEA Repair
622-3201-011	ALT-50A		Radio Altimeter Transceiver	Collins	SEA Repair
622-3201-012	ALT-50A		Radio Altimeter R/T (non adj trips)	Collins	SEA Repair
622-3338-001	WXT-250		Radar Transceiver	Collins	SEA Repair
622-3698-001	ANT-50A		Radio Altimeter Antenna	Collins	SEA Repair
622-3702-001	BDI-36	5826-01-346-8798	Bearing Distance Indicator	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-3702-002	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-003	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-004	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-005	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-006	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-007	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-008	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-009	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-010	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-011	BDI-36	5826-01-345-1261	Bearing Distance Indicator	Collins	SEA Repair
622-3702-012	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-013	BDI-36		Bearing Distance Indicator	Collins	SEA Repair
622-3702-014	BDI-36	5826-01-333-7911	Bearing Distance Indicator	Collins	SEA Repair
622-3702-015	BDI-36	5826-01-074-7162	Bearing Distance Indicator	Collins	SEA Repair
622-3702-016	BDI-36	5826-01-134-8901	Bearing Distance Indicator	Collins	SEA Repair
622-3710-001	ANT-60B	5985-01-258-5646	Dual ADF Antenna	Collins	SEA Repair
622-3881-001	IND-40C		DME Indicator	Collins	SEA Repair
622-3915-001	IND-40	5840-01-188-4694	DME Indicator	Collins	SEA Repair
622-3915-002	IND-40		DME Indicator	Collins	SEA Repair
622-3916-001	IND-40A	6605-01-350-7225	DME Indicator	Collins	SEA Repair
622-3916-002	IND-40A		DME Indicator	Collins	SEA Repair
622-3917-001	IND-40B		DME Indicator	Collins	SEA Repair
622-3917-002	IND-40B		DME Indicator (Grey)	Collins	SEA Repair
622-3918-001	IND-41		DME Indicator	Collins	SEA Repair
622-3918-002	IND-41	5841-01-126-6621	DME Indicator	Collins	SEA Repair
622-3919-001	IND-41A	5841-01-220-0659	DME Indicator	Collins	SEA Repair
622-3919-002	IND-41A		DME Indicator	Collins	SEA Repair
622-3920-001	IND-41B	5826-01-422-5469	DME Indicator	Collins	SEA Repair
622-3920-002	IND-41B		DME Indicator	Collins	SEA Repair
622-3921-001	IND-41C		DME Indicator	Collins	SEA Repair
622-3921-002	IND-41C		DME Indicator	Collins	SEA Repair
622-3975-004	ALI-80A	6610-01-500-2937	Encoding Altimeter	Collins	SEA Exchange
622-3975-014	ALI-80A		Encoding Altimeter	Collins	SEA Exchange
622-4020-001	ANT-212D		Radar Antenna	Collins	SEA Repair
622-4021-001	WXT-200A		Radar Transceiver	Collins	SEA Repair
622-4022-001	WXT-250A	5895-01-304-3879	Radar Transceiver	Collins	SEA Repair
622-4023-001	IND-200A		Radar Indicator	Collins	SEA Repair
622-4023-002	IND-200A		Radar Indicator	Collins	SEA Repair
622-4037-001	RT-1299(V)1/ARC-186V	5821-01-068-7854	Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-4037-002	RT-1299(V)2/ARC-186V	5821-01-075-9419	Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-4037-003	RT-1299(V)3/ARC-186V		Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-4037-004	RT-1299(V)4/ARC-186V	5821-01-075-9421	Panel Mount VHF AM/FM R/T	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-4037-005	RT-1299(V)5/ARC-186V	5821-01-075-9422	Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-4037-006	RT-1299(V)6/ARC-186V	5821-01-070-4720	Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-4037-007	RT-1299(V)7/ARC-186V		Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-4038-001	RT-1300/ARC-186	5821-01-062-1019	VHF COMM AM/FM R/T	Collins	SEA Repair
622-4038-002	RT-1300A/ARC-186(V)	5821-01-194-8160	Remote Mount VHF AM/FM R/T	Collins	SEA Repair
622-4151-006	HSI-84		HSI	Collins	SEA Exchange
622-4151-016	HSI-84	5840-01-194-1284	HSI	Collins	SEA Exchange
622-4160-001	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-002	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-003	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-004	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-005	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-006	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-007	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-008	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-009	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-010	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-011	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-012	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-013	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-014	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-015	DRI-55	5841-01-322-8892	Radio Altimeter Indicator	Collins	SEA Repair
622-4160-016	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-017	DRI-55		Radio Altimeter Indicator	Collins	SEA Repair
622-4160-018	DRI-55	5841-01-421-7405	Radio Altimeter Indicator	Collins	SEA Repair
622-4331-001	IND-300	5841-01-300-2714	Color Radar Indicator	Collins	SEA Repair
622-4331-002	IND-300	5998-01-307-2611	Color Radar Indicator	Collins	SEA Repair
622-4331-003	IND-300		Color Radar Indicator	Collins	SEA Repair
622-4471-001	CTL-201		HF CONTROL	Collins	SEA Repair
622-4483-001	IND-31C		VOR/LOC/GS Nav Indicator	Collins	SEA Repair
622-4483-002	IND-31C		VOR/LOC/GS Nav Indicator	Collins	SEA Repair
622-4483-003	IND-31C	5220-01-393-1264	VOR/LOC/GS Nav Indicator	Collins	SEA Repair
622-4490-001	CTL-201A		HF Control	Collins	SEA Repair
622-4490-002	CTL-201A		Control	Collins	SEA Repair
622-4523-001	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-002	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-003	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-004	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-005	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-006	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-007	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-008	CTL-20	5999-01-410-6903	VHF Comm Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-4523-009	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-010	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-011	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-012	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-013	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-014	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-015	CTL-20	5826-01-309-9752	VHF Comm Control	Collins	SEA Repair
622-4523-016	CTL-20	5826-01-448-0870	VHF Comm Control	Collins	SEA Repair
622-4523-017	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-018	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-201	CTL-20		Comm Control	Collins	SEA Repair
622-4523-202	CTL-20		Comm Control	Collins	SEA Repair
622-4523-203	CTL-20		Comm Control	Collins	SEA Repair
622-4523-204	CTL-20		Comm Control	Collins	SEA Repair
622-4523-205	CTL-20		Comm Control	Collins	SEA Repair
622-4523-206	CTL-20		Comm Control	Collins	SEA Repair
622-4523-207	CTL-20		Comm Control	Collins	SEA Repair
622-4523-208	CTL-20		Comm Control	Collins	SEA Repair
622-4523-209	CTL-20		Comm Control	Collins	SEA Repair
622-4523-210	CTL-20		Comm Control	Collins	SEA Repair
622-4523-211	CTL-20		Comm Control	Collins	SEA Repair
622-4523-212	CTL-20		Comm Control	Collins	SEA Repair
622-4523-213	CTL-20		Comm Control	Collins	SEA Repair
622-4523-214	CTL-20		Comm Control	Collins	SEA Repair
622-4523-215	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-216	CTL-20		Comm Control	Collins	SEA Repair
622-4523-217	CTL-20		Comm Control	Collins	SEA Repair
622-4523-218	CTL-20		Comm Control	Collins	SEA Repair
622-4523-801	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-802	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-803	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4523-804	CTL-20		VHF Comm Control	Collins	SEA Repair
622-4524-001	CTL-30		Nav Control	Collins	SEA Repair
622-4524-002	CTL-30		Nav Control	Collins	SEA Repair
622-4524-003	CTL-30		Nav Control	Collins	SEA Repair
622-4524-004	CTL-30		Nav Control	Collins	SEA Repair
622-4524-005	CTL-30		Nav Control	Collins	SEA Repair
622-4524-030	CTL-30		Nav Control	Collins	SEA Repair
622-4524-041	CTL-30		Nav Control	Collins	SEA Repair
622-4524-042	CTL-30		Nav Control	Collins	SEA Repair
622-4524-043	CTL-30		Nav Control	Collins	SEA Repair
622-4524-044	CTL-30		Nav Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-4524-049	CTL-30		Nav Control	Collins	SEA Repair
622-4524-050	CTL-30		Nav Control	Collins	SEA Repair
622-4524-051	CTL-30		Nav Control	Collins	SEA Repair
622-4524-052	CTL-30		Nav Control	Collins	SEA Repair
622-4524-053	CTL-30		Nav Control	Collins	SEA Repair
622-4524-054	CTL-30		Nav Control	Collins	SEA Repair
622-4524-055	CTL-30		Nav Control	Collins	SEA Repair
622-4524-056	CTL-30		Nav Control	Collins	SEA Repair
622-4524-057	CTL-30		Nav Control	Collins	SEA Repair
622-4524-058	CTL-30		Nav Control	Collins	SEA Repair
622-4524-059	CTL-30		Nav Control	Collins	SEA Repair
622-4524-060	CTL-30		Nav Control	Collins	SEA Repair
622-4524-061	CTL-30		Nav Control	Collins	SEA Repair
622-4524-062	CTL-30		Nav Control	Collins	SEA Repair
622-4524-063	CTL-30	5826-01-448-0869	Nav Control	Collins	SEA Repair
622-4524-064	CTL-30		Nav Control	Collins	SEA Repair
622-4524-065	CTL-30		Nav Control	Collins	SEA Repair
622-4524-066	CTL-30		Nav Control	Collins	SEA Repair
622-4524-067	CTL-30		Nav Control	Collins	SEA Repair
622-4524-068	CTL-30		Nav Control	Collins	SEA Repair
622-4524-073	CTL-30		Nav Control	Collins	SEA Repair
622-4524-074	CTL-30		Nav Control	Collins	SEA Repair
622-4524-075	CTL-30		Nav Control	Collins	SEA Repair
622-4524-076	CTL-30		Nav Control	Collins	SEA Repair
622-4524-077	CTL-30		Nav Control	Collins	SEA Repair
622-4524-078	CTL-30		Nav Control	Collins	SEA Repair
622-4524-079	CTL-30		Nav Control	Collins	SEA Repair
622-4524-080	CTL-30		Nav Control	Collins	SEA Repair
622-4524-085	CTL-30		Nav Control	Collins	SEA Repair
622-4524-086	CTL-30		Nav Control	Collins	SEA Repair
622-4524-087	CTL-30	5826-01-309-9753	Nav Control	Collins	SEA Repair
622-4524-088	CTL-30		Nav Control	Collins	SEA Repair
622-4524-097	CTL-30		Nav Control	Collins	SEA Repair
622-4524-098	CTL-30		Nav Control	Collins	SEA Repair
622-4524-099	CTL-30		Nav Control	Collins	SEA Repair
622-4524-100	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-101	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-102	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-103	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-104	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-105	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-106	CTL-30		Navigation Control Head	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-4524-107	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-108	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-109	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-110	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-111	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-112	CTL-30		Navigation Control Head	Collins	SEA Repair
622-4524-277	CTL-30		Nav Control	Collins	SEA Repair
622-4524-278	CTL-30		Nav Control	Collins	SEA Repair
622-4524-279	CTL-30		Nav Control	Collins	SEA Repair
622-4524-814	CTL-30		Nav Control	Collins	SEA Repair
622-4524-815	CTL-30		Nav Control	Collins	SEA Repair
622-4526-001	CTL-60		ADF Control	Collins	SEA Repair
622-4526-002	CTL-60		ADF Control	Collins	SEA Repair
622-4526-003	CTL-60		ADF Control	Collins	SEA Repair
622-4526-004	CTL-60		ADF Control	Collins	SEA Repair
622-4526-005	CTL-60		ADF Control	Collins	SEA Repair
622-4526-006	CTL-60		ADF Control	Collins	SEA Repair
622-4526-007	CTL-60		ADF Control	Collins	SEA Repair
622-4526-008	CTL-60	5826-01-408-9326	ADF Control	Collins	SEA Repair
622-4526-009	CTL-60		ADF Control	Collins	SEA Repair
622-4526-010	CTL-60		ADF Control	Collins	SEA Repair
622-4526-011	CTL-60		ADF Control	Collins	SEA Repair
622-4526-012	CTL-60		ADF Control	Collins	SEA Repair
622-4526-013	CTL-60		ADF Control	Collins	SEA Repair
622-4526-014	CTL-60		ADF Control	Collins	SEA Repair
622-4526-015	CTL-60	5826-01-309-9754	ADF Control	Collins	SEA Repair
622-4526-016	CTL-60		ADF Control	Collins	SEA Repair
622-4526-017	CTL-60		ADF Control	Collins	SEA Repair
622-4526-018	CTL-60		ADF Control	Collins	SEA Repair
622-4526-019	CTL-60		ADF Control	Collins	SEA Repair
622-4526-020	CTL-60		ADF Control	Collins	SEA Repair
622-4526-021	CTL-60		ADF Control	Collins	SEA Repair
622-4526-022	CTL-60		ADF Control	Collins	SEA Repair
622-4526-023	CTL-60		ADF Control	Collins	SEA Repair
622-4526-024	CTL-60		ADF Control	Collins	SEA Repair
622-4526-025	CTL-60		ADF Control	Collins	SEA Repair
622-4526-026	CTL-60		ADF Control	Collins	SEA Repair
622-4526-027	CTL-60		ADF Control	Collins	SEA Repair
622-4526-028	CTL-60		ADF Control	Collins	SEA Repair
622-4526-029	CTL-60		ADF Control	Collins	SEA Repair
622-4526-030	CTL-60		ADF Control	Collins	SEA Repair
622-4526-031	CTL-60		ADF Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-4526-032	CTL-60		ADF Control	Collins	SEA Repair
622-4526-033	CTL-60		ADF Control	Collins	SEA Repair
622-4526-034	CTL-60		ADF Control	Collins	SEA Repair
622-4526-804	CTL-60		ADF Control	Collins	SEA Repair
622-4527-001	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-002	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-003	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-004	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-005	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-006	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-007	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-008	CTL-90	5826-01-408-9327	Transponder Control	Collins	SEA Repair
622-4527-009	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-010	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-011	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-012	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-013	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-014	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-015	CTL-90	5826-01-309-9755	Transponder Control	Collins	SEA Repair
622-4527-016	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-017	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-018	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-019	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-020	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-021	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-803	CTL-90		Transponder Control	Collins	SEA Repair
622-4527-804	CTL-90		Transponder Control	Collins	SEA Repair
622-4530-016	CTL-21		Comm Control	Collins	SEA Repair
622-4530-215	CTL-21		Comm Control	Collins	SEA Repair
622-4531-064	CTL-31		Nav Control	Collins	SEA Repair
622-4531-113	CTL-31		Nav Control	Collins	SEA Repair
622-4532-005	CTL-61		ADF Control	Collins	SEA Repair
622-4532-007	CTL-61		ADF Control	Collins	SEA Repair
622-4532-016	CTL-61		ADF Control	Collins	SEA Repair
622-4532-017	CTL-61		ADF Control	Collins	SEA Repair
622-4533-005	CTL-91		Control	Collins	SEA Repair
622-4533-008	CTL-91		Transponder Control	Collins	SEA Repair
622-4533-017	CTL-91		Transponder Control	Collins	SEA Repair
622-4545-001	CTL-220		HF Control	Collins	SEA Repair
622-4545-002	CTL-220		HF Control	Collins	SEA Repair
622-4545-003	CTL-220		HF Control	Collins	SEA Repair
622-4545-004	CTL-220		HF control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-4545-005	CTL-220		HF Control	Collins	SEA Repair
622-4545-006	CTL-220		HF Control	Collins	SEA Repair
622-4545-011	CTL-220		HF Control	Collins	SEA Repair
622-4545-012	CTL-220		HF Control	Collins	SEA Repair
622-4545-013	CTL-220		HF Control	Collins	SEA Repair
622-4545-014	CTL-220		HF Control	Collins	SEA Repair
622-4545-015	CTL-220		HF Control	Collins	SEA Repair
622-4545-016	CTL-220		HF Control	Collins	SEA Repair
622-4545-021	CTL-220		HF Control	Collins	SEA Repair
622-4545-022	CTL-220		HF Control	Collins	SEA Repair
622-4545-023	CTL-220		HF Control	Collins	SEA Repair
622-4545-024	CTL-220		HF Control	Collins	SEA Repair
622-4545-025	CTL-220		HF Control	Collins	SEA Repair
622-4545-026	CTL-220		HF Control	Collins	SEA Repair
622-4545-031	CTL-220		HF Control	Collins	SEA Repair
622-4545-032	CTL-220		HF Control	Collins	SEA Repair
622-4545-033	CTL-220		HF Control	Collins	SEA Repair
622-4545-034	CTL-220		HF Control	Collins	SEA Repair
622-4545-035	CTL-220		HF Control	Collins	SEA Repair
622-4545-036	CTL-220		HF Control	Collins	SEA Repair
622-4563-001	339H-6		Radio Altimeter Indicator	Collins	SEA Repair
622-4563-004	339H-6		Radar Altimeter Indicator	Collins	SEA Repair
622-4563-006	339H-6		Radio Altimeter Indicator	Collins	SEA Repair
622-4563-008	339H-6		Radio Altimeter Indicator	Collins	SEA Repair
622-4563-011	339H-6		Radio Altimeter Indicator	Collins	SEA Repair
622-4565-001	332D-11T	6615-01-328-1062	Vertical Gyro	Collins	SEA Exchange
622-4565-002	332D-11T	6625-01-353-3975	Vertical Gyro	Collins	SEA Exchange
622-4572-001	HSI-70C		HSI	Collins	SEA Exchange
622-4938-001	RMI-30	5826-01-296-3914	Radio Magnetic Indicator	Collins	SEA Repair
622-4938-002	RMI-30		Radio Magnetic Indicator	Collins	SEA Repair
622-4938-003	RMI-30		Radio Magnetic Indicator	Collins	SEA Repair
622-4938-004	RMI-30		Radio Magnetic Indicator	Collins	SEA Repair
622-4938-006	RMI-30		Radio Magnetic Indicator	Collins	SEA Repair
622-4938-007	RMI-30	5826-01-370-9328	Radio Magnetic Indicator	Collins	SEA Repair
622-4938-021	RMI-30		RMI	Collins	SEA Repair
622-4938-022	RMI-30		RMI	Collins	SEA Repair
622-4938-023	RMI-30		RMI	Collins	SEA Repair
622-4938-024	RMI-30		RMI	Collins	SEA Repair
622-4938-025	RMI-30		RMI	Collins	SEA Repair
622-4938-026	RMI-30		RMI	Collins	SEA Repair
622-4938-027	RMI-30		RMI	Collins	SEA Repair
622-5337-001	TCR-220		HF Transceiver	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-5337-002	TCR-220		HF Transceiver	Collins	SEA Repair
622-5367-001	ALI-55B		Radio Altitude Indicator	Collins	SEA Repair
622-5528-001	RT-1354/ARC-186(V)	5821-01-092-4907	Panel Mount VHF AM/FM R/T	Collins	SEA Repair
622-5798-008	FCP-65	1680-01-651-3424	Flight Control Panel	Collins	SEA Exchange
622-5798-013	FCP-65	5895-01-325-4788	Flight Control Panel	Collins	SEA Exchange
622-5799-001	MAP-65	6340-01-495-9725	Mode Annunciator Panel	Collins	SEA Exchange
622-5812-001	FDU-70	6605-01-345-1258	Flux Detector Unit	Collins	SEA Repair
622-5812-002	FDU-70	6605-01-329-0833	Flux Detector	Collins	SEA Repair
622-5812-003	FDU-70		Flux Detector Unit	Collins	SEA Repair
622-5812-004	FDU-70		Flux Detector Unit	Collins	SEA Repair
622-5812-005	FDU-70		Flux Detector Unit	Collins	SEA Repair
622-5812-006	FDU-70		Flux Detector Unit	Collins	SEA Repair
622-5940-001	IND-220		Color Radar Indicator	Collins	SEA Repair
622-5940-008	IND-220		Color Radar Indicator	Collins	SEA Repair
622-5941-001	IND-270		Radar Indicator	Collins	SEA Repair
622-6020-021	EFD-85	5840-01-345-1650	EFIS Display (Black)	Collins	SEA Exchange
622-6136-001	DGS-65	6615-01-308-3085	Directional Gyro	Collins	SEA Exchange
622-6136-002	DGS-65	6615-01-311-6126	Directional Gyro	Collins	SEA Exchange
622-6137-001	VIR-32	5826-01-300-2715	Navigation Receiver	Collins	SEA Repair
622-6137-201	VIR-32	5826-01-450-6351	Nav Receiver w/ FM Immunity	Collins	SEA Repair
622-6152-001	VHF-22A	5895-01-369-5448	VHF Comm	Collins	SEA Repair
622-6152-002	VHF-22A		VHF Comm Transceiver	Collins	SEA Repair
622-6152-011	VHF-22A		VHF Comm Transceiver	Collins	SEA Repair
622-6152-012	VHF-22A		VHF Comm Transceiver	Collins	SEA Repair
622-6152-021	VHF-22A		VHF Comm Transceiver	Collins	SEA Repair
622-6152-022	VHF-22A		VHF Comm Transceiver	Collins	SEA Repair
622-6152-023	VHF-22A		VHF Comm	Collins	SEA Repair
622-6152-031	VHF-22A	5821-01-640-9029	VHF Comm Transceiver	Collins	SEA Repair
622-6152-032	VHF-22A		VHF Comm Transceiver	Collins	SEA Repair
622-6152-033	VHF-22A		VHF Comm	Collins	SEA Repair
622-6153-001	VHF-22B	5820-01-328-1040	VHF Comm Transceiver (118-151 MHz)	Collins	SEA Repair
622-6153-002	VHF-22B	5820-01-423-9200	VHF Comm	Collins	SEA Repair
622-6153-021	VHF-22B		VHF Comm Transceiver	Collins	SEA Repair
622-6153-022	VHF-22B		VHF Comm Transceiver	Collins	SEA Repair
622-6153-023	VHF-22B		VHF Comm	Collins	SEA Repair
622-6198-001	HPU-74	6610-01-492-0605	HSI Processor Unit	Collins	SEA Exchange
622-6198-002	HPU-74	6610-01-322-0569	HSI Processor Unit	Collins	SEA Exchange
622-6263-001	DME-42	5895-01-304-3814	DME Transceiver	Collins	SEA Repair
622-6263-002	DME-42		DME Transceiver	Collins	SEA Repair
622-6263-003	DME-42	5895-01-304-3814	DME Transceiver	Collins	SEA Repair
622-6347-001	RT-1300B/ARC-186(V)	5821-01-208-1093	VHF AM/FM Receiver Transmitter	Collins	SEA Repair
622-6347-002	RT-1300C/ARC-186(V)	5821-01-213-3980	VHF AM/FM Receiver Transmitter	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-6389-001	VHF-21A		VHF Comm Transceiver	Collins	SEA Repair
622-6389-002	VHF-21A		VHF Comm Transceiver	Collins	SEA Repair
622-6389-011	VHF-21A	5825-01-332-9175	VHF Comm Transceiver	Collins	SEA Repair
622-6389-012	VHF-21A		VHF Comm Transceiver	Collins	SEA Repair
622-6390-001	VHF-21B	5821-01-330-6120	VHF Comm Transceiver	Collins	SEA Repair
622-6390-002	VHF-21B		VHF Comm	Collins	SEA Repair
622-6470-001	AAC-200P		HF Antenna Coupler	Collins	SEA Exchange
622-6471-001	AAC-220P		HF Antenna Coupler	Collins	SEA Repair
622-6471-002	AAC-220P		Antenna Coupler	Collins	SEA Repair
622-6513-001	ANT-312A		Radar Antenna	Collins	SEA Repair
622-6520-001	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-002	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-003	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-004	CTL-22	5820-01-328-0802	VHF Comm Control	Collins	SEA Repair
622-6520-005	CTL-22	5895-01-417-3012	VHF Comm Control	Collins	SEA Repair
622-6520-006	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-007	CTL-22	5985-01-304-3751	VHF Comm Control	Collins	SEA Repair
622-6520-008	CTL-22	5826-01-305-9618	VHF Comm Control	Collins	SEA Repair
622-6520-009	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-010	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-011	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-012	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-013	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-014	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-015	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-016	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-801	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6520-802	CTL-22		VHF Comm Control	Collins	SEA Repair
622-6521-001	CTL-32		Nav Control	Collins	SEA Repair
622-6521-002	CTL-32		Nav Control	Collins	SEA Repair
622-6521-003	CTL-32		Nav Control	Collins	SEA Repair
622-6521-004	CTL-32		Nav Control	Collins	SEA Repair
622-6521-005	CTL-32		Nav Control	Collins	SEA Repair
622-6521-006	CTL-32		Nav Control	Collins	SEA Repair
622-6521-007	CTL-32	5895-01-344-7311	Nav Control	Collins	SEA Repair
622-6521-008	CTL-32	5895-01-301-0081	Nav Control	Collins	SEA Repair
622-6521-009	CTL-32		Nav Control	Collins	SEA Repair
622-6521-010	CTL-32		Nav Control	Collins	SEA Repair
622-6521-011	CTL-32	5985-01-304-3752	Nav Control	Collins	SEA Repair
622-6521-012	CTL-32	5985-01-314-9901	Nav Control	Collins	SEA Repair
622-6521-013	CTL-32	5821-01-333-9234	Nav Control	Collins	SEA Repair
622-6521-014	CTL-32	5836-01-450-6438	Nav Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-6521-015	CTL-32	5895-01-493-3013	Nav Control	Collins	SEA Repair
622-6521-016	CTL-32	5821-01-249-6476	Nav Control	Collins	SEA Repair
622-6521-025	CTL-32		Nav Control	Collins	SEA Repair
622-6521-026	CTL-32		Nav Control	Collins	SEA Repair
622-6521-027	CTL-32		Nav Control	Collins	SEA Repair
622-6521-028	CTL-32		Nav Control	Collins	SEA Repair
622-6521-029	CTL-32		Nav Control	Collins	SEA Repair
622-6521-030	CTL-32		Nav Control	Collins	SEA Repair
622-6521-031	CTL-32		Nav Control	Collins	SEA Repair
622-6521-032	CTL-32		Nav Control	Collins	SEA Repair
622-6522-001	CTL-62		ADF Control	Collins	SEA Repair
622-6522-002	CTL-62		ADF Control	Collins	SEA Repair
622-6522-003	CTL-62	5895-01-325-4789	ADF Control	Collins	SEA Repair
622-6522-004	CTL-62	5985-01-316-6426	ADF Control	Collins	SEA Repair
622-6522-005	CTL-62	5821-01-333-9235	ADF Control	Collins	SEA Repair
622-6522-006	CTL-62		ADF Control	Collins	SEA Repair
622-6522-007	CTL-62		ADF Control	Collins	SEA Repair
622-6522-008	CTL-62	5985-01-327-9565	ADF Control	Collins	SEA Repair
622-6522-009	CTL-62		ADF Control	Collins	SEA Repair
622-6522-010	CTL-62		ADF Control	Collins	SEA Repair
622-6522-011	CTL-62		ADF Control	Collins	SEA Repair
622-6522-012	CTL-62		ADF Control	Collins	SEA Repair
622-6522-013	CTL-62		ADF Control	Collins	SEA Repair
622-6522-014	CTL-62		ADF Control	Collins	SEA Repair
622-6522-015	CTL-62		ADF Control	Collins	SEA Repair
622-6522-016	CTL-62		ADF Control	Collins	SEA Repair
622-6522-017	CTL-62		ADF Control	Collins	SEA Repair
622-6522-018	CTL-62		ADF Control	Collins	SEA Repair
622-6522-019	CTL-62		ADF Control	Collins	SEA Repair
622-6522-020	CTL-62		ADF Control	Collins	SEA Repair
622-6522-021	CTL-62		ADF Control	Collins	SEA Repair
622-6522-022	CTL-62		ADF Control	Collins	SEA Repair
622-6522-023	CTL-62		ADF Control	Collins	SEA Repair
622-6522-024	CTL-62		ADF Control	Collins	SEA Repair
622-6522-025	CTL-62		ADF Control	Collins	SEA Repair
622-6522-026	CTL-62		ADF Control	Collins	SEA Repair
622-6522-027	CTL-62		ADF Control	Collins	SEA Repair
622-6522-028	CTL-62		ADF Control	Collins	SEA Repair
622-6522-029	CTL-62		ADF Control	Collins	SEA Repair
622-6522-030	CTL-62		ADF Control	Collins	SEA Repair
622-6522-031	CTL-62		ADF Control	Collins	SEA Repair
622-6522-032	CTL-62		ADF Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-6522-801	CTL-62		ADF Control	Collins	SEA Repair
622-6522-802	CTL-62		ADF Control	Collins	SEA Repair
622-6522-803	CTL-62		ADF Control	Collins	SEA Repair
622-6522-804	CTL-62		ADF Control	Collins	SEA Repair
622-6523-001	CTL-92	1440-01-423-9207	Transponder Control	Collins	SEA Repair
622-6523-002	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-003	CTL-92	5895-01-372-5176	Transponder Control	Collins	SEA Repair
622-6523-004	CTL-92	1440-01-316-6427	ATC Transponder Control	Collins	SEA Repair
622-6523-005	CTL-92	5821-01-333-9236	ATC Transponder Control	Collins	SEA Repair
622-6523-006	CTL-92		ATC Transponder Control	Collins	SEA Repair
622-6523-007	CTL-92	5985-01-304-3754	ATC Transponder Control	Collins	SEA Repair
622-6523-008	CTL-92	5895-01-370-4296	Transponder Control	Collins	SEA Repair
622-6523-009	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-010	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-011	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-012	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-013	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-014	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-015	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-016	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-201	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-202	CTL-92	5895-01-424-3790	Transponder Control	Collins	SEA Repair
622-6523-203	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-204	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-205	CTL-92	5895-01-498-5233	Transponder Control	Collins	SEA Repair
622-6523-206	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-207	CTL-92	5895-01-497-8158	Transponder Control	Collins	SEA Repair
622-6523-208	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-209	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-210	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-211	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-212	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-213	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-214	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-215	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-305	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-306	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-307	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-308	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-313	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-314	CTL-92		Transponder Control	Collins	SEA Repair
622-6523-315	CTL-92		Transponder Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-6523-316	CTL-92		Transponder Control	Collins	SEA Repair
622-6524-001	IND-42A	5826-01-249-6477	DME Indicator	Collins	SEA Repair
622-6524-002	IND-42A		DME Indicator	Collins	SEA Repair
622-6524-003	IND-42A	5826-01-439-5461	DME Indicator	Collins	SEA Repair
622-6524-004	IND-42A	5826-01-314-9992	DME Indicator	Collins	SEA Repair
622-6557-001	TCR-230	5820-01-304-3884	HF Transceiver	Collins	SEA Repair
622-6557-002	TCR-230		TRANSCEIVER	Collins	SEA Repair
622-6557-003	TCR-230		HF Transceiver w/ Constant Audio Output	Collins	SEA Repair
622-6557-011	TCR-230		HF Transceiver	Collins	SEA Repair
622-6557-013	TCR-230		HF Transceiver	Collins	SEA Repair
622-6590-001	CAD-62	7050-01-306-4536	Control Adapter	Collins	SEA Repair
622-6590-002	CAD-62	7050-01-526-3268	ADF/Transponder Adapter	Collins	SEA Repair
622-6614-001	CTL-230	5985-01-306-4533	HF Control	Collins	SEA Repair
622-6614-002	CTL-230		HF Control	Collins	SEA Repair
622-6614-003	CTL-230		HF Control	Collins	SEA Repair
622-6614-004	CTL-230		HF Control	Collins	SEA Repair
622-6614-005	CTL-230		HF Control	Collins	SEA Repair
622-6614-006	CTL-230		HF Control	Collins	SEA Repair
622-6614-007	CTL-230		HF Control	Collins	SEA Repair
622-6614-008	CTL-230		HF Control	Collins	SEA Repair
622-6614-021	CTL-230		HF Control	Collins	SEA Repair
622-6614-022	CTL-230	5895-01-560-5110	HF Control	Collins	SEA Repair
622-6614-023	CTL-230	5821-01-641-7772	HF Control	Collins	SEA Repair
622-6614-024	CTL-230		HF Control	Collins	SEA Repair
622-6614-025	CTL-230		HF Control	Collins	SEA Repair
622-6614-026	CTL-230		HF Control	Collins	SEA Repair
622-6614-027	CTL-230		HF Control	Collins	SEA Repair
622-6614-028	CTL-230		HF Control	Collins	SEA Repair
622-6633-001	ANT-318A		Radar Antenna	Collins	SEA Repair
622-6667-001	PWR-230	5895-01-306-4529	HF Power Amplifier	Collins	SEA Repair
622-6793-001	ANT-52	5985-01-416-2520	Radio Altimeter Antenna	Collins	SEA Repair
622-7139-001	PAC-230		HF Antenna Probe Coupler	Collins	SEA Exchange
622-7194-001	VIR-432		Nav Receiver	Collins	SEA Repair
622-7194-011	VIR-432		Nav Receiver	Collins	SEA Repair
622-7194-101	VIR-432		Navigation Receiver	Collins	SEA Repair
622-7194-201	VIR-432	5826-01-432-2044	Navigation Receiver	Collins	SEA Repair
622-7292-001	VHF-422A		VHF Comm	Collins	SEA Repair
622-7292-101	VHF-422A		VHF Comm	Collins	SEA Repair
622-7292-121	VHF-422A		VHF Comm	Collins	SEA Repair
622-7292-123	VHF-422A		VHF Comm	Collins	SEA Repair
622-7293-001	VHF-422B		VHF Comm	Collins	SEA Repair
622-7293-002	VHF-422B		VHF Comm	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-7293-101	VHF-422B	5821-01-442-4176	VHF Comm	Collins	SEA Repair
622-7293-102	VHF-422B		VHF Comm	Collins	SEA Repair
622-7293-121	VHF-422B		VHF Comm	Collins	SEA Repair
622-7293-122	VHF-422B		VHF Comm	Collins	SEA Repair
622-7293-123	VHF-422B		VHF Comm	Collins	SEA Repair
622-7309-001	DME-442		DME Transceiver	Collins	SEA Repair
622-7309-101	DME-442	5895-01-459-8627	DME Transceiver	Collins	SEA Repair
622-7318-001	IND-42C	6695-01-333-9237	DME Indicator	Collins	SEA Repair
622-7318-002	IND-42C		DME Indicator	Collins	SEA Repair
622-7318-003	IND-42C	5826-01-439-5463	DME Indicator	Collins	SEA Repair
622-7318-004	IND-42C	5826-01-547-5136	DME Indicator	Collins	SEA Repair
622-7337-001	WXT-250B	5841-01-315-0645	Radar Transceiver	Collins	SEA Repair
622-7382-001	ADF-462		ADF Receiver	Collins	SEA Repair
622-7382-101	ADF-462	5821-01-327-9610	ADF Receiver	Collins	SEA Repair
622-7382-111	ADF-462		ADF Receiver	Collins	SEA Repair
622-7383-001	ANT-462A	5985-01-328-9812	ADF Antenna	Collins	SEA Repair
622-7384-001	ANT-462B	5985-01-493-3461	Dual ADF Antenna	Collins	SEA Repair
622-7444-001	ANT-310A		Radar Antenna	Collins	SEA Repair
622-8332-001	CAD-31	6625-01-329-0815	Control Adapter	Collins	SEA Repair
622-8332-002	CAD-31	6625-01-546-0880	Nav Adapter	Collins	SEA Repair
622-8439-003	RTA-852	5895-01-450-5722	Radar Transceiver	Collins	SEA Exchange
622-8441-004	RTA-858	5841-01-524-9566	Radar Transceiver/Antenna	Collins	SEA Exchange
622-8738-001	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-002	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-003	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-004	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-005	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-006	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-007	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-008	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-009	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-010	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-011	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-012	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-013	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-014	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-015	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-016	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-025	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-026	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-027	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-028	CTL-32A		Nav Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-8738-029	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-030	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-031	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-032	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-801	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-802	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-803	CTL-32A		Nav Control	Collins	SEA Repair
622-8738-804	CTL-32A		Nav Control	Collins	SEA Repair
622-9210-001	TDR-94D		Mode S Transponder	Collins	SEA Repair
622-9210-002	TDR-94D		Mode S Transponder	Collins	SEA Repair
622-9210-003	TDR-94D	5895-01-424-3785	Mode S Transponder	Collins	SEA Repair
622-9336-002	AHC-85E		AHARS Computer	Collins	OEM Dealer Repair
622-9336-400	AHC-85E		Attitude/Heading Computer	Collins	OEM Dealer Repair
622-9345-203	EFD-871		EFIS Display	Collins	OEM Dealer Repair
622-9352-001	TDR-94		Mode S Transponder	Collins	SEA Repair
622-9352-002	TDR-94		Mode S Transponder	Collins	SEA Repair
622-9352-003	TDR-94		Mode S Transponder	Collins	SEA Repair
622-9353-021	TVI-920		IVSI	Collins	OEM Dealer Repair
622-9353-221	TVI-920		TCAS IND/VSII	Collins	OEM Dealer Repair
622-9353-223	TVI-920		TCAS Indicator/IVSI	Collins	OEM Dealer Repair
622-9353-315	TVI-920	6605-01-550-6277	TCAS IIVSI/RA/TA Ind.	Collins	OEM Dealer Repair
622-9353-423	TVI-920		IVSI	Collins	OEM Dealer Repair
622-9353-621	TVI-920		TCAS Indicator	Collins	OEM Dealer Repair
622-9353-623	TVI-920		TCAS Indicator	Collins	OEM Dealer Repair
622-9405-001	HF-9042	5985-01-325-1931	HF Antenna Coupler	Collins	OEM Dealer Repair
622-9614-001	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-002	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-003	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-004	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-005	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-006	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-007	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-008	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-009	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-010	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-011	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-012	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-013	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-014	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-015	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-016	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-101	CTL-92T	6605-01-504-8453	TCAS Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
622-9614-102	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-103	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-104	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-105	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-106	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-107	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-108	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-109	CTL-92T	5895-01-498-5232	TCAS Control	Collins	SEA Repair
622-9614-110	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-111	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-112	CTL-92T	5895-01-588-0995	TCAS Control	Collins	SEA Repair
622-9614-113	CTL-92T	5895-01-498-5232	TCAS Control	Collins	SEA Repair
622-9614-114	CTL-92T		TCAS Control	Collins	SEA Repair
622-9614-115	CTL-92T	5895-01-497-8161	TCAS Control	Collins	SEA Repair
622-9614-116	CTL-92T		TCAS Control	Collins	SEA Repair
622-9627-005	FYD-65		Flight Director/Yaw Damper Computer	Collins	SEA Exchange
622-9627-205	FYD-65		Flight Director/Yaw Damper Computer	Collins	SEA Exchange
622-9682-004	DPU-84		Display Processor Unit	Collins	SEA Exchange
622-9683-011	DSP-84		Display Select Panel	Collins	SEA Exchange
622-9683-101	DSP-84		Display Select Panel	Collins	SEA Exchange
622-9724-099	APC-65H		Autopilot Computer	Collins	SEA Exchange
622-9728-113	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-115	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-125	TVI-920D	5826-01-558-9707	TCAS Indicator	Collins	OEM Dealer Repair
622-9728-311	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-313	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-314	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-316	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-325	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-415	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-423	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9728-424	TVI-920D		TCAS Indicator	Collins	OEM Dealer Repair
622-9810-016	EFD-4076		Electronic Flight Display	Collins	OEM Dealer Repair
622-9814-009	IOC-4000		I/O CNCTR	Collins	OEM Dealer Repair
622-9814-607	IOC-4000		I/O CNCTR - EHS	Collins	OEM Dealer Repair
622-9852-106	RTU-4000		Radio Tuning Unit	Collins	OEM Dealer Repair
6402-43011-02	MFD-640		Multi-Function Display	Universal Avionics	OEM Dealer Repair
7000298-901	TZ-701		Turn Computer	Honeywell	OEM Dealer Repair
7000299-901	PC-702		Helipilot Controller	Honeywell	OEM Dealer Repair
7000299-902	PC-702		Helipilot Controller	Honeywell	SEA Exchange
7000299-903	PC-702	5962-01-428-3282	Helipilot Controller	Honeywell	SEA Exchange
7000299-904	PC-702		Helipilot Controller	Honeywell	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
7000299-907	PC-702		Helipilot Controller	Honeywell	SEA Exchange
7000299-909	PC-702		Helipilot Control	Honeywell	SEA Exchange
7000299-910	PC-700		Helipilot Controller	Honeywell	OEM Dealer Repair
7000299-912	PC-702		Helipilot Controller	Honeywell	SEA Exchange
7000300-901	AS-702		Airspeed Sensor	Honeywell	OEM Dealer Repair
7000466-901	AD-650A		ADI	Honeywell	SEA Exchange
7000466-914	AD-600H		Attitude Gyro	Honeywell	SEA Exchange
7000466-935	AD-650		ADI	Honeywell	SEA Exchange
7000469-902	RD-650B	6605-01-121-4930	HSI	Honeywell	SEA Exchange
7000469-904	RD-650B		HSI	Honeywell	SEA Exchange
7000469-906	RD-650B		HSI	Honeywell	SEA Exchange
7000469-907	RD-650A		HSI	Honeywell	SEA Exchange
7000469-909	RD-650A		HSI	Honeywell	SEA Exchange
7000469-911	RD-650A		HSI	Honeywell	SEA Exchange
7000469-913	RD-650		HSI	Honeywell	SEA Exchange
7000472-904	AL-800		Altitude Alerter Panel	Honeywell	OEM Dealer Repair
7000472-906	AL-800		Altitude Preslect Control	Honeywell	OEM Dealer Repair
7000472-926	AL-800		Altitude Preselect Controller	Honeywell	OEM Dealer Repair
7000605-901	MS-702	6220-01-595-2331	Flight Director Mode Selector	Honeywell	SEA Exchange
7000605-902	MS-700		Mode Selector	Honeywell	OEM Dealer Repair
7000605-902	MS-700	5962-01-428-3338	Mode Selector	Honeywell	SEA Exchange
7000605-904	MS-700		Mode Selector	Honeywell	SEA Exchange
7000605-905	MS-700		Mode Selector	Honeywell	SEA Exchange
7000605-909	MS-700		Mode Selector	Honeywell	SEA Exchange
7000605-911	MS-700		Mode Selector	Honeywell	SEA Exchange
7000622-901	VG-14A	6615-01-479-4247	Vertical Gyro	Honeywell	SEA Exchange
7000700-665	AZ-800		Air Data Computer	Honeywell	OEM Dealer Repair
7000700-903	AZ-600		Air Data Computer	Honeywell	OEM Dealer Repair
7000700-923	AZ-800		Air Data Computer	Honeywell	OEM Dealer Repair
7000700-930	AZ-800		Air Data Computer	Honeywell	OEM Dealer Repair
7000700-975	AZ-810		Digital Air Data Computer	Honeywell	OEM Dealer Repair
7000788-175	GH-206		Horizon Gyro	Honeywell	OEM Dealer Repair
7000839-901	RA-315	5841-01-541-1622	Radio Altimeter Indicator	Honeywell	SEA Repair
7000839-902	RA-315	5841-01-582-3995	Radio Altitude Indicator	Honeywell	SEA Repair
7000839-903	RA-315		Radio Altimeter Indicator	Honeywell	SEA Repair
7000839-904	RA-335	5841-01-276-4232	Rad Alt Indicator	Honeywell	SEA Repair
7000839-905	RA-335		Rad. Alt. Indicator	Honeywell	SEA Repair
7000839-906	RA-315		Radio Altimeter Indicator	Honeywell	SEA Repair
7000839-922	RA-315		Radio Altimeter Indicator	Honeywell	SEA Repair
7000839-923	RA-335		Radio Alt Indicator	Honeywell	SEA Repair
7001840-901	RT-300	5841-01-003-1964	Radio Altimeter R/T	Honeywell	SEA Repair
7001840-902	RT-300	5841-01-003-1964	Radio Altimeter R/T	Honeywell	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
7001840-903	RT-300	5840-01-256-6113	Radio Altimeter Transceiver	Honeywell	SEA Repair
7001840-905	RT-300		Rad Alt Rec/ Trans	Honeywell	SEA Repair
7001840-906	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-911	RT-300		Radar Altimeter R/T	Honeywell	SEA Repair
7001840-912	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-913	RT-300	5840-01-480-2290	Radio Altimeter R/T	Honeywell	SEA Repair
7001840-915	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-916	RT-300		Rad. Alt. R/T	Honeywell	SEA Repair
7001840-917	RT-300	5841-01-003-1964	Radio Altimeter R/T	Honeywell	SEA Repair
7001840-918	RT-300	5841-01-483-1843	Radio Altimeter R/T	Honeywell	SEA Repair
7001840-922	RT-300	5841-01-423-9247	Radio Altimeter Transceiver	Honeywell	SEA Repair
7001840-924	RT-300		RAD. ALT. R/T	Honeywell	SEA Repair
7001840-926	RT-300		Radio Altimeter	Honeywell	SEA Repair
7001840-928	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-931	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-932	RT-300	5821-01-610-1611	Radio Altimeter Transceiver	Honeywell	SEA Repair
7001840-934	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-936	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7001840-937	RT-300		Radio Altimeter R/T	Honeywell	SEA Repair
7002353-902	AZ-649	6610-01-415-5877	Air Data Computer	Honeywell	OEM Dealer Repair
7002353-911	AZ-649	6605-01-439-7590	Air Data Computer	Honeywell	OEM Dealer Repair
7002412-902	AL-200	5895-01-439-7596	Alt Alert Controller	Honeywell	OEM Dealer Repair
7002412-906	AL-300	6610-01-428-3285	Altitude Preselect Controller	Honeywell	OEM Dealer Repair
7003110-901	ED-800	7025-01-423-9258	EFIS Display	Honeywell	SEA Exchange
7003110-902	ED-800	7025-01-394-6537	EFIS Display	Honeywell	SEA Exchange
7003110-912	ED-800		EFIS Display	Honeywell	SEA Exchange
7003180-904	SZ-400		Stab Augmentation Computer	Honeywell	OEM Dealer Repair
7003183-903	FZ-700		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7003183-914	FZ-700		Helipilot Computer	Honeywell	OEM Dealer Repair
7003183-932	FZ-700		AFCS Comp.	Honeywell	OEM Dealer Repair
7003360-941	AH-600	7021-01-269-3243	AHARS Computer	Honeywell	OEM Dealer Repair
7003400-624	SG-603		EFIS Symbol Generator	Honeywell	OEM Dealer Repair
7003430-902	ED-600	6615-01-421-7368	EFIS Display	Honeywell	OEM Dealer Repair
7003652-611	ID-802	7025-01-423-9253	Flight Advisory Panel	Honeywell	OEM Dealer Repair
7003897-902	PC-400	6615-01-439-7593	Autopilot Control	Honeywell	OEM Dealer Repair
7003938-906	MS-400	6615-01-439-7597	Mode Selector	Honeywell	OEM Dealer Repair
7003938-908	MS-400		Mode Selector	Honeywell	OEM Dealer Repair
7003974-730	FZ-800	6615-01-487-6257	Flight Guidance Computer	Honeywell	OEM Dealer Repair
7003975-901	GC-800		Guidance Controller	Honeywell	OEM Dealer Repair
7004110-901	SM-510		Roll Control Rod Assy.	Honeywell	OEM Dealer Repair
7004126-901	FZ-400		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7004206-901	SP-717		CSAS Computer	Honeywell	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
7004536-915	MS-500A		Mode Selector	Honeywell	OEM Dealer Repair
7004544-712	SG-811		Symbol Generator	Honeywell	OEM Dealer Repair
7007453-902	RG-204		Rate Gyro	Honeywell	OEM Dealer Repair
7007549-901	CD-810		Control Display Unit	Honeywell	OEM Dealer Repair
7007549-906	CD-810		Control Display Unit	Honeywell	OEM Dealer Repair
7008138-903	FZ-710		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7009330-901	WR-700	5821-01-439-7152	Radar R/T	Honeywell	SEA Exchange
7009330-911	WR-700A	5821-01-522-5712	Radar R/T	Honeywell	SEA Exchange
7010133	FX-600		Flux Valve	Honeywell	OEM Dealer Repair
7010680-902	FZ-450		Digital Flight Control Computer	Honeywell	OEM Dealer Repair
7010680-903	FZ-450		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7010680-905	FZ-450		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7011672-100	SG-805		Symbol Generator	Honeywell	OEM Dealer Repair
7011672-708	SG-705	6610-01-428-3303	Symbol Generator	Honeywell	OEM Dealer Repair
7011672-709	SG-705		Symbol Generator	Honeywell	OEM Dealer Repair
7011672-780	SG-705		Symbol Generator	Honeywell	OEM Dealer Repair
7011672-781	SG-705		Symbol Generator	Honeywell	OEM Dealer Repair
7011672-782	SG-705		Symbol Generator	Honeywell	OEM Dealer Repair
7011673-606	MG-605		Multifunction Generator	Honeywell	OEM Dealer Repair
7011673-661	MG-605		Multifunction Generator	Honeywell	OEM Dealer Repair
7011673-807	MG-805		Multifunction Generator	Honeywell	OEM Dealer Repair
7011702-946	GC-810		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7011822-903	LP-850		Lightning Receiver/Processor	Honeywell	OEM Dealer Repair
7011822-904	LP-860	5865-01-514-0258	Lightning Sensor Processor	Honeywell	OEM Dealer Repair
7012100-811	RM-850		Radio Management Unit	Honeywell	OEM Dealer Repair
7012100-954	RM-850		Radio Management Unit	Honeywell	OEM Dealer Repair
7012693-901	RQ-710		Yaw Servo monitor	Honeywell	OEM Dealer Repair
7012977-734	DC-811		EFIS Display Controller	Honeywell	OEM Dealer Repair
7012977-748	DC-811		EFIS Display Controller	Honeywell	OEM Dealer Repair
7012977-772	DC-811		EFIS Display Controller	Honeywell	OEM Dealer Repair
7012977-986	DC-811		EFIS Display Controller	Honeywell	OEM Dealer Repair
7013348-951	DAU-800		Data Acquisition Unit	Honeywell	OEM Dealer Repair
7014300-901	DU-870	702501-483-4089	Display Unit	Honeywell	SEA Exchange
7014300-902	DU-870		Display Unit	Honeywell	SEA Exchange
7015480-902	FZ-706		Digital Flight Control Computer	Honeywell	OEM Dealer Repair
7015480-903	FZ-706		Flight Guidance Computer	Honeywell	OEM Dealer Repair
7018879-03014	NZ-2000		Navigation Computer	Honeywell	OEM Dealer Repair
7021450-601	WU-660	5985-01-532-4218	Radar Transceiver	Honeywell	SEA Repair
7024440-1901	PWR-902		Power Supply Module Assembly	Honeywell	OEM Dealer Repair
70256N02D02	AM-250		Digital Encoding Altimeter	Honeywell	SEA Exchange
7025725-941	MC-850		Multi Purpose Control	Honeywell	OEM Dealer Repair
70259N01D01	AM-250		Digital Encoding Altimeter (TBM700)	Honeywell	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
7027110-904	PC-770		Autopilot Controller	Honeywell	OEM Dealer Repair
7029194-1901			INPUT/OUTPUT Processor	Honeywell	OEM Dealer Repair
7037620-814	DU-1080		Display Unit	Honeywell	OEM Dealer Repair
7510100-931	RNZ-850		Integrated Nav Unit	Honeywell	OEM Dealer Repair
7510184-855	DM-855		DME Module - EPIC	Honeywell	OEM Dealer Repair
7510300-901	AT-860	5985-01-499-6079	ADF Antenna	Honeywell	OEM Dealer Repair
7510700-665	RCZ-833K	5895-01-544-0324	Integrated Comm Transceiver	Honeywell	OEM Dealer Repair
7510700-727	RCZ-854		Integrated Comm Unit	Honeywell	OEM Dealer Repair
7510700-806			Comm Unit	Honeywell	OEM Dealer Repair
7510700-901	RCZ-850		Integrated Communication Unit	Honeywell	OEM Dealer Repair
7510700-951	RCZ-852	5826-01-618-5020	Mode S Transponder	Honeywell	OEM Dealer Repair
7511000-908	AV-850		Audio Control Panel	Honeywell	OEM Dealer Repair
7511900-99001	AV900		Audio Panel	Honeywell	OEM Dealer Repair
7513000-902	CD-850		Control Head	Honeywell	OEM Dealer Repair
7513006-904	DI-851		DME Indicator	Honeywell	OEM Dealer Repair
7514081-901	AT-910	5985-01-521-0300	TCAS Antenna w/ Mounting Plate	ACSS	OEM Dealer Repair
7514081-910	AT-910	5985-01-482-4812	TCAS Antenna w/ Mounting Plate	ACSS	OEM Dealer Repair
777-1493-001	614L-11	5826-01-124-2598	ADF Control	Collins	SEA Repair
777-1493-002	614L-11		ADF Control	Collins	SEA Repair
777-1493-003	614L-11	5826-01-051-2577	ADF Control	Collins	SEA Repair
777-1493-004	614L-11	4920-01-439-7376	ADF Control	Collins	SEA Repair
777-1493-005	614L-11		ADF Control	Collins	SEA Repair
777-1493-006	614L-11	5826-00-269-5362	ADF Control	Collins	SEA Repair
777-1493-007	614L-11	5826-01-367-2530	ADF Control	Collins	SEA Repair
777-1493-008	614L-11		ADF Control	Collins	SEA Repair
777-1493-009	614L-11		ADF Control	Collins	SEA Repair
777-1493-010	614L-11		ADF CONTROL	Collins	SEA Repair
787-6366-001	614L-12		ADF Control	Collins	SEA Repair
787-6366-002	614L-12		ADF Control	Collins	SEA Repair
787-6366-003	614L-12		ADF Control	Collins	SEA Repair
787-6366-004	614L-12		ADF Control	Collins	SEA Repair
787-6366-005	614L-12		ADF Control	Collins	SEA Repair
787-6366-006	614L-12		ADF Control	Collins	SEA Repair
787-6366-007	614L-12		ADF Control	Collins	SEA Repair
787-6366-008	614L-12		ADF Control	Collins	SEA Repair
787-6366-009	614L-12		ADF Control	Collins	SEA Repair
787-6366-010	614L-12		ADF Control	Collins	SEA Repair
787-6366-011	614L-12		ADF Control	Collins	SEA Repair
787-6366-012	614L-12		ADF Control	Collins	SEA Repair
792-6091-012	331A-9G		Horizontal Situation Indicator	Collins	SEA Exchange
792-6091-013	331A-9G		Horizontal Situation Indicator	Collins	SEA Exchange
792-6091-015	331A-9G		Horizontal Situation Indicator	Collins	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
792-6091-016	331A-9G	6605-01-472-2662	Horizontal Situation Indicator	Collins	SEA Exchange
792-6275-001	614L-13		ADF Control	Collins	SEA Repair
792-6275-002	614L-13	5826-01-065-1759	ADF Control	Collins	SEA Repair
792-6275-003	614L-13		ADF Control	Collins	SEA Repair
792-6275-004	614L-13		ADF Control	Collins	SEA Repair
792-6275-005	614L-13		ADF Control	Collins	SEA Repair
792-6275-006	614L-13		ADF Control	Collins	SEA Repair
792-6275-007	614L-13	5825-01-020-3865	ADF Control	Collins	SEA Repair
792-6275-008	614L-13		ADF Control	Collins	SEA Repair
792-6657-001	VHF-20	5821-01-041-2708	VHF Comm R/T	Collins	SEA Repair
792-6657-002	VHF-20		VHF Comm R/T	Collins	SEA Repair
792-6657-003	VHF-20	5821-01-332-0386	VHF Comm R/T	Collins	SEA Repair
792-6657-004	VHF-20		VHF Comm R/T	Collins	SEA Repair
792-6686-001	37R-2W		UHF/VHF Antenna	Collins	SEA Repair
792-6694-001	332D-11A	5826-00-348-3874	Vertical Gyro	Collins	SEA Exchange
805-10800-001	TRC497		Skywatch R/T Computer		SEA Exchange
805-11500-001	WX-500	5999-01-533-8554	Stormscope Processor		SEA Exchange
805-11900-001	TRC899	5826-01-608-1052	Transmitter/Receiver Computer		SEA Exchange
8095536-8101	RS-811A		Radar Sensor	Honeywell	SEA Repair
8095537-8101	IN-812A		Radar Indicator	Honeywell	SEA Repair
8095537-8102	IN-812A		Radar Indicator	Honeywell	SEA Repair
81438-00-242N	2000 Approach		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81438-02-240B	2000 Approach Plus		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81438-02-240D	2000 Approach Plus		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81438-02-240M	2000 Approach Plus		TNL GPS Receiver	Free Flight	OEM Dealer Repair
81438-02-240N	2000 Approach Plus		GPS Receiver	Free Flight	OEM Dealer Repair
81439-00-0232	TNL2101		GPS Receiver	Free Flight	OEM Dealer Repair
81439-00-0237	TNL2101		GPS Receiver	Free Flight	OEM Dealer Repair
81439-00-242P	TNL 2100T		GPS Receiver	Free Flight	OEM Dealer Repair
81439-02-240B	2101 Approach Plus		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81439-02-240D	2101 Approach Plus		IFR GPS Receiver (unit only) - Black	Free Flight	OEM Dealer Repair
81439-02-240M	2101 Approach Plus		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81439-02-240N	2101 Approach Plus		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81439-02-240P	2101 Approach Plus		IFR GPS Receiver	Free Flight	SEA Exchange
81439-03-240B	2101 Approach Plus		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81439-03-240D	2101 Approach Plus		IFR GPS Receiver (unit only) - Gray	Free Flight	OEM Dealer Repair
81440-00-0233	TNL2101 I/O		GPS Receiver	Free Flight	OEM Dealer Repair
81440-01-243P	2101 I/O Approach +		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81440-02-241B	2101 I/O Approach +		GPS Receiver	Free Flight	OEM Dealer Repair
81440-02-241D	TNL 2101 I/O App+		IFR GPS Receiver (unit only)	Free Flight	OEM Dealer Repair
81440-02-241M	2101 I/O Approach +		IFR GPS Receiver (unit only)	Free Flight	OEM Dealer Repair
81440-02-241N	2101 I/O Approach +		IFR GPS Receiver	Free Flight	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
81440-02-241P	2101 I/O Approach +		IFR GPS Receiver	Free Flight	SEA Exchange
81440-03-241P	2101 I/O Approach +		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81440-12-241N	2101 I/O Approach +		IFR GPS Receiver (NVG)	Free Flight	OEM Dealer Repair
81440-12-241P	2101 I/O Approach +		IFR GPS Receiver (NVG)	Free Flight	OEM Dealer Repair
81440-32-241J	2101 I/O Approach +		IFR GPS Receiver (Unit only) - Black	Free Flight	OEM Dealer Repair
81440-32-241M	2101 I/O Approach +		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81440-32-241N	2101 I/O Approach +		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81440-32-241P	2101 I/O Approach +		IFR GPS Receiver	Free Flight	SEA Exchange
81440-42-241J	2101 I/O Approach +		IFR GPS Receiver	Free Flight	OEM Dealer Repair
81440-42-241P	2101 I/O Approach +		IFR GPS Receiver (NVG)	Free Flight	OEM Dealer Repair
822-0021-102	CDU-4100		Control Display Unit	Collins	OEM Dealer Repair
822-0044-001	FCP-4002		Flight Control Panel	Collins	OEM Dealer Repair
822-0336-001	TPR-900		Mode S Transponder	Collins	OEM Dealer Repair
822-0389-433	ADC-850D		Air Data Computer	Collins	OEM Dealer Repair
822-0416-001	IND-270A		Color Radar Indicator	Collins	SEA Repair
822-0615-002	ALT-4000	5826-01-594-1533	Radar Altimeter	Collins	OEM Dealer Repair
822-0615-101	ALT-4000	5841-01-531-3159	Radar Altimeter	Collins	OEM Dealer Repair
822-0615-305	ALT-4000		Radio Altimeter R/T	Collins	OEM Dealer Repair
822-0668-011	RTU-4200		Radio Tuning Unit	Collins	OEM Dealer Repair
822-0668-031	RTU-4200		Radio Tuning Unit	Collins	OEM Dealer Repair
822-0730-112	RTU-4220		Radio Tuning Unit	Collins	OEM Dealer Repair
822-0730-132	RTU-4220		Radio Tuning Unit	Collins	OEM Dealer Repair
822-0783-011	FMC-4200		Flight Management Computer	Collins	OEM Dealer Repair
822-0883-048	FMC-3000		Flight Management Computer FMC-3000	Collins	OEM Dealer Repair
822-0884-191	CDU-3000		Control Display Unit	Collins	OEM Dealer Repair
822-0891-005	FMC-5000		Flight Management Computer	Collins	OEM Dealer Repair
822-1019-313	FCC-4007		Flight Control Computer	Collins	OEM Dealer Repair
822-1036-466	ADC-850F		Air Data Computer	Collins	OEM Dealer Repair
822-1107-103	FGP-3000		Flight Guidance Panel	Collins	OEM Dealer Repair
822-1109-002	ADC-3000		Air Data Computer	Collins	OEM Dealer Repair
822-1109-011	ADC-3000		Air Data Computer	Collins	OEM Dealer Repair
822-1113-001	VHF-22C	5821-01-587-6175	8.33 VHF Comm	Collins	SEA Repair
822-1113-021	VHF-22C		8.33 VHF Comm	Collins	SEA Repair
822-1113-023	VHF-22C		8.33 VHF Comm	Collins	SEA Repair
822-1114-001	VHF-22D	5821-01-467-8793	8.33 VHF Comm (Ext. Range)	Collins	SEA Repair
822-1114-021	VHF-22D	5821-01-484-2068	VHF Comm (8.33)	Collins	SEA Repair
822-1114-023	VHF-22D		VHF Comm Transceiver w/8.33 kHz spacing	Collins	SEA Repair
822-1115-001	VHF-422C		8.33 VHF Comm	Collins	SEA Repair
822-1115-021	VHF-422C		8.33 VHF Comm	Collins	SEA Repair
822-1115-023	VHF-422C		8.33 VHF Comm	Collins	SEA Repair
822-1116-001	VHF-422D	5821-01-468-7785	8.33 VHF Comm	Collins	SEA Repair
822-1116-021	VHF-422D	5821-01-564-9215	8.33 VHF Comm	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
822-1116-023	VHF-422D		8.33 VHF Comm	Collins	SEA Repair
822-1120-001	CTL-22C		8.33 VHF Comm Control	Collins	SEA Repair
822-1120-002	CTL-22C		8.33 VHF Comm Control	Collins	SEA Repair
822-1120-003	CTL-22C		8.33 VHF Comm Control	Collins	SEA Repair
822-1120-004	CTL-22C		8.33 VHF Comm Control	Collins	SEA Repair
822-1120-005	CTL-22C	5821-01-467-8794	8.33 Comm Control	Collins	SEA Repair
822-1120-006	CTL-22C		8.33 Comm Control	Collins	SEA Repair
822-1120-007	CTL-22C	5895-01-484-2102	8.33 Comm Control	Collins	SEA Repair
822-1120-008	CTL-22C	5826-01-471-8067	8.33 Comm Control	Collins	SEA Repair
822-1120-009	CTL-22C		8.33 VHF Comm Control	Collins	SEA Repair
822-1120-010	CTL-22C		VHF Communication Control	Collins	SEA Repair
822-1279-003	CHP-3000		Course Heading Panel	Collins	OEM Dealer Repair
822-1294-002	TTR-4000	5895-01-499-4902	TCAS R/T 4MCU AC/DC	Collins	OEM Dealer Repair
822-1466-001	DME-4000	5826-01-524-9585	Distance Measuring Equipment	Collins	OEM Dealer Repair
822-1719-003	DCP-2000		Display Control Panel	Collins	OEM Dealer Repair
822-1987-005	MDC-3110		Maintenance Diagnostic Computer	Collins	OEM Dealer Repair
822-1988-024	MDC-4110		Maintenance Diagnostic Computer	Collins	OEM Dealer Repair
822-2175-001	CTL-22D		8.33 Comm Control	Collins	SEA Repair
822-2175-003	CTL-22D	5821-01-564-9216	8.33 Comm Control	Collins	SEA Repair
822-2175-005	CTL-22D		8.33 Comm Control	Collins	SEA Repair
822-2175-007	CTL-22D	5821-01-564-9213	8.33 Comm Control	Collins	SEA Repair
822-2175-009	CTL-22D		8.33 Comm Control	Collins	SEA Repair
822-2176-001	CTL-22G		Comm Control	Collins	SEA Repair
822-2176-003	CTL-22G		Comm Control	Collins	SEA Repair
822-2176-005	CTL-22G		Comm Control	Collins	SEA Repair
822-2176-007	CTL-22G		Comm Control	Collins	SEA Repair
822-2176-009	CTL-22G		Comm Control	Collins	SEA Repair
822-2179-001	CTL-32G		Nav Control	Collins	SEA Repair
822-2179-005	CTL-32G		Nav Control	Collins	SEA Repair
822-2179-007	CTL-32G		Nav Control	Collins	SEA Repair
822-2179-009	CTL-32G		Nav Control	Collins	SEA Repair
822-2179-011	CTL-32G	6605-01-572-8686	Nav Control	Collins	SEA Repair
822-2179-013	CTL-32G		Nav Control	Collins	SEA Repair
822-2179-015	CTL-32G	6605-01-562-4242	Nav Control	Collins	SEA Repair
822-2179-025	CTL-32G		Nav Control	Collins	SEA Repair
822-2180-001	CTL-62G		ADF Control	Collins	SEA Repair
822-2180-003	CTL-62G	6605-01-550-6152	ADF Control	Collins	SEA Repair
822-2180-005	CTL-62G		ADF Control	Collins	SEA Repair
822-2180-007	CTL-62G	6605-01-562-4243	ADF Control	Collins	SEA Repair
822-2180-009	CTL-62G		ADF Control	Collins	SEA Repair
822-2180-011	CTL-62G		ADF Control	Collins	SEA Repair
822-2180-013	CTL-62G		ADF Control	Collins	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
822-2180-015	CTL-62G		ADF Control	Collins	SEA Repair
822-2180-017	CTL-62G		ADF Control	Collins	SEA Repair
822-2181-201	CTL-92G		Transponder Control	Collins	SEA Repair
822-2181-203	CTL-92G	6605-01-572-8731	Transponder Control	Collins	SEA Repair
822-2181-205	CTL-92G		Transponder Control	Collins	SEA Repair
822-2181-207	CTL-92G		Transponder Control	Collins	SEA Repair
822-2181-213	CTL-92G		Transponder Control	Collins	SEA Repair
822-2189-002	GPS-4000S	5895-01-590-1329	GPS Receiver with SBAS (WAAS)	Collins	OEM Dealer Repair
822-2189-004	GPS-4000S	5826-01-610-5148	GPS Receiver with SBAS (WAAS)	Collins	OEM Dealer Repair
822-2189-005	GPS-4000S	5826-01-613-6417	GPS Receiver with SBAS (WAAS)	Collins	OEM Dealer Repair
822-2189-010	GPS-4000S	5826-01-621-4426	GPS Receiver with SBAS (WAAS)	Collins	OEM Dealer Repair
84100-02-0304	1201		GPS/WAAS 1201 Sensor	Free Flight	OEM Dealer Repair
84100-02-0306	1201		WAAS GPS Receiver	Free Flight	OEM Dealer Repair
84100-03-0304	1201		GPS/WAAS Sensor (unit only)	Free Flight	OEM Dealer Repair
84100-03-0306	1201		GPS/WAAS Sensor - Unit Only	Free Flight	OEM Dealer Repair
84560-01-200B	RA-4000		Radio Altimeter Sensor	Free Flight	OEM Dealer Repair
84560-11-300A	RA-4000		Radar Altimeter Transceiver	Free Flight	OEM Dealer Repair
84560-12-300A	RA-4500		Radio Altimeter Transceiver	Free Flight	OEM Dealer Repair
84939-10-0100	RAD40		Radar Altimeter Display (NVG)	Free Flight	OEM Dealer Repair
921012-1	TFM-138		VHF FM Transceiver - 138 - 174 MHz	Technisonic	SEA Repair
921012-1	TFM-138B		VHF FM Transceiver - 138 - 174 MHz - Option B	Technisonic	SEA Repair
921012-1 (5V)	TFM-138		VHF FM Transceiver - 138 - 174 MHz	Technisonic	SEA Repair
921012-1 (5V)	TFM-138B		VHF FM Transceiver - 138 - 174 MHz - Option B	Technisonic	SEA Repair
921012-2	TFM-138		VHF FM Transceiver - 138 - 174 MHz	Technisonic	SEA Repair
921012-2	TFM-138B		VHF FM Transceiver - 138 - 174 MHz - Option B	Technisonic	SEA Repair
921012-2 (5V)	TFM-138		VHF FM Transceiver - 138 - 174 MHz	Technisonic	SEA Repair
921012-2 (5V)	TFM-138B		VHF FM Transceiver - 138 - 174 MHz - Option B	Technisonic	SEA Repair
93A055-03	A553		CVR MIC	L3 Communications	SEA Repair
93A055-04	A55B	5965-01-130-0762	MIC	L3 Communications	SEA Repair
93A055-30	A55B		MIC	L3 Communications	SEA Repair
93A055-40	A55B	5965-01-227-3689	Remote Microphone	L3 Communications	SEA Repair
93A055-60	A55B		Remote Mic	L3 Communications	SEA Repair
93A055-67	A55B	5965-01-422-7638	CVR Microphone	L3 Communications	SEA Repair
93A055-95	A55B		CVR Microphone (Pigtail)	L3 Communications	SEA Repair
93A151-20	A151B	5895-01-234-5862	CVR Control	L3 Communications	SEA Repair
93A151-30	A151B	5895-01-122-2751	CVR Control	L3 Communications	SEA Repair
93A151-40	A151B		CVR Control	L3 Communications	SEA Repair
93A152-00	A-152	5835-00-019-1816	CVR Control Unit	L3 Communications	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
93A152-04	A152		CVR Control	L3 Communications	SEA Repair
93A152-20	A152B	5835-01-601-3416	CVR Control w/ Microphone	L3 Communications	SEA Repair
93A152-25	A152B		CVR Control	L3 Communications	SEA Repair
93A152-30	A152B		CVR Control w/ Microphone	L3 Communications	SEA Repair
93A152-40	A152B		CVR Control w/ Microphone	Honeywell	SEA Repair
93A152-60	A152B		CVR Control w/ Microphone	L3 Communications	SEA Repair
93A152-70	A152B		CVR Control w/ Microphone	L3 Communications	SEA Repair
941059-1	TFM-403		UHF/FM Transceiver - 403 - 512 MHz	Technisonic	SEA Repair
941059-1 (5V)	TFM-403		UHF/FM Transceiver - 403 - 512 MHz	Technisonic	SEA Repair
941059-2	TFM-403		UHF/FM Transceiver - 403 - 512 MHz	Technisonic	SEA Repair
941059-2 (5V)	TFM-403		UHF/FM Transceiver - 403 - 512 MHz	Technisonic	SEA Repair
961082-1	TFM-30		FM Low Band Transceiver - 30 - 50 MHz	Technisonic	SEA Repair
961082-1 (5V)	TFM-30		FM Low Band Transceiver - 30 - 50 MHz	Technisonic	SEA Repair
961082-2	TFM-30		FM Low Band Transceiver - 30 - 50 MHz	Technisonic	SEA Repair
961082-2 (5V)	TFM-30		FM Low Band Transceiver - 30 - 50 MHz	Technisonic	SEA Repair
971083-1	TFM-500		VHF/UHF Transceiver 138-174 - 403-512 MHz	Technisonic	SEA Exchange
990-3138-000	M1090		CVR Adapter/Mixer	Honeywell	SEA Repair
990-3338-000	M1091	6110-01-502-5356	Audio Amplifier	Honeywell	SEA Exchange
991095-1	TFM-550		VHF/UHF Transceiver - 30-50 - 138-174 - 403-512 MHz	Technisonic	SEA Repair
991095-1 (5V)	TFM-550		VHF/UHF Transceiver - 30-50 - 138-174 - 403-512 MHz	Technisonic	SEA Repair
991095-2	TFM-550		VHF/UHF Transceiver - 30-50 - 138-174 - 403-512 MHz	Technisonic	SEA Repair
991095-2 (5V)	TFM-550		VHF/UHF Transceiver - 30-50 - 138-174 - 403-512 MHz	Technisonic	SEA Repair
A301-61A	A30161A	5895-01-422-3263	Audio Panel	Andrea	SEA Exchange
A301-61B-1	A301-61B1	5895-01-422-3797	Audio Panel	Andrea	SEA Exchange
A301-6W	A3016W	5831-01-477-6896	Audio Panel	Andrea	SEA Exchange
AA12S-002	AA12S		Audio Controller	AEM	SEA Exchange
AA24-001	AA24001		Audio Controller	AEM	SEA Exchange
AA25-001	AA25001		Audio Controller	AEM	SEA Exchange
AMS42	AMS-42		Audio Controller/ Dual Channel	AEM	SEA Exchange
AMS42F	AMS-42F		Multi-User Audio Controller	AEM	SEA Exchange
AMS43	AMS-43		Audio Controller	AEM	SEA Exchange
AMS43TSO	AMS-43TSO		Audio Controller	Cobham	SEA Exchange
AMS44	AMS-44		Audio Controller - Dual Channel	AEM	SEA Exchange
AMS44T	AMS-44T		Multi-User Audio Controller	AEM	SEA Exchange
CP1976A1	704A45-360-072		Audio Control Panel	TEAM	SEA Exchange
D51506	900/D51506	5365-00-469-4036	CVFDR - Voice/Data Recorder	Penny & Giles	SEA Exchange
D51508	900/D51508		CVFDR - Voice/Data Recorder	Penny & Giles	SEA Exchange

Part Number	Model	NSN	Description	Manufacturer	Capability
D51615-102	MPFR		Multi Purpose CVR/FDR	Penny & Giles	SEA Exchange
G7622-001	CTL-22D		8.33 Comm Control	Collins	SEA Repair
G7622-101	CTL-22G		Comm Control	Collins	SEA Repair
G7622-102	CTL-22G		Comm Control	Collins	SEA Repair
G7622-103	CTL-22G		Comm Control	Collins	SEA Repair
G7622-104	CTL-22G		Comm Control	Collins	SEA Repair
G7622-105	CTL-22G		Comm Control	Collins	SEA Repair
G7622-112	CTL-22D		8.33 Comm Control	Collins	SEA Repair
G7622-113	CTL-22D		8.33 Comm Control	Collins	SEA Repair
G7622-114	CTL-22D		8.33 Comm Control	Collins	SEA Repair
G7622-115	CTL-22D		8.33 Comm Control	Collins	SEA Repair
G7632-101	CTL-32G		Nav Control	Collins	SEA Repair
G7632-103	CTL-32G		Nav Control	Collins	SEA Repair
G7632-104	CTL-32G		Nav Control	Collins	SEA Repair
G7632-105	CTL-32G		Nav Control	Collins	SEA Repair
G7632-106	CTL-32G		Nav Control	Collins	SEA Repair
G7632-107	CTL-32G		Nav Control	Collins	SEA Repair
G7632-108	CTL-32G		Nav Control	Collins	SEA Repair
G7632-115	CTL-32G		Nav Control	Collins	SEA Repair
G7662-101	CTL-62G		ADF Control	Collins	SEA Repair
G7662-102	CTL-62G		ADF Control	Collins	SEA Repair
G7662-103	CTL-62G		ADF Control	Collins	SEA Repair
G7662-104	CTL-62G		ADF Control	Collins	SEA Repair
G7662-105	CTL-62G		ADF Control	Collins	SEA Repair
G7662-106	CTL-62G		ADF Control	Collins	SEA Repair
G7662-107	CTL-62G		ADF Control	Collins	SEA Repair
G7662-108	CTL-62G		ADF Control	Collins	SEA Repair
G7662-111	CTL-62G		ADF Control	Collins	SEA Repair
G7692-121	CTL-92G		Transponder Control	Collins	SEA Repair
G7692-122	CTL-92G		Transponder Control	Collins	SEA Repair
G7692-123	CTL-92G		Transponder Control	Collins	SEA Repair
G7692-124	CTL-92G		Transponder Control	Collins	SEA Repair
G7692-127	CTL-92G		Transponder Control	Collins	SEA Repair
H140ABM2	H140ABM2		Horizon Gyro	Thales	SEA Exchange
H140JIM1	H140JIM1		Attitude Gyro	Thales	SEA Exchange
H321ABM1	H321ABM1		Gyro	Thales	SEA Exchange
H321CMM	H321CMM		Horizon Gyro	Thales	SEA Exchange
KCA0104W	KCA-0104W	6605-00-452-6355	Compass	Smiths Industries	SEA Exchange
KCA0113W	KCA0113W		Compass	Smiths Industries	SEA Exchange
MI-585200	RT-4001		Radar Transceiver	Honeywell	SEA Repair
MI-585200-1	RT-4001		Radar R/T	Honeywell	SEA Repair
MI-585201	DI-4001		Radar Indicator	Honeywell	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
MI-585201-1	DI-4001		Radar Indicator	Honeywell	SEA Repair
MI-585201-3	DI-4001		Radar Indicator	Honeywell	SEA Repair
MI-585202	AP-4001		Radar Antenna	Honeywell	SEA Repair
MI-585202-1	AP-4001		ANTENNA PEDESTAL	Honeywell	SEA Repair
MI-585222-1	RT-3002		Radar Transceiver	Honeywell	SEA Repair
MI-585224	AP-3001		Radar Antenna	Honeywell	SEA Repair
MI-585224-1	AP-3001		Radar Antenna	Honeywell	SEA Repair
MI-585224-2	AP-3001		Radar Antenna (P300)	Honeywell	SEA Repair
MI-585224-3	AP-3001		P300 Antenna	Honeywell	SEA Repair
MI-585228	DI-3003		Radar Indicator	Honeywell	SEA Repair
MI-585228-1	DI-3003		Radar Indicator	Honeywell	SEA Repair
MI-585228-2	DI-3003		RADAR IND	Honeywell	SEA Repair
MI-585228-3	DI-3003		RADAR INDICATOR	Honeywell	SEA Repair
MI-585277	DI-2007		Radar Indicator	Honeywell	SEA Repair
MI-585277-1	DI-2007		Color Radar Indicator	Honeywell	SEA Repair
MI-585277-2	DI-2008		Color Radar Indicator (Gray)	Honeywell	SEA Repair
MI-585277-3	DI-2008		Color Radar Indicator (Black)	Honeywell	SEA Repair
MI-585277-4	DI-2007		Radar Indicator	Honeywell	SEA Repair
MI-585277-5	DI-2007		Radar Indicator	Honeywell	SEA Repair
MI-585300	RT-5001		Radar Transceiver	Honeywell	SEA Repair
MI-585300-1	RT-5001		Radar Transceiver	Honeywell	SEA Repair
MI-585300-4	RT-5001		Radar Transceiver	Honeywell	SEA Repair
MI-585301	DI-5001		Radar Indicator	Honeywell	SEA Repair
MI-585301-1	DI-5001		Radar Indicator	Honeywell	SEA Repair
MI-585301-2	DI-5001		Radar Indicator	Honeywell	SEA Repair
MI-585301-3	DI-5001		Radar Indicator	Honeywell	SEA Repair
MI-585302	AP-5001		Radar Antenna	Honeywell	SEA Repair
MI-585302-1	AP-5001		Radar Antenna	Honeywell	SEA Repair
MI-585343	DI-4002		Radar Indicator (Gray)	Honeywell	SEA Repair
MI-585343-1	DI-4002		Radar Indicator (Black)	Honeywell	SEA Repair
MI-585467	WA-700	5985-01-439-7154	Antenna Pedestal		SEA Exchange
N301A-000	N301A		Audio Controller	Cobham	SEA Exchange
NPX138N-000	NPX138N		Panel Mount FM Transceiver	Cobham	SEA Exchange
NPX138N-070	NPX138N		Panel Mount FM Radio (Prog. Guard)	Cobham	SEA Exchange
NPX138N-500	NPX138N		Panel Mount FM Transceiver	Cobham	SEA Exchange
P-20	P-20		INVERTER	L3 Communications	SEA Repair
PC-125	PC125	8415-00-634-5278	Static Inverter	Marathon	SEA Repair
PC-14	PC-14	6130-00-085-2960	Static Inverter	Marathon	SEA Repair
PC-14A	PC-14A		INVERTER	Marathon	SEA Repair
PC-14C	PC14C	6130-01-450-5293	STATIC INVERTER 100VA	Marathon	SEA Repair
PC-14D	PC14D		Static Inverter	Marathon	SEA Repair
PC-15B	PC-15B	6130-01-005-3827	INVERTER	Marathon	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
PC-15BC	PC15BC		Static Inverter	Marathon	SEA Repair
PC-15BC(D)	PC-15BC(D)		Static Inverter	Marathon	SEA Repair
PC-15H	PC-15H		Inverter	Marathon	SEA Repair
PC-15H(F)	PC-15H(F)		Inverter	Marathon	SEA Repair
PC-16	PC16	5310-00-983-8485	Static Inverter	Marathon	SEA Repair
PC-16-2	PC-16-2	6130-01-202-4587	INVERTER	Marathon	SEA Repair
PC-16-3	PC-16-3		STATIC INVERTER	Marathon	SEA Repair
PC-17	PC17	4810-00-149-0815	Static Inverter	Marathon	SEA Repair
PC-17-3	PC17-3	5999-01-082-0403	Static Inverter	Marathon	SEA Repair
PC-17A	PC17A	6130-01-020-3951	Static Inverter	Marathon	SEA Repair
PC-250	PC-250	3020-00-204-2828	Inverter	Marathon	SEA Repair
PC-251	PC251	2930-00-043-2339	Static Inverter	Marathon	SEA Repair
PC-251-1C	PC2511C	6130-01-178-7678	Static Inverter	Marathon	SEA Repair
PC-350	PC350	2930-00-848-0522	Inverter	Marathon	SEA Repair
PC-6	PC-6	6210-00-163-3593	STATIC INVERTER	Marathon	SEA Repair
PC-6B	PC6B		Dc to DC Converter 12V to 24V	Marathon	SEA Repair
PMA6000M-S			Audio Panel (Stereo)	PS Engineering	OEM Dealer Repair
PMA7000B	PMA7000B		Stereo Audio Panel w/ Marker Beacon	PS Engineering	SEA Exchange
PMA7000B Option3	PMA7000B		Audio Selector Panel	PS Engineering	OEM Dealer Repair
PMA7000CD	PMA-7000CD		Audio Panel	PS Engineering	OEM Dealer Repair
PMA7000M-S	PMA7000MS		Stereo Audio Panel w/ Marker	PS Engineering	OEM Dealer Repair
PTA12-000	PTA-12		Airborne Telephone Adapter	Cobham	SEA Exchange
PTA12-100	PTA-12		Airborne Telephone Adapter w/ Display	Cobham	SEA Exchange
S055-0030-00	S055		Remote Microphone Module	L3 Communications	SEA Repair
S055-0065-00	S055	5965-01-526-4758	Remote Microphone Module	L3 Communications	SEA Repair
S055-0066-00	S055		Remote Microphone Module	L3 Communications	SEA Repair
S055-0067-00	S055	5965-01-520-3772	Remote Microphone Module	L3 Communications	SEA Repair
S055-0067-01	S055		Remote Microphone Module	L3 Communications	SEA Repair
S055-0068-00	S055		Remote Microphone Module	L3 Communications	SEA Repair
S056-0030-00	S056	5965-01-520-9623	Remote Microphone Module	L3 Communications	SEA Repair
S056-0047-00	S056		Remote Microphone Module	L3 Communications	SEA Repair
S056-0048-00	S056		Remote Microphone Module	L3 Communications	SEA Repair
S056-0048-10	S056	5965-01-593-9931	Remote Microphone Module	L3 Communications	SEA Repair
S056-0048-15	S056		Remote Microphone Module	L3 Communications	SEA Repair
S056-0049-00	S056		Remote Microphone Module	L3 Communications	SEA Repair
S056-0050-00	S056		Remote Microphone Module	L3 Communications	SEA Repair
S056-0051-00	S056		Remote Microphone Module	L3 Communications	SEA Repair
S056-1048-00	S056	5965-01-535-4571	Remote Microphone Module	L3 Communications	SEA Repair
S058-0048-00	S058		Remote Microphone Module	L3 Communications	SEA Repair
S058-0048-01	S058		Remote Microphone Module	L3 Communications	SEA Repair
S058-0148-10	S058		Remote Microphone Module	L3 Communications	SEA Repair
S100-0080-00	A100S	5835-01-459-8659	Solid State CVR	L3 Communications	SEA Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
S100-0080-01	A100S	5930-01-207-9528	Solid State CVR	L3 Communications	SEA Repair
S150-0020-00	S150	5895-01-432-3148	Microphone Preamplifier Module	L3 Communications	SEA Repair
S151-0020-00	S151	1680-01-525-8838	SSCVR Control Unit	L3 Communications	SEA Repair
S151-0030-00	S151	5821-01-595-1545	SSCVR Control Unit	L3 Communications	SEA Repair
S151-0040-00	S151	1680-01-652-8667	SSCVR Control Unit	L3 Communications	SEA Repair
S151-0050-00	S151		SSCVR Control Unit	L3 Communications	SEA Repair
S151-0060-00	S151		SSCVR Control Unit	L3 Communications	SEA Repair
S152-0020-00	S152	6110-01-552-8870	SSCVR Control Unit	L3 Communications	SEA Repair
S152-0020-01	S152	5965-01-633-7662	SSCVR Control Unit	L3 Communications	SEA Repair
S152-0030-00	S152	5835-01-560-6516	SSCVR Control Unit	L3 Communications	SEA Repair
S152-0030-01	S152		SSCVR Control Unit	L3 Communications	SEA Repair
S152-0040-00	S152		SSCVR Control Unit	L3 Communications	SEA Repair
S160-0020-00	S160		Microphone Preamplifier Module	L3 Communications	SEA Repair
S161-0020-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0020-10	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0030-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0040-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0050-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0060-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0080-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0090-00	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-0090-02	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-1090-20	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-1120-10	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-1390-01	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-1390-02	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S161-1390-03	S161		SSCVR Control Unit	L3 Communications	SEA Repair
S162-0020-00	S162	5835-00-019-1816	SSCVR Control Unit	L3 Communications	SEA Repair
S162-0030-00	S162	5835-01-572-9308	SSCVR Control Unit	L3 Communications	SEA Repair
S162-0040-00	S162		SSCVR Control Unit	L3 Communications	SEA Repair
S200-0012-00	A200S		SSCVR	L3 Communications	SEA Repair
S251-1120-00	S251		SSCVR Control Unit	L3 Communications	SEA Repair
S251-1130-00	S251		SSCVR Control Unit	L3 Communications	SEA Repair
S251-1170-00	S251		SSCVR Control Unit	L3 Communications	SEA Repair
S261-0050-00	S261		SSCVR Control Unit	L3 Communications	SEA Repair
S261-1120-00	S261		SSCVR Control Unit	L3 Communications	SEA Repair
S261-1121-00	S261		SSCVR Control Unit	L3 Communications	SEA Repair
S261-1130-00	S261	1680-01-589-6616	SSCVR Control Unit	L3 Communications	SEA Repair
SA4550-001	SA4550		Primary Attitude Display - Black	Sandel Avionics	SEA Exchange
SG102-000	SG102		AHRS Unit - Piston Aircraft	Sandel Avionics	SEA Exchange
SG102-100	SG102		AHRS (Turbine Aircraft)	Sandel Avionics	OEM Dealer Repair
SG102-200	SG102		AHRS Unit - Helicopter	Sandel Avionics	OEM Dealer Repair

Part Number	Model	NSN	Description	Manufacturer	Capability
SN3308-00-BL	SN3308		EHSI	Sandel Avionics	OEM Dealer Repair
SN3308-00-BR			EHSI Display	Sandel Avionics	OEM Dealer Repair
SN3500-002	SN3500		EHSI (Black)	Sandel Avionics	SEA Exchange
SN3500-004	SN3500	6605-01-630-2286	EHSI (Black - High Vibration)	Sandel Avionics	SEA Exchange
SPC-10(F)	SPC-10F		Static Inverter	KGS Electronics	SEA Exchange
SPC-38B	SPC-38(B)		Inverter (28VDC TO 115VAC/400Hz/375VA)	KGS Electronics	SEA Exchange
SPC-75B	SPC-75(B)	6130-01-415-2375	Inverter	KGS Electronics	SEA Exchange
SPS1307	SPS-1307	6130-01-281-4747	Static Inverter	KGS Electronics	SEA Exchange
SPS-1307B	SPS1307B		Static Inverter	KGS Electronics	SEA Exchange
SPS-306B	SPS-306B		Inverter	KGS Electronics	SEA Exchange
SPS-306B-3	SPS306B3		Static Inverter	KGS Electronics	SEA Exchange
SR-151A	SR-151-A	6685-00-515-3996	Pressure Indicator	KGS Electronics	SEA Exchange
SR-152A	SR-152-A	6685-00-526-5625	Pressure Indicator	KGS Electronics	SEA Exchange
SS40	SS-40	4720-00-052-0112	Inverter 28vdc - 115 vac 60hz 400va	KGS Electronics	SEA Exchange
SS50	SS-50	5930-00-009-1378	Static Inverter	KGS Electronics	SEA Exchange
ST3400-000	ST3400		TAWS/RMI (Class A - Black)	Sandel Avionics	SEA Exchange
ST3400-001	ST3400		TAWS/RMI (Class A - Gray)	Sandel Avionics	SEA Exchange
ST3400-100	ST3400		TAWS/RMI (Class B - Black)	Sandel Avionics	SEA Exchange
ST3400-102	ST3400		TAWS/RMI (Class B - Gray)	Sandel Avionics	OEM Dealer Repair
ST-901	ST901		GPSS Converter	Genesys Aerosystems	OEM Dealer Repair