



Southeast Aerospace, Inc
1399 General Aviation Dr
Melbourne, Florida 32935 USA
sales@seaerospace.com
Tel: 321-255-9877
Fax: 321-255-9608
www.seaerospace.com

Airbus AS365N Capabilities List

| Part Number | Model | Description | Capability |
|----------------|----------|---------------------|----------------------------|
| 011-01060-00 | GNS-430W | GPS/Nav/Comm | Repair, Spares, & Exchange |
| 011-01600-40 | GNS-430W | GPS/Nav/Comm | Repair, Spares, & Exchange |
| 064-1023-00 | KTR-908 | VHF Comm | Repair, Spares, & Exchange |
| 066-01153-0101 | KRA-405B | Rad Alt Transceiver | Repair, Spares, & Exchange |
| 066-04034-0101 | KLN-900 | GPS Receiver | Repair, Spares, & Exchange |
| 066-04034-0102 | KLN-900 | GPS Receiver | Repair, Spares, & Exchange |
| 066-04034-0104 | KLN-900 | GPS Receiver | Repair, Spares, & Exchange |
| 066-1066-25 | KDM-706A | DME Transceiver | Repair, Spares, & Exchange |
| 066-1069-00 | KDI-572 | DME Indicator | Repair, Spares, & Exchange |
| 066-1071-00 | KXP-756 | Transponder | Repair, Spares, & Exchange |
| 066-1077-00 | KDF-806 | ADF Receiver | Repair, Spares, & Exchange |
| 066-1077-01 | KDF-806 | ADF Receiver | Repair, Spares, & Exchange |
| 066-1078-10 | KNR-634A | Nav Receiver | Repair, Spares, & Exchange |
| 066-3034-06 | KI-207 | CDI | Repair, Spares, & Exchange |
| 066-3084-32 | IN-182A | Radar Indicator | Repair, Spares, & Exchange |
| 071-01519-0101 | ART-2000 | Radar Transceiver | Repair, Spares, & Exchange |
| 071-1276-08 | KFS-576A | Transponder Control | Repair, Spares, & Exchange |
| 071-1282-65 | KFS-598A | Comm Control | Repair, Spares, & Exchange |
| 071-1283-17 | KFS-564A | Nav Control | Repair, Spares, & Exchange |
| 071-1284-12 | KFS-586A | ADF Control | Repair, Spares, & Exchange |
| 4000831-0105 | RT-1401B | Radar Transceiver | Repair, Spares, & Exchange |
| 622-1233-001 | DME-40 | DME Transceiver | Repair, Spares, & Exchange |
| 622-1270-001 | TDR-90 | Transponder | Repair, Spares, & Exchange |
| 622-2506-003 | RMI-36 | RMI | Repair, Spares, & Exchange |
| 622-3915-001 | IND-40 | DME Indicator | Repair, Spares, & Exchange |
| 622-6137-001 | VIR-32 | Nav Receiver | Repair, Spares, & Exchange |
| 622-6137-201 | VIR-32 | Nav Receiver | Repair, Spares, & Exchange |

| Part Number | Model | Description | Capability |
|--------------|----------|-----------------|----------------------------|
| 622-6263-003 | DME-42 | DME Transceiver | Repair, Spares, & Exchange |
| 622-6520-004 | CTL-22 | Comm Control | Repair, Spares, & Exchange |
| 622-6521-012 | CTL-32 | Nav Control | Repair, Spares, & Exchange |
| 622-6524-004 | IND-42A | DME Control | Repair, Spares, & Exchange |
| 622-7293-101 | VHF-422B | VHF Comm | Repair, Spares, & Exchange |
| 822-1115-001 | VHF-422C | VHF Comm | Repair, Spares, & Exchange |
| 822-1115-021 | VHF-422C | VHF Comm | Repair, Spares, & Exchange |