



Southeast Aerospace, Inc
1399 General Aviation Dr
Melbourne, Florida 32935 USA
sales@seaerospace.com
Tel: 321-255-9877
Fax: 321-255-9608
www.seaerospace.com

ATR 42/72 Capabilities List

Part Number	Model	Description	Capability
064-1023-00	KTR-908	VHF Comm	Repair, Spares, Exchange
066-1066-11	KDM-706	DME	Repair, Spares, Exchange
066-1066-20	KDM-706A	DME	Repair, Spares, Exchange
066-1066-22	KDM-706A	DME	Repair, Spares, Exchange
066-1066-24	KDM-706A	DME	Repair, Spares, Exchange
066-1071-00	KXP-756	Transponder	Repair, Spares, Exchange
066-1077-00	KDF-806	ADF Receiver	Repair, Spares, Exchange
066-1078-04	KNR-634	Nav Receiver	Repair, Spares, Exchange
071-1192-14	KFS-576	Transponder Control	Repair, Spares, Exchange
071-1210-08	KFS-586	ADF Control	Repair, Spares, Exchange
071-1215-34	KFS-598	Comm Control	Repair, Spares, Exchange
071-1216-20	KFS-564	Nav Control	Repair, Spares, Exchange
071-1234-00	KA-44B	ADF Antenna	Repair, Spares, Exchange
17M800-251	F800	FDR	Spares, Exchange
17M800-261	F800	FDR	Spares, Exchange
301-2000		Emergency Light Power Supply	Spares, Exchange
4013013-913	VS-200	VSI	Spares, Exchange
4016341-906	BA-141	Altimeter	Spares, Exchange
520-3337-213	D3337LB61C	RMI	Spares, Exchange
622-1270-001	TDR-90	Transponder	Repair, Spares, Exchange
622-2362-001	ADF-60A	ADF Receiver	Repair, Spares, Exchange
622-2363-001	ANT-60A	ADF Antenna	Repair, Spares, Exchange
622-6137-001	VIR-32	Nav Receiver	Repair, Spares, Exchange
622-6137-201	VIR-32	Nav Receiver	Repair, Spares, Exchange
622-6152-011	VHF-22A	VHF Comm	Repair, Spares, Exchange
622-6263-001	DME-42	DME	Repair, Spares, Exchange
622-6263-003	DME-42	DME	Repair, Spares, Exchange
622-6471-002	AAC-220P	Antenna Coupler	Repair, Spares, Exchange
622-6520-003	CTL-22	Comm Control	Repair, Spares, Exchange
622-6521-011	CTL-32	Nav Control	Repair, Spares, Exchange
622-6522-003	CTL-62	ADF Control	Repair, Spares, Exchange
622-6523-007	CTL-92	Transponder Control	Repair, Spares, Exchange
622-6557-011	TCR-230	HF Transceiver	Repair, Spares, Exchange
622-6590-001	CAD-62	Control Adapter	Repair, Spares, Exchange
622-6667-001	PWR-230	HF Power Amplifier	Repair, Spares, Exchange
622-9210-002	TDR-94D	Transponder	Repair, Spares, Exchange
622-9210-003	TDR-94D	Transponder	Repair, Spares, Exchange
64141-362-1		Standby Altimeter	Spares, Exchange
64141-372-1		Standby Altimeter	Spares, Exchange
7002260-822	SM-300	Servo Actuator	Spares, Exchange

Part Number	Model	Description	Capability
7002260-922	SM-300	Servo Actuator	Spares, Exchange
7002860-909	SI-285	Airspeed Indicator	Spares, Exchange
93A100-80	A100A	CVR	Repair, Spares, Exchange
93A100-83	A100A	CVR	Repair, Spares, Exchange
93A151-50	A151B	CVR Control	Repair, Spares, Exchange
965-0476-088	Mark II	GPWS	Spares, Exchange
DK100		ULB	Repair, Spares, Exchange
DK120		ULB	Repair, Spares, Exchange
H321BDM1		Horizon Gyro	Spares, Exchange
MI-585350-5	WR-800	Radar Transceiver	Spares, Exchange