



**Southeast Aerospace, Inc**  
1399 General Aviation Dr  
Melbourne, Florida 32935 USA  
[sales@seaerospace.com](mailto:sales@seaerospace.com)  
Tel: 321-255-9877  
Fax: 321-255-9608  
[www.seaerospace.com](http://www.seaerospace.com)

## DASH 8 Capabilities List

Part Number	Model	Description	Capability
060-0015-00	KG-102A	Directional Gyro	Repair, Spares, Exchange
064-1023-00	KTR-908	VHF Comm Transceiver	Repair, Spares, Exchange
066-03062-0002	KEA-346	Servoed Encoding Altimeter	Repair, Spares, Exchange
066-1066-23	KDM-706A	DME	Repair, Spares, Exchange
066-1077-00	KDF-806	ADF Receiver	Repair, Spares, Exchange
066-1077-01	KDF-806	ADF Receiver	Repair, Spares, Exchange
066-1078-04	KNR-634	Nav Receiver	Repair, Spares, Exchange
066-3060-02	KEA-346	Servoed Encoding Altimeter	Repair, Spares, Exchange
21140-1134-2		Airspeed Indicator	Spares, Exchange
21140-1150		Airspeed Indicator	Spares, Exchange
2587193-43	C-14A	Directional Gyro	Repair, Spares, Exchange
2593379-001	DRC-1	Dual Remote Compensator	Repair, Spares, Exchange
4002963-901	RH-445	Radio Magnetic Indicator	Spares, Exchange
4012373-905	SM-710	Servo	Spares, Exchange
4016341-905	BA-141	Barometric Altitude Indicator	Spares, Exchange
4026206-915	RI-306	Remote Controller	Spares, Exchange
4029529-901	RD-500A	Horizontal Situation Indicator	Spares, Exchange
520-3137-317	3137LB21C	Radio Magnetic Indicator	Spares, Exchange
522-2638-006	331A-3G	Course Indicator	Repair, Spares, Exchange
522-2644-011	328A-3G	Course Indicator	Repair, Spares, Exchange
522-3241-00	332E-4	Directional Gyro	Repair, Spares, Exchange
522-3241-000	332E-4	Directional Gyro	Repair, Spares, Exchange
522-4945-001	323A-2G	Flux Valve	Repair, Spares, Exchange
5550-8340N1L		Turn and Bank Indicator	Spares, Exchange
60-3844-1		Emergency Battery Power Supply	Spares, Exchange
60-3844-3		Emergency Battery Power Supply	Spares, Exchange
622-0876-001	VIR-30A	Nav Receiver	Repair, Spares, Exchange
622-1270-001	TDR-90	Transponder	Repair, Spares, Exchange
622-1879-001	VHF-20A	VHF Comm Transceiver	Repair, Spares, Exchange
622-1879-002	VHF-20A	VHF Comm Transceiver	Repair, Spares, Exchange
622-2362-001	ADF-60A	ADF Receiver	Repair, Spares, Exchange
622-2506-006	RMI-36	Radio Magnetic Indicator	Repair, Spares, Exchange
622-3710-001	ANT-60B	ADF Antenna	Repair, Spares, Exchange
622-4563-001	339H-6	Radio Altitude Indicator	Repair, Spares, Exchange
622-5812-001	FDU-70	Flux Valve	Repair, Spares, Exchange
622-6137-001	VIR-32	Navigation Receiver	Repair, Spares, Exchange
622-6137-201	VIR-32	Navigation Receiver	Repair, Spares, Exchange
622-6152-001	VHF-22A	VHF Comm Transceiver	Repair, Spares, Exchange
622-6152-011	VHF-22A	VHF Comm Transceiver	Repair, Spares, Exchange
622-6153-001	VHF-22B	VHF Comm Transceiver	Repair, Spares, Exchange

Part Number	Model	Description	Capability
622-6263-001	DME-42	DME Transceiver	Repair, Spares, Exchange
622-6389-001	VHF-21A	VHF Comm Transceiver	Repair, Spares, Exchange
622-6520-001	CTL-22	Comm Control	Repair, Spares, Exchange
622-6521-009	CTL-32	Nav Control	Repair, Spares, Exchange
622-6522-001	CTL-62	ADF Control	Repair, Spares, Exchange
622-6523-XXX	CTL-92	Transponder Control	Repair, Spares, Exchange
622-6590-001	CAD-62	Control Adapter	Repair, Spares, Exchange
622-7318-001	IND-42C	DME Indicator	Repair, Spares, Exchange
7000622-901	VG-14A	Vertical Gyro	Repair, Spares, Exchange
7000836-913	AD-500C	Attitude Director Indicator	Spares, Exchange
7001179-901	RD-550A	Horizontal Situation Indicator	Spares, Exchange
7001179-951	RD-550A	Horizontal Situation Indicator	Spares, Exchange
7001182-909	AD-550A	Attitude Director Indicator	Spares, Exchange
7001182-913	AD-550C	Attitude Director Indicator	Spares, Exchange
7001840-912	RT-300	Radio Altimeter R/T	Repair, Spares, Exchange
7001840-918	RT-300	Radio Altimeter R/T	Repair, Spares, Exchange
7002260-722	SM-300	Servo Drive	Repair, Spares, Exchange
7002260-723	SM-300	Servo Drive	Spares, Exchange
70-0253-7			Spares, Exchange
7004577-903	AL-801	Altitude Preselect Control & Display	Spares, Exchange
7010133	FX-600	Flux Valve	Repair, Spares, Exchange
8047/10	8047-10	Altimeter	Spares, Exchange
8047/10DH	8047-10DH	Altimeter	Spares, Exchange
8047/20DH	8047-20DH	Altimeter	Spares, Exchange
965-0476-088	MARK II	GPWS	Spares, Exchange
980-6005-077	CVR	CVR	Spares, Exchange
H321ALM1		Horizon Gyro	Spares, Exchange