



Southeast Aerospace, Inc
1399 General Aviation Dr
Melbourne, Florida 32935 USA
sales@seaerospace.com
Tel: 321-255-9877
Fax: 321-255-9608
www.seaerospace.com

EMB 120 Capabilities List

Part Number	Model	Description	Capability
30-0191-7		Nav Light	SEA Exchange
30-0191-8		Nav Light	SEA Exchange
30-0876-9		Strobe Light	SEA Exchange
30-1192-5		Strobe Light	SEA Exchange
540-45100-E2111	45100-E2111	Altitude Alerter	SEA Exchange
501-1197-09	AI-804AH	Standby Horizon Gyro	SEA Exchange
501-1228-04	PS-835D	Emergency Power Supply	SEA Repair
519-28704-E2101	28704-E2101	Encoding Altimeter	SEA Exchange
519-28704-F2101	28704-F2101	Encoding Altimeter	SEA Exchange
540-45100-E2111	45100-E2111	Altitude Alerter	SEA Exchange
570-23932-981	23932-981	Encoding Altimeter	SEA Exchange
570-24929-951	24929-951	Encoding Altimeter	SEA Exchange
570-24929-J2002	24929-J2002	Encoding Altimeter	SEA Exchange
60-2799-1		POWER SUPPLY	SEA Exchange
622-2506-006	RMI-36	RMI	SEA Repair
622-2855-001	ALT-55B	Rad Alt Transceiver	SEA Repair
622-2937-004	ALI-55	Rad Alt Indicator	SEA Repair
622-4022-001	WXT-250A	Radar Transceiver	SEA Repair
622-4565-001	332D-11T	Vertical Gyro	SEA Repair
622-5734-002	SVO-65	Primary Servo	SEA Repair
622-6092-012	WXP-85A	Radar Control Panel	SEA Exchange
622-6137-001	VIR-32	Nav Receiver	SEA Repair
622-6137-201	VIR-32	Nav Receiver	SEA Repair
622-6152-001	VHF-22A	VHF Comm Transceiver	SEA Repair
622-6263-001	DME-42	DME	SEA Repair
622-6520-001	CTL-22	Comm Control	SEA Repair
622-6521-009	CTL-32	Nav Control	SEA Repair
622-6522-001	CTL-62	ADF Control	SEA Repair
787-6173-013	ADI-84	Attitude Direction Indicator	SEA Exchange
792-6694-001	332D-11A	Vertical Gyro	SEA Repair
9300-343		CVR Mount	SEA Exchange
93A100-80	A100A	CVR	SEA Repair
93A100-83	A100A	CVR	SEA Repair
93A152-20	A152B	CVR Control	SEA Repair
PC251-1C	PC2511C	Inverter	SEA Repair
SEDL-OC4BC		Oil Temp Pressure Indicator	SEA Exchange
SEL-OC29DH		RPM Indicator	SEA Exchange
S100-0080-00	A100S	SSCVR	SEA Repair