



**Southeast Aerospace, Inc**  
1399 General Aviation Dr  
Melbourne, Florida 32935 USA  
[sales@seaerospace.com](mailto:sales@seaerospace.com)  
Tel: 321-255-9877  
Fax: 321-255-9608  
[www.seaerospace.com](http://www.seaerospace.com)

## Hawker Beechjet 400 Capabilities List

Part Number	Model	Description	Capability
2587193-43	C-14A	Directional Gyro	SEA Repair
2593379-001	DRC-1	Dual Remote Compensator	SEA Repair
2594484	FX-220	Flux Valve	SEA Repair
4008519-916	SP-200	Autopilot Computer	SEA Exchange
4016341-906	BA-141	Altimeter	SEA Exchange
4018285-906	AL-285	Altitude Alerter	SEA Exchange
4018369-905	FZ-500	Flight Director Computer	SEA Exchange
4018639-907	PC-500	Autopilot Computer	SEA Exchange
4027170-904	RD-500	H.S.I.	SEA Exchange
501-1197-07	AI-804T	Standby Attitude Indicator	SEA Exchange
501-1228-04	PS-835D	Power Supply	SEA Repair
501-1228-06	PS-835F	Power Supply	SEA Repair
501-1412-03	AI-804BC	Attitude Indicator	SEA Exchange
60-1321-1		Emergency Exit Light	SEA Exchange
60-1755-1		Power Supply	SEA Exchange
622-0876-001	VIR-30A	Nav Receiver	SEA Repair
622-0876-201	VIR-30A	Nav Receiver	SEA Repair
622-1270-001	TDR-90	Transponder	SEA Repair
622-2362-001	ADF-60A	ADF Receiver	SEA Repair
622-2363-001	ANT-60A	ADF Antenna	SEA Repair
622-2855-001	ALT-55B	Rad Alt Transceiver	SEA Repair
622-2855-002	ALT-55B	Rad Alt Transceiver	SEA Repair
622-2855-011	ALT-55B	Rad Alt Transceiver	SEA Repair
622-3710-001	ANT-60B	Dual ADF Antenna	SEA Repair
622-4022-001	WXT-250A	Radar Transceiver	SEA Repair
622-4160-017	DRI-55	Rad Alt Indicator	SEA Repair
622-4331-001	IND-300	Radar Indicator	SEA Repair
622-5027-102	SVO-85B	Servo	SEA Repair
622-5029-101	SVO-85B	Servo	SEA Repair
622-5812-001	FDU-70	Flux Valve	SEA Repair
622-6152-001	VHF-22A	VHF Comm	SEA Repair
622-6152-002	VHF-22A	VHF Comm	SEA Repair
622-6152-011	VHF-22A	VHF Comm	SEA Repair
622-6263-001	DME-42	DME Tranceiver	SEA Repair
622-6263-003	DME-42	DME Tranceiver	SEA Repair
622-6520-007	CTL-22	Comm Control	SEA Repair
622-6521-015	CTL-32	Nav Control	SEA Repair
622-6522-007	CTL-62	ADF Control	SEA Repair
622-6523-008	CTL-92	Transponder Control	SEA Repair
622-6523-208	CTL-92	Transponder Control	SEA Repair

Part Number	Model	Description	Capability
622-6524-003	IND-42A	DME Indicator	SEA Repair
622-7309-101	DME-442	DME	SEA Repair
622-7318-004	IND-42C	DME Indicator	SEA Repair
622-7382-001	ADF-462	ADF Receiver	SEA Repair
7000466-902	AD-650A	Attitude Indicator	SEA Exchange
7000469-902	RD-650B	H.S.I.	SEA Exchange
7000836-902	AD-500A	Attitude Indicator	SEA Exchange
7001179-954	RD-550B	Attitude Indicator	SEA Exchange
7001182-902	AD-550	Attitude Indicator	SEA Exchange
7002493-902	RD-450	H.S.I.	SEA Exchange
8047-10		Altimeter	SEA Exchange
93A100-80	A100A	CVR	SEA Repair
93A100-83	A100A	CVR	SEA Repair
93A151-30	A152B	CVR Control	SEA Repair
PC-250		Static Inverter	SEA Repair