

KAS-297 Application Chart

By Aircraft Type

065-0046-02	Aerostar 600
065-0046-02	Aerostar 601
065-0046-02	Aerostar 601P
065-0046-02	Aerostar 602P
065-0046-02	Beech K35
065-0046-02	Beech M35
065-0046-02	Beech N35
065-0046-02	Beech P35
065-0046-02	Beech S35
065-0046-02	Beech V35
065-0046-02	Beech V35A
065-0046-02	Beech V35B
065-0046-02	Beechcraft A36
065-0046-02	Beechcraft A36TC
065-0046-02	Beechcraft B36TC
065-0046-02	Beechcraft Baron 58
065-0046-02	Beechcraft Baron 58A
065-0046-02	Beechcraft Baron 58P
065-0046-02	Beechcraft Baron 58PA
065-0046-02	Beechcraft Baron 58TC
065-0046-02	Beechcraft Baron 58TCA
065-0046-02	Beechcraft Baron 95-55
065-0046-02	Beechcraft Baron 95-A55
065-0046-02	Beechcraft Baron 95-B55
065-0046-02	Beechcraft Baron 95-B55A
065-0046-02	Beechcraft Baron 95-C55
065-0046-02	Beechcraft Baron D55
065-0046-02	Beechcraft Baron E55
065-0046-02	Beechcraft Baron E55A
065-0046-02	Cessna 210L
065-0046-02	Cessna 210M
065-0046-02	Cessna 210N
065-0046-02	Cessna 310P
065-0046-02	Cessna 310Q
065-0046-02	Cessna 310R
065-0046-02	Cessna 340A
065-0046-02	Cessna 402C
065-0046-02	Cessna 414A
065-0046-02	Cessna 421C
065-0046-02	Cessna P210N
065-0046-02	Cessna T210L
065-0046-02	Cessna T210M
065-0046-02	Cessna T210N
065-0046-02	Cessna T310P
065-0046-02	Cessna T310Q
065-0046-02	Cessna T310R
065-0046-02	Mooney M20J
065-0046-02	Mooney M20K
065-0046-02	Piper Navajo PA-31
065-0046-02	Piper Navajo PA-31-325
065-0046-02	Piper Navajo PA-31-350
065-0046-02	Piper Seneca II PA-34-200T
065-0046-02	Piper Seneca III PA-34-220T