

KC-295 Application Chart

By Part Number

065-0034-00	Aerostar 600
065-0034-00	Aerostar 601
065-0034-00	Aerostar 601P
065-0034-00	Aerostar 602P
065-0034-00	Cessna 310P
065-0034-00	Cessna 310Q
065-0034-00	Cessna 310R
065-0034-00	Cessna T310P
065-0034-00	Cessna T310Q
065-0034-00	Cessna T310R
065-0034-00	Piper Arrow III PA28R-201
065-0034-00	Piper Arrow III PA28R-201T
065-0034-00	Cessna 210K
065-0034-00	Cessna 210L
065-0034-00	Cessna 210M
065-0034-00	Cessna 210N
065-0034-00	Cessna T210K
065-0034-00	Cessna T210L
065-0034-00	Cessna T210M
065-0034-00	Cessna T210N
065-0034-00	Cessna 340A
065-0034-00	Piper Arrow II PA28R-200
065-0034-00	Piper Aztec PA-23-250 Model F
065-0034-00	Cessna 337G
065-0034-00	Cessna 421C
065-0034-00	Navion Model H
065-0034-00	Piper Navajo PA-31
065-0034-00	Piper Navajo PA-31-325
065-0034-00	Piper Seneca II PA-34-200T
065-0034-00	Piper Seneca II PA-34-220T
065-0034-00	Beechcraft Baron 58
065-0034-00	Beechcraft Baron 58A
065-0034-00	Beechcraft Baron 58P
065-0034-00	Beechcraft Baron 58PA
065-0034-00	Beechcraft Baron 58TC
065-0034-00	Beechcraft Baron 58TCA
065-0034-00	Beechcraft Baron 95-55
065-0034-00	Beechcraft Baron 95-A55
065-0034-00	Beechcraft Baron 95-B55
065-0034-00	Beechcraft Baron 95-B55A
065-0034-00	Beechcraft Baron 95-C55
065-0034-00	Beechcraft Baron D55
065-0034-00	Beechcraft Baron E55
065-0034-00	Beechcraft Baron E55A
065-0034-00	Beechcraft Bonanza 36
065-0034-01	Beechcraft Bonanza A36
065-0034-01	Beechcraft Bonanza F33A
065-0034-03	Beechcraft Bonanza K35
065-0034-03	Beechcraft Bonanza M35
065-0034-03	Beechcraft Bonanza N35
065-0034-03	Beechcraft Bonanza P35
065-0034-03	Beechcraft Bonanza S35
065-0034-04	Beechcraft Bonanza V35
065-0034-05	Beechcraft Bonanza V35A
065-0034-06	Beechcraft Bonanza V35B
065-0034-07	Piper Aztec PA-23-250 Model C,D & E
065-0034-07	Piper chieftain PA-31-350
065-0034-07	Rockwell Model 112
065-0034-08	Rockwell Model 112B
065-0034-09	Rockwell Model 112TC
065-0034-09	Rockwell Model 112TCA
065-0034-09	Rockwell Model 114
065-0034-09	Beechcraft Bonanza 35-B33
065-0034-09	Beechcraft Bonanza 35-C33A

KC-295 Application Chart

By Part Number

065-0034-09	Cessna 404 (1979 and before)
065-0034-09	Cessna 404 (1980 and after)
065-0034-09	Cessna 414A
065-0034-09	Cessna 182P
065-0034-09	Cessna 182Q
065-0034-10	Piper Lance PA32RT-300
065-0034-10	Piper Lance PA32RT-300T
065-0034-10	Bellanca Viking 17-30A
065-0034-10	Bellanca Viking 17-31A
065-0034-10	Bellanca Viking 17-31ATC
065-0034-10	Cessna 402C
065-0034-10	Cessna R182
065-0034-10	Cessna TR182
065-0034-10	Beech 76
065-0034-11	Cessna P210N
065-0034-11	Beechcraft Bonanza A36
065-0034-12	Beechcraft Bonanza A36TC
065-0034-12	Beechcraft Bonanza B36TC
065-0034-12	Cessna Stationair U206F
065-0034-12	Cessna Stationair TU206F
065-0034-12	Cessna Stationair U206G
065-0034-12	Cessna Stationair TU206G
065-0034-13	Beech A36
065-0034-13	Beech B36TC
065-0034-13	Mooney M20K
065-0034-13	Mooney M20J
065-0034-14	Piper Seminole PA-44-180
065-0034-14	Beech A65
065-0034-15	Beech A65-8200
065-0034-15	Beech 70
065-0034-15	Beech 65-80
065-0034-16	Beech 65-A80
065-0034-16	Beech 65-A80-8800
065-0034-16	Beech 65-B80
065-0034-16	Piper Saratoga S.P. PA-32R-301
065-0034-17	Piper Saratoga S.P. PA-32R-301T
065-0034-17	Beech 58
065-0034-17	Beech 58A
065-0034-17	Beech 58TC
065-0034-17	Beech 58TCA
065-0034-17	Beech 58P
065-0034-17	Beech 58PA
065-0034-17	Beech 65 (Military L23F)